

CANopen Fieldbus manual

for Lexium MDrive

V1.00, 09.2014




CANopen

CE  REACH

Applicable to:

LMDOA42x	LMDOA42x
LMDOA57x	LMDOA57x
LMDOA85x	LMDOA85x

Schneider
 Electric

[illegible]

Important information

This manual is part of the product.

Carefully read this manual and observe all instructions.

Keep this manual for future reference.

Hand this manual and all other pertinent product documentation over to all users of the product.

Carefully read and observe all safety instructions and the chapter "Before you begin - safety information".

Some products are not available in all countries.

For information on the availability of products, please consult the catalog.

Subject to technical modifications without notice.

All details provided are technical data which do not constitute warranted qualities.

Most of the product designations are registered trademarks of their respective owners, even if this is not explicitly indicated.

This page intentionally left blank

Table of Contents

Important information	3
About this manual	1-1
Further reading.....	1-1
1 Introduction.....	1
1.1 CAN bus	1
1.2 CANopen technology	2
1.2.1 CANopen description language	2
1.2.2 Communication layers	2
1.2.3 Objects.....	3
1.2.4 CANopen profiles.....	4
2 Before you begin - safety information.....	5
2.1 Qualification of personnel.....	5
2.2 Intended use.....	5
2.3 Hazard categories	6
2.4 Basic information	7
2.5 Standards and terminology	8
3 Basics	9
3.1 Communication profile.....	9
3.1.1 Object dictionary	9
3.1.2 Communication objects	10
3.1.3 Communication relationships.....	13
3.2 Service data communication	15
3.2.1 Overview	15
3.2.2 SDO data exchange	15
3.2.3 SDO message	16
3.2.4 Reading and writing data	17
3.2.5 Reading data longer than 4 bytes	19
3.3 Process data communication	21
3.3.1 Overview.....	21
3.3.3 PDO message	22
3.3.4 PDO mapping	25
3.4 Synchronization.....	28
3.5 Emergency service.....	30
3.6 Network management services	32
3.6.1 NMT services for device control	33
3.6.2 NMT services for connection monitoring	35
3.6.2.1 Node guarding / Life guarding	35
3.6.2.2 Heartbeat	37
4 Installation.....	39
5 Commissioning.....	41
5.1 Commissioning the device	41
5.2 Address and baud rate	42
5.3 Commissioning via supplied utility.....	42
5.4 Commissioning via Layer Setting Services (LSS)	42
5.5 Commissioning via switch mode global.....	43
5.6 Commissioning via switch mode selective	45

6	Operation	47
6.1	Operating states	48
6.1.1	State diagram	48
6.2	Control and status	50
6.2.1	Controlling the state machine	50
6.2.2	Indication of the operating state	51
6.3	Option code objects	53
6.3.1	Abort connection (6007 _h)	53
6.3.2	Error code (603F _h)	53
6.3.3	Quick stop (605A _h)	54
6.3.4	Shutdown (605B _h)	55
6.3.5	Disable operation (605C _h)	55
6.3.6	Halt (605D _h)	56
6.3.7	Fault reaction (605E _h)	56
6.4	Supported modes of operation	57
6.4.1	Mode of operation (6060 _h)	57
6.4.2	Mode of operation display (6061 _h)	58
6.4.3	Supported drive modes (6502 _h)	58
6.5	Profile position mode	59
6.5.1	Overview	59
6.5.2	Functional description	60
6.5.3	Control word definition for profile position	62
6.5.4	Status word definition for profile position	62
6.5.5	607A _h Target position	63
6.5.6	607E _h Polarity	63
6.5.7	6081 _h Profile velocity	64
6.5.8	6082 _h End velocity	64
6.5.9	6083 _h Profile acceleration	65
6.5.10	6084 _h Profile deceleration	65
6.5.11	6085 _h Quick stop deceleration	66
6.5.12	6086 _h Motion profile type	66
6.5.13	Profile position application example	67
6.6	Profile velocity mode	68
6.6.1	Overview	68
6.6.2	Control word definition for profile velocity	69
6.6.3	Status word definition for profile velocity	69
6.6.4	606C _h Velocity actual value	70
6.6.5	60F8 _h Maximum slippage	70
6.6.6	60FF _h Target velocity	71
6.6.7	Profile velocity application example	71
6.7	Homing mode	72
6.7.1	Overview	72
6.7.2	Control word definition for homing mode	72
6.7.3	Status word definition for homing mode	73
6.7.4	607C _h Homing offset	73
6.7.5	6098 _h Homing method	74
6.7.5	6099 _h Homing speeds	79
6.7.6	Homing mode application example	80
6.8	Torque mode (Closed loop models only)	81
6.8.1	Overview	81
6.8.2	Control word definition for profile torque mode	81
6.8.2	Control word definition for profile torque mode	82
6.8.3	Object 6071 _h : Target torque	82
6.8.4	Object 6077 _h : Torque actual value	83
6.8.5	Object 6087 _h : Torque slope	83
6.8.6	Profile torque example	83
6.9	Cyclic synchronous position	84
6.9.1	Overview	84
6.9.2	Controlword and statusword for csp	85

6.10	Position control function	86
6.10.1	Overview	86
6.10.2	6062 _h Position demand actual value	86
6.10.3	6063 _h Position actual value internal	86
6.10.4	6064 _h Position actual value	87
6.10.5	6065 _h Following error window	87
6.10.6	6066 _h Following error timeout	88
6.10.7	6067 _h Position window	88
6.10.8	6068 _h Position window time	89
6.11	Factors	90
6.11.1	608F _h Position encoder resolution	90
6.11.2	6092 _h Feed and drive shaft resolution	91
6.12	Optional application FE (general I/O)	92
6.12.1	60FD _h Digital inputs	92
6.12.1	60FE _h Digital outputs	93
7	Diagnostics and Troubleshooting	95
7.1	Fieldbus communication error diagnostics	95
7.2	Error diagnostics via fieldbus	96
7.2.1	Message objects	96
7.2.2	Messages on device status	96
7.3	CANopen error messages	96
7.3.1	Error register (1001 _h)	97
7.3.2	Pre-defined error (1003 _h)	97
7.4	Status LED	99
8	Object Dictionary	101
8.1	Specification for the objects	101
8.2	Overview of object group 1000 _h	102
8.3	Overview of manufacturer specific objects group 2000 _h	105
8.4	Overview of assignment objects group 6000 _h	108
8.5	Details of object group 1000 _h	110
8.5.1	1000 _h Device type	110
8.5.2	1001 _h Error register	110
8.5.3	1003 _h Pre-defined error field	111
8.5.4	1005 _h COB ID SYNC message	112
8.5.5	1007 _h Sync window length	113
8.5.6	1008 _h Mfg. device name	113
8.5.7	1009 _h Mfg. hardware version	114
8.5.8	100A _h Mfg. software version	114
8.5.9	100C _h Guard time	115
8.5.10	100D _h Life time factor	116
8.5.10	1010 _h Store parameters	117
8.5.11	1011 _h Restore default parameters	119
8.5.12	1012 _h COB-ID time stamp object	121
8.5.13	1014 _h COB-ID emergency error object	122
8.5.14	1015 _h Inhibit time EMCY object	123
8.5.15	1017 _h Producer heartbeat time	123
8.5.16	1018 _h Identity object	124
8.5.18	1400 – 1403 _h Receive PDO communications parameter	126
8.5.19	1600 – 1603 _h RxPDO mapping parameter	129
8.5.20	1800 – 1803 _h RxPDO mapping parameter	132
8.5.21	1A00 – 1A02 _h TxPDO mapping parameter	133
8.6	Details of object group 2000 _h (Mfg specific)	135
8.6.1	2000 _h I/O configuration	135
8.6.2	2003 _h Configure input switches	137
8.6.3	2004 _h Configure input filter mask	138

8.6.4	2006 _h	Configure input filter time.....	141
8.6.7	2007 _h	Inhibit switch reaction	143
8.6.8	2008 _h	Output definition	144
8.6.9	2010 _h	Analog input configuration	145
8.6.10	2014 _h	Auxiliary power input monitoring.....	146
8.6.11	2015 _h	+VDC input monitoring	147
8.6.12	2018 _h	PCB temperature options.....	148
8.6.13	2019 _h	Bridge temperature options.....	150
8.6.14	2020 _h	Software limits as hardware.....	151
8.6.15	2022 _h	Actual position software limit.....	153
8.6.16	2030 _h	Output bridge polarity.....	154
8.6.17	2031 _h	Unit options (encoder enable, trip/capture enable)	154
8.6.18	2033 _h	Capture input parameters	156
8.6.19	2034 _h	Bridge on settle time	157
8.6.20	2035 _h	Brake settle allow time	158
8.6.21	2036 _h	Hold current delay time	160
8.6.22	2037 _h	Bridge on to encoder settle time	160
8.6.23	2038 _h	Trip output configuration	161
8.6.24	2098 _h	Homing configuration	162
8.6.25	2204 _h	Run current	163
8.6.26	2205 _h	Hold current	163
8.6.27	2211 _h	Position present point target	164
8.6.28	2212 _h	Position final point target.....	164
8.6.29	2221 _h	Following error	165
8.6.30	2401 _h	General purpose user variable.....	165
8.6.31	2504 _h	SEM options.....	166
8.6.32	2701 _h	hMTechnology enable.....	166
8.6.33	2702 _h	hMTechnology configuration.....	167
8.6.34	2703 _h	Make-up velocity	168
8.6.35	2704 _h	Torque velocity.....	169
8.6.36	2740 _h	Clear locked rotor.....	169
8.6.37	2741 _h	hMTechnology status (filtered).....	170
8.6.38	2742 _h	hMTechnology status (unfiltered).....	171
8.6.39	2743 _h	hMTechnology status byte filter	172
8.7		Details of object group 5000 _h (Mfg factory specific).....	172
8.8		Details of assignment objects group 6000 _h	172
9		CANopen configurator	173

List of Figures

Figure 1.1: CANopen layer model.....	2
Figure 1.2: Device model with object dictionary.....	3
Figure 1.3: CANopen reference model	4
Figure 3.1: Communication objects.....	10
Figure 3.2: CAN message and simplified CANopen message....	11
Figure 3.3: COB ID with function code and node address.....	11
Figure 3.4: Master – slave relationship	13
Figure 3.5: Client – server relationship	14
Figure 3.6: Producer – consumer relationship	14
Figure 3.7: SDO message exchange with request and response	15
Figure 3.8: SDO message example	16
Figure 3.9: Rearranging numeric values greater than 1 byte.....	16
Figure 3.10: Writing parameter values	17
Figure 3.11: Reading a parameter value	18
Figure 3.12: Response with error message (error response)	18
Figure 3.13: Transmitting the first message.....	19
Figure 3.14: PDO data exchange.....	21
Figure 3.15: Activating PDOs via subindex 01 _h , bit 31	22
Figure 3.16: Receive PDOs	23
Figure 3.17: Transmit PDOs	24
Figure 3.18: PDO mapping	25
Figure 3.19: Structure of entries for PDO mapping.....	26
Figure 3.20: SYNC message	28
Figure 3.21: Synchronization times.....	28
Figure 3.22: Cyclic and acyclic transmission	29
Figure 3.23: Error message via EMCY objects.....	30
Figure 3.24: EMCY message	30
Figure 3.25: NMT services via the master-slave relationship	32
Figure 3.26: NMT state machine and communication objects	33
Figure 3.27: NMT message.....	34
Figure 3.28: Acknowledgement of the NMT slave	35
Figure 3.29: «Node Guarding» and «Life Guarding»	36
Figure 3.30: «Heartbeat» monitoring	37
Figure 5.1: LSS message structure.....	42
Figure 6.1: State diagram.....	48
Figure 6.2: Trajectory generator for profile position	59
Figure 6.3: Set-point transmission from host	60
Figure 6.4: Single set-point mode 6040 _h , bit 5=0	61
Figure 6.5: Set of set-points 6040 _h bit 5=1	62
Figure 6.6: Profile velocity control function	68
Figure 6.8 : The homing function	72
Figure 6.7: The homing offset	73
Figure 6.9: Homing on the negative limit switch and index	74
Figure 6.10: Homing on the positive limit switch and index	75
Figure 6.11: Homing on positive home switch and index.....	75
Figure 6.12: Homing on negative home switch and index	76
Figure 6.13: Homing on home switch and index - pos. initial.....	77
Figure 6.14: Homing on home switch and index - neg. initial.....	77
Figure 6.15: Homing without and index pulse.....	78
Figure 6.16: Homing on an index pulse	78
Figure 6.17: Profile torque mode.....	81
Figure 6.18: Cyclic synchronous position control function	84
Figure 8.1: Storage write access signature.....	117


Figure 8.2: Storage read access structure	117
Figure 8.3: Restore default parameters write access signature.119	
Figure 8.4: Restore default parameters write access structure. 119	
Figure 8.5: Structure of the COB-ID TIME entry	121
Figure 8.6: Structure of the EMCY identifier entry	122
Figure 8.7: Structure of the revision number.....	124
Figure 8.8: Structure of the PDO COB-ID entry	126
Figure 8.9: Structure of the PDO mapping entry.....	129
Figure 8.10: Principle of PDO mapping.....	130
Figure 8.12: Input filter mask.....	138
Figure 8.13: Software limits as hardware functions	151
Figure 8.14: Bridge to brake timing	158
Figure 8.15: Brake functions block diagram.....	159

List of Tables

Table 3.1: Example index and subindex entries	9
Table 3.2: COB IDs of communication objects	12
Table 3.3: Command code for writing parameter values	17
Table 3.4: Command code for transmitting a read value	18
Table 3.5: Command code data lengths > 4 bytes	20
Table 3.6: Communication objects for PDO	22
Table 3.7: Dynamic PDO mapping parameters	25
Table 3.8: Subindex object length entries	26
Table 3.9: Supported PDO mapping objects.....	27
Table 3.10: NMT state machine transitions.....	33
Table 6.1: Operating states.....	49
Table 6.2: Error class	49
Table 6.3: Control word value range.....	50
Table 6.4: Status word status bit states	51
Table 6.5: Operation mode status.....	52
Table 6.6: Abort Connection Option Code	53
Table 6.7: Quick stop option codes.....	54
Table 6.8: Shutdown option codes.....	55
Table 6.9:: Disable operation option codes.....	55
Table 6.10: Halt option codes	56
Table 6.11: Fault reaction option codes	56
Table 6.12: Mode of operation	57
Table 6.13: Input data objects for profile position	59
Table 6.13: Input data objects for profile position	60
Table 6.14: Set-point transmission from host bit states	61
Table 6.15: Profile position mode control word (6040 _h) bit state meanings.....	62
Table 6.16: Profile position mode status word (6041 _h).....	62
Table 6.17: Profile position mode application example.....	67
Table 6.18: Profile velocity mode control word (6040 _h)	69
Table 6.19: Profile velocity mode status word (6041 _h)	69
Table 6.20: Profile velocity mode application example	71
Table 6.21: Homing mode control word (6040 _h)	72
Table 6.22: Homing mode status word (6041 _h)	73
Table 6.23: Homing mode application example	80
Table 6.24: Profile torque mode control word (6040 _h)	81
Table 6.25: Profile torque mode status word (6041 _h)	82
Table 6.25: Profile torque application example	83
Table 6.26: Statusword for Cyclic Synchronous Position mode..	85
Table 7.1: Abort Connection Option Code	97
Table 7.2: Description of the error codes.....	98
Table 8.1: CANopen object codes	101
Table 8.2: CANopen data types.....	101
Table 8.3: Structure of read access	117
Table 8.4: Structure of write access.....	119
Table 8.5: Description of the TIME COB-ID entry	121

Table 8.6: Description of the COB-ID entry.....	122
Table 8.7: Description of the PDO COB-ID entry.....	126
Table 8.8: Description of the PDO COB-ID entry.....	127
Table 8.9: Inhibit switch reactions.....	143
Table 8.10: Brake and target reached output definition	144
Table 8.11: Description of limit reached flag 2020.01h.....	151
Table 8.12: Description of unit options object 2031.00h	155

About this manual



The information provided in this manual supplements the product hardware manual.

Source manuals The latest versions of the manuals can be downloaded from the Internet at:

<http://motion.schneider-electric.com/>

Source EDS files For easier engineering, Electronic Datasheet Files and product master data are available for download from the Internet at:

<http://motion.schneider-electric.com/>

Graphic User Interface software For easier configuration, a Graphic User Interface (GUI) is available for use with Lexium MDrive and Lexium MDrive product in conjunction with the optional MD-CC501-000 USB to CANopen interface cable kit. This software is available for download from the Internet at:

<http://motion.schneider-electric.com/>

Further reading

Recommended literature for further reading.

CAN users and manufacturers organization CiA - CAN in Automation
Am Weichselgarten 26
D-91058 Erlangen

<http://www.can-cia.org/>

- CANopen standards*
- CiA Standard 301 (DS301)
CANopen application layer and communication profile
 - CiA Standard 402 (DSP402)
Device profile for drives and motion control
 - ISO 11898: Controller Area Network (CAN) for high speed communication
 - EN 50325-4: Industrial communications subsystem based on ISO 11898 for controller device interfaces (CANopen)

Page intentionally left blank

1 Introduction

1

1.1 CAN bus

The CAN bus (Controller Area Network) was originally developed for fast, economical data transmission in the automotive industry. Today, the CAN bus is also used in industrial automation technology and has been further developed for communication at fieldbus level.

Features of the CAN bus

The CAN bus is a standardized, open bus enabling communication between devices, sensors and actuators from different manufacturers. The features of the CAN bus comprise

- Multi-master capability
Each device in the fieldbus can transmit and receive data independently without depending on an “ordering” master functionality.
- Message-oriented communication
Devices can be integrated into a running network without re-configuration of the entire system. The address of a new device does not need to be specified on the network.
- Prioritization of messages
Messages with higher priority are sent first for time-critical applications.
- Residual error probability
Various security features in the network reduce the probability of undetected incorrect data transmission to less than 10^{-11} .

Transmission technology

In the CAN bus, multiple devices are connected via a bus cable. Each network device can transmit and receive messages. Data between network devices are transmitted serially.

Network devices

Examples of CAN bus devices are

- Automation devices, for example, PLCs
- PCs
- Input/output modules
- Drives
- Analysis devices
- Sensors and actuators

1.2 CANopen technology

1.2.1 CANopen description language

CANopen is a device- and manufacturer-independent description language for communication via the CAN bus. CANopen provides a common basis for interchanging commands and data between CAN bus devices.

1.2.2 Communication layers

CANopen uses the CAN bus technology for data communication.

CANopen is based on the basic network services for data communication as per the ISO-OSI model model. 3 layers enable data communication via the CAN bus.

- Physical Layer
- Data Link Layer
- Application Layer




Figure 1.1: CANopen layer model

Physical Layer The physical layer defines the electrical properties of the CAN bus such as connectors, cable length and cable properties as well as bit coding and bit timing.

Data Link Layer The data link layer connects the network devices. It assigns priorities to individual data packets and monitors and corrects errors.

Application Layer The application layer uses communication objects (COB) to exchange data between the various devices. Communication objects are elementary components for creating a CANopen application.

1.2.3 Objects

Processes under CANopen are executed via objects. Objects carry out different tasks; they act as communication objects for data transport to the fieldbus, control the process of establishing a connection or monitor the network devices. If objects are directly linked to the device (device specific objects), the device functions can be used and changed via these objects.

Object dictionary The object dictionary of each network device allows for communication between the devices. Other devices find the objects with which they can communicate in this dictionary.




Figure 1.2: Device model with object dictionary

The object dictionary contains objects for describing the data types and executing the communication tasks and device functions under CANopen.

Object index Each object is addressed by means of a 16 bit index, which is represented as a four-digit hexadecimal number. The objects are arranged in groups in the object dictionary. The following table shows an overview of the object dictionary supported by Lexium MDrive products as per the CANopen definition.

Index range (hex)	Object group
1000h - 1FFFh	Communications profile
2000h - 5FFFh	Vendor specific objects
6000h - 9FFFh	Standardized device profiles

For a list of all CANopen objects see chapter 7 “Object dictionary”.

1.2.4 CANopen profiles

Standardized profiles

Standardized profiles describe objects that are used with different devices without additional configuration. The users and manufacturers organization CAN in Automation has standardized various profiles. These include:

- DS301 communication profile
- DSP402 device profile




Figure 1.3: CANopen reference model

DS301 communication profile

The DS301 communication profile is the interface between device profiles and CAN bus. It was specified in 1995 under the name DS301 and defines uniform standards for common data exchange between different device types under CANopen.

The objects of the communication profile in the device carry out the tasks of data exchange and parameter exchange with other network devices and initialize, control and monitor the device in the network.

DSP402 device profile

The DSP402 device profile describes standardized objects for positioning, monitoring and settings of drives. The tasks of the objects include:

- Device monitoring and status monitoring (Device Control)
- Standardized parameterization
- Changing, monitoring and execution of operating modes

Vendor-specific profiles

The basic functions of a device can be used with objects of standardized device profiles. Only vendor-specific device profiles offer the full range of functions. The objects with which the special functions of a device can be used under CANopen are defined in these vendor-specific device profiles.

2 Before you begin - safety information

2

The information provided in this manual supplements the product manual. Carefully read the product manual before using the product.

2.1 Qualification of personnel

Only appropriately trained persons who are familiar with and understand the contents of this manual and all other pertinent product documentation are authorized to work on and with this product. In addition, these persons must have received safety training to recognize and avoid hazards involved. These persons must have sufficient technical training, knowledge and experience and be able to foresee and detect potential hazards that may be caused by using the product, by changing the settings and by the mechanical, electrical and electronic equipment of the entire system in which the product is used.

All persons working on and with the product must be fully familiar with all applicable standards, directives, and accident prevention regulations when performing such work.

2.2 Intended use

This product is a motor with an integrated drive and intended for industrial use according to this manual.

The product may only be used in compliance with all applicable safety regulations and directives, the specified requirements and the technical data.

Prior to using the product, you must perform a risk assessment in view of the planned application. Based on the results, the appropriate safety measures must be implemented.

Since the product is used as a component in an entire system, you must ensure the safety of persons by means of the design of this entire system (for example, machine design).

Operate the product only with the specified cables and accessories. Use only genuine accessories and spare parts. The product must NEVER be operated in explosive atmospheres (hazardous locations, Ex areas).

Any use other than the use explicitly permitted is prohibited and can result in hazards.

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel.

2.3 Hazard categories

Safety instructions to the user are highlighted by safety alert symbols in the manual. In addition, labels with symbols and/or instructions are attached to the product that alert you to potential hazards.

Depending on the seriousness of the hazard, the safety instructions are divided into 4 hazard categories.

▲ DANGER

DANGER indicates an imminently hazardous situation, which, if not avoided, will result in death or serious injury.

▲ WARNING

WARNING indicates a potentially hazardous situation, which, if not avoided, **can result** in death, serious injury, or equipment damage.

▲ CAUTION

CAUTION indicates a potentially hazardous situation, which, if not avoided, **can result** in injury or equipment damage.

CAUTION

CAUTION used without the safety alert symbol, is used to address practices not related to personal injury (e.g. **can result** in equipment damage).

2.4 Basic information

▲ DANGER

UNINTENDED CONSEQUENCES OF EQUIPMENT OPERATION

When the system is started, the drives are usually out of the operator's view and cannot be visually monitored.

- Only start the system if there are no persons in the hazardous area.

Failure to follow these instructions will result in death or serious injury.

▲ WARNING

LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop, overtravel stop, power outage and restart.
- Separate or redundant control paths must be provided for critical functions.
- System control paths may include communication links. Consideration must be given to the implication of unanticipated transmission delays or failures of the link.
- Observe all accident prevention regulations and local safety guidelines. 1)
- Each implementation of the product must be individually and thoroughly tested for proper operation before being placed into service.

Failure to follow these instructions can result in death or serious injury.

1) For USA: Additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control" and to NEMA ICS 7.1 (latest edition), "Safety Standards for Construction and Guide for Selection, Installation and Operation of Adjustable-Speed Drive Systems".

2.5 Standards and terminology

Technical terms, terminology and the corresponding descriptions in this manual are intended to use the terms or definitions of the pertinent standards.

In the area of drive systems, this includes, but is not limited to, terms such as “safety function”, “safe state”, “fault”, “fault reset”, “failure”, “error”, “error message”, “warning”, “warning message”, etc.

Among others, these standards include:

- IEC 61800 series: “Adjustable speed electrical power drive systems”
- IEC 61158 series: “Industrial communication networks - Fieldbus specifications”
- IEC 61784 series: “Industrial communication networks - Profiles”
- IEC 61508 series: “Functional safety of electrical/electronic/programmable electronic safety-related systems”

3 Basics

3

3.1 Communication profile

CANopen manages communication between the network devices with object dictionaries and objects. A network device can use process data objects (PDO) and service data objects (SDO) to request the object data from the object dictionary of another device and, if permissible, write back modified values.

The following can be done by accessing the objects of the network devices

- Exchange parameter values
- Start motion functions of individual CAN bus devices
- Request status information

3.1.1 Object dictionary

Each CANopen device manages an object dictionary which contains the objects for communication.

Index, subindex

The objects are addressed in the object dictionary via a 16 bit index. One or more 8 bit subindex entries for each object specify individual data fields in the object. Index and subindex are shown in hexadecimal notation with a subscript “_h”.

Example

The following table shows index and subindex entries using the example of the object Homing Speeds (6098_h) for specifying the fast and slow speeds for homing functions.

Index	Subindex	Name	Meaning
6098 _h	00 _h	—	Number of data fields
	01 _h	Homing speed fast	High speed during homing
	02 _h	Homing speed slow	Low speed during homing

Table 3.1: Example index and subindex entries

Object descriptions in the manual

For CAN programming of a device, the objects of the following object groups are described in detail:

1xxx_h objects: Communication objects.

2xxx_h objects: Vendor-specific objects required to control the vendor specific functions of the device.

6xxx_h objects: standardized objects of the device profile.

Standardized objects Standardized objects allow you to use the same application program for different network devices of the same device type. This requires these objects to be contained in the object dictionary of the network devices. Standardized objects are defined in the DS301 communication profile and the DSP402 device profile.

3.1.2 Communication objects

Overview The communication objects are standardized with the DS301 CANopen communication profile. The objects can be classified into 4 groups according to their tasks.

Process data objects

T_PDO1 R_PDO1
T_PDO2 R_PDO2
T_PDO3 R_PDO3
T_PDO4 R_PDO4

Special objects

SYNC
EMCY

Communication objects

Service data objects

T_SDO
R_SDO

Network management

NMT Services
NMT Node guarding
NMT Heartbeat


T_ = Transmit
R_ = Receive

Figure 3.1: Communication objects

- PDOs (process data objects) for real-time transmission of process data
- SDOs (service data object) for read and write access to the object dictionary
- Objects for controlling CAN messages:
 1. SYNC object (synchronization object) for synchronization of network devices
 2. EMCY object (emergency object), for signaling errors of a device or its peripherals.
- Network management services:
 1. NMT services for initialization and network control (NMT: network management)
 2. NMT Node Guarding for monitoring the network devices
 3. NMT Heartbeat for monitoring the network devices

CAN message Data is exchanged via the CAN bus in the form of CAN messages. A CAN message transmits the communication object as well as numerous administration and control data.

CAN message



CANopen message (simplified)

Figure 3.2: CAN message and simplified CANopen message

CANopen message For work with CANopen objects and for data exchange, the CAN message can be represented in simplified form because most of the bits are used for error correction. These bits are automatically removed from the receive message by the data link layer of the OSI model, and added to a message before it is transmitted.

The two bit fields "Identifier" and "Data" form the simplified CANopen message. The "Identifier" corresponds to the "COB ID" and the "Data" field to the data frame (maximum length 8 bytes) of a CANopen message.

COB ID The COB ID (**C**ommunication **O**bject Identifier) has 2 tasks as far as controlling communication objects is concerned:

- Bus arbitration: Specification of transmission priorities
- Identification of communication objects
An 11 bit COB identifier as per the CAN 3.0A specification is defined for CAN communication; it comprises 2 parts
- Function code, 4 bits
- Node address (node ID), 7 bits.

COB ID




Figure 3.3: COB ID with function code and node address

COB IDs of the communication objects The following table shows the COB IDs of all communication objects with the factory settings. The column «Index of object parameters» shows the index of special objects with which the settings of the communication objects can be read or modified via an SDO.

Communications object	Function code	Node address, node ID [1...127]	COB ID decimal (hex)	Index of object parameters
NMT Start/Stop Service	0 0 0 0	0 0 0 0 0 0 0	0 (0 _h)	—
SYNC object	0 0 0 1	0 0 0 0 0 0 0	128 (80 _h)	1005 _h ...1007 _h
EMCY object	0 0 0 1	x x x x x x x x	128 (80 _h) + node ID	1014 _h , 1015 _h
T_PDO1	0 0 1 1	x x x x x x x x	384 (180 _h) + node ID	1800 _h
R_PDO1	0 1 0 0	x x x x x x x x	512 (200 _h) + node ID	1400 _h
T_PDO2	0 1 0 1	x x x x x x x x	640 (280 _h) + node ID	1801 _h
R_PDO2	0 1 1 0	x x x x x x x x	768 (300 _h) + node ID	1401 _h
T_PDO3	0 1 1 1	x x x x x x x x	896 (380 _h) + node ID	1802 _h
R_PDO3	1 0 0 0	x x x x x x x x	1024 (400 _h) + node ID	1402 _h
T_PDO4	1 0 0 1	x x x x x x x x	1152 (480 _h) + node ID	1803 _h
R_PDO4	1 0 1 0	x x x x x x x x	1280 (500 _h) + node ID	1403 _h
R_SDO	—	x x x x x x x x	1408 (580 _h) + node ID	—
R_SDO	—	x x x x x x x x	1536 (600 _h) + node ID	—
NMT error control	1 1 1 0	x x x x x x x x	1792 (700 _h) + node ID	—
LMT Services	1 1 1 1	1 1 0 0 1 0 x	2020 (7E4 _h), 2021 (7E5 _h)	—
NMT Identify Service	1 1 1 1	1 1 0 0 1 1 0	2022 (7E6 _h)	—
NMT Services	1 1 1 1	1 1 0 1 0 0 x	2025 (7E9 _h), 2026 (7EA _h)	—

Table 3.2: COB IDs of communication objects

Function code The function code classifies the communication objects. Since the bits of the function code in the COB ID are more significant, the function code also controls the transmission priorities: Objects with a lower function code are transmitted with higher priority. For example, an object with function code “1” is transmitted prior to an object with function code “3” in the case of simultaneous bus access.

Node address Each network device is configured before it can be operated on the network. The device is assigned a unique 7 bit node address (node ID) between 1 (01_h) and 127 (7F_h). The device address “0” is reserved for “broadcast transmissions” which are used to send messages to all reachable devices simultaneously.

Example Selection of a COB ID

For a device with the node address 5, the COB ID of the communication object T_PDO1 is:

$$384 + \text{node ID} = 384 (180_{\text{h}}) + 5 = 389 (185_{\text{h}}).$$

Data frame The data frame of the CANopen message can hold up to 8 bytes of data. In addition to the data frame for SDOs and PDOs, special frame types are specified in the CANopen profile:

- Error data frame
- Remote data frame for requesting a message

The data frames contain the respective communication objects.

3.1.3 Communication relationships

CANopen uses 3 relationships for communication between network devices:

- Master-slave relationship
- Client-server relationship
- Producer-consumer relationship

Master-slave relationship

A network master controls the message traffic. A slave only responds when it is addressed by the master.

The master-slave relationship is used with network management objects for a controlled network start and to monitor the connection of devices.




Figure 3.4 : Master – slave relationship

Messages can be interchanged with and without confirmation. If the master sends an unconfirmed CAN message, it can be received by a single slave or by all reachable slaves or by no slave.

To confirm the message, the master requests a message from a specific slave, which then responds with the desired data.

Client-server relationship

A client-server relationship is established between 2 devices. The «server» is the device whose object dictionary is used during data exchange. The «client» addresses and starts the exchange of messages and waits for a confirmation from the server.

A client-server relationship with SDOs is used to send configuration data and long messages.




Figure 3.5: Client – server relationship

The client addresses and sends a CAN message to a server. The server evaluates the message and sends the response data as an acknowledgement.

Producer-consumer relationship

The producer-consumer relationship is used for exchanging messages with process data, because this relationship enables fast data exchange without administration data.

A “Producer” sends data, a “Consumer” receives data.




Figure 3.6: Producer – consumer relationship

The producer sends a message that can be received by one or more network devices. The producer does not receive an acknowledgement to the effect that the message was received. The message transmission can be triggered by

- An internal event, for example, “target position reached”
- The synchronization object SYNC
- A request of a consumer

See Section 3.3 “Process data communication” for details on the function of the producer-consumer relationship and on requesting messages.

3.2 Service data communication

3.2.1 Overview

Service Data Objects (SDO: Service Data Object) can be used to access the entries of an object dictionary via index and subindex. The values of the objects can be read and, if permissible, also be changed.

Every network device has at least one server SDO to be able to respond to read and write requests from a different device. A client SDO is only required to request SDO messages from the object dictionary of a different device or to change them in the dictionary.

The T_SDO of an SDO client is used to send the request for data exchange; the R_SDO is used to receive. The data frame of an SDO consist of 8 bytes.

SDOs have a higher COB ID than PDOs; therefore, they are transmitted over the CAN bus at a lower priority.

3.2.2 SDO data exchange

A service data object (SDO) transmits parameter data between 2 devices. The data exchange conforms to the client-server relationship. The server is the device to whose object dictionary an SDO message refers.




Figure 3.7: SDO message exchange with request and response

Message types

Client-server communication is triggered by the client to send parameter values to the server or to get them from the server. In both cases, the client starts the communication with a request and receives a response from the server.

3.2.3 SDO message

Put simply, an SDO message consists of the COB ID and the SDO data frame, in which up to 4 bytes of data can be sent. Longer data sequences are distributed over multiple SDO messages with a special protocol.

The device transmits SDOs with a data length of up to 4 bytes. Greater amounts of data such as 8 byte values of the data type «Visible String 8» can be distributed over multiple SDOs and are transmitted successively in blocks of 7 bytes.

Example The following illustration shows an example of an SDO message.




Figure 3.8: SDO message example

COB ID and data frame R_SDO and T_SDO have different COB IDs.

The data frame of an SDO messages consists of:

- Command code (ccd) which contains the SDO message type and the data length of the transmitted value
- Index and subindex which point to the object whose data is transported with the SDO message
- Data of up to 4 bytes

Evaluation of numeric values

Index and data are transmitted left-aligned in Intel, or little endian format. If the SDO contains numerical values of more than 1 byte in length, the data must be rearranged byte-by-byte before and after a transmission.




Figure 3.9: Rearranging numeric values greater than 1 byte

3.2.4 Reading and writing data

Writing data The client starts a write request by sending index, subindex, data length and value. The server sends a confirmation indicating whether the data was correctly processed. The confirmation contains the same index and subindex, but no data.




Figure 3.10: Writing parameter values

Unused bytes in the data field are shown with a slash in the graphic. The content of these data fields is not defined.

ccd coding The table below shows the command code for writing parameter values. It depends on the message type and the transmitted data length.

Message type	Data length used				
	4 byte	3 byte	2 byte	1 byte	
Write request	23 _h	27 _h	2B _h	2F _h	Transmitting parameters
Write response	60 _h	60 _h	60 _h	60 _h	Confirmation
Error response	80 _h	80 _h	80 _h	80 _h	Error

Table 3.3: Command code for writing parameter values

Reading data The client starts a read request by transmitting the index and subindex that point to the object or part of the object whose value it wants to read.

The server confirms the request by sending the desired data. The SDO response contains the same index and subindex. The length of the response data is specified in the command code «ccd».




Figure 3.11: Reading a parameter value

The table below shows the command code transmitting a read value. It depends on the message type and the transmitted data length.

Message type	Data length used				
	4 byte	3 byte	2 byte	1 byte	
Read request	43 _h	47 _h	4B _h	4F _h	Request read value
Read response	40 _h	40 _h	40 _h	40 _h	Return read value
Error response	80 _h	80 _h	80 _h	80 _h	Error

Table 3.4: Command code for transmitting a read value

Error response If a message could not be evaluated, the server sends an error message. See section 7.4.3 “SDO error message ABORT” for details on the evaluation of the error message.




Figure 3.12: Response with error message (error response)

3.2.5 Reading data longer than 4 bytes

If values of more than 4 bytes are to be transmitted with an SDO message, the message must be divided into several frames. Each frame consists of 2 parts.

- Request by the SDO client,
- Confirmation by the SDO server.

The request by the SDO client contains the command code «ccd» with the toggle bit and a data segment. The confirmation frame also contains a toggle bit in the «ccd» segment. In the first frame, the toggle bit has the value «0», in the subsequent frames it toggles between 1 and 0.

Reading data The client starts a read request by transmitting the index and subindex that point to the object or the object value whose value it wants to read.

The server confirms the request by transmitting index, subindex, data length and the first 4 bytes of the requested data. The command code specifies that data of more than 4 bytes are transmitted. The command code of the read response from the server to the first message is 41h.




Figure 3.13: Transmitting the first message

In the next frames, the remaining data is requested and transmitted in packets of 7 bytes from the server.

ccd coding The table below shows the command code for transmitting a read value. It depends on the message type, the value of the toggle bit, the transmitted data length and the value of the bit that indicates the end of the entire SDO message.

Message type	Data length used							
	7 byte	6 byte	5 byte	4 byte	3 byte	2 byte	1 byte	
Read request Toggle Bit = 0		60 _h	60 _h		60 _h	60 _h	60 _h	Confirmation with Toggle Bit = 0
Read request Toggle Bit = 1	70 _h	70 _h	70 _h	70 _h	70 _h	70 _h	70 _h	Confirmation with Toggle Bit = 1
Read response Toggle Bit = 0	00 _h	—	—	—	—	—	—	Send parameter with Toggle Bit = 0
Read response Toggle Bit = 1	10 _h	—	—	—	—	—	—	Send parameter with Toggle Bit = 1
Read response last message Toggle Bit = 0	01 _h	03 _h	05 _h	07 _h	09 _h	0B _h	0D _h	Transmit parameter with last message and Toggle Bit = 0
Read response last message Toggle Bit = 1	11 _h	13 _h	15 _h	17 _h	19 _h	1B _h	1D _h	Transmit parameter with last message and Toggle Bit = 1
Error response	80 _h	80 _h	80 _h	80 _h	80 _h	80 _h	80 _h	Error

Table 3.5: Command code data lengths > 4 bytes

Refer to the DS301 of the CiA for additional information on this procedure.

3.3 Process data communication

3.3.1 Overview

Process data objects (PDO: Process Data Object) are used for realtime data exchange of process data such as actual and reference values or the operating state of the device. Transmission is very fast because the data is sent without additional administration data and data transmission acknowledgment from the recipient is not required.

The flexible data length of a PDO message also increases the data throughput. A PDO message can transmit up to 8 bytes of data. If only 2 bytes are assigned, only 2 data bytes are sent. The length of a PDO message and the assignment of the data fields are specified by PDO mapping. See section 3.3.4 «PDO mapping» for additional information.

PDO messages can be exchanged between devices that generate or process process data.




Figure 3:14: PDO data exchange

Data exchange with PDOs follows to the producer-consumer relationship and can be triggered in 3 ways:

- Synchronized
- Event-driven, asynchronous

The SYNC object controls synchronized data processing. Synchronous PDO messages are transmitted immediately like the standard PDO messages, but are only evaluated on the next SYNC. For example, several drives can be started simultaneously via synchronized data exchange.

The device immediately evaluates PDO messages that are called on request or in an event-driven way.

The transmission type can be specified separately for each PDO with sub-index 02_h (transmission type) of the PDO communication parameter. The objects are listed in Table 3.5.

3.3.3 PDO message

T_PDO, R_PDO One PDO each is available for sending and receiving a PDO message:

- T_PDO to transmit the PDO message (T: Transmit),
- R_PDO to receive PDO messages (R: Receive).



The following settings for PDOs correspond to the defaults read and set via objects of the communication profile.

The device uses 6 PDOs, 3 receive PDOs and 3 transmit PDOs. By default, the PDOs are evaluated or transmitted in an event-driven way.

PDO settings The PDO settings can be read and changed with 8 communication objects:

Object	Meaning
1st receive PDO parameter (1400 _h)	Settings for R_PDO1
2nd receive PDO parameter (1401 _h)	Settings for R_PDO2
3rd receive PDO parameter (1402 _h)	Settings for R_PDO3
4th receive PDO parameter (1403 _h)	Settings for R_PDO4
1st transmit PDO parameter (1800 _h)	Settings for T_PDO1
2nd transmit PDO parameter (1801 _h)	Settings for T_PDO2
3rd transmit PDO parameter (1802 _h)	Settings for T_PDO3
4th transmit PDO parameter (1803 _h)	Settings for T_PDO4

Table 3.6: Communication objects for PDO

Activating PDOs With the default PDO settings, R_PDO1 and T_PDO1 are activated. The other PDOs must be activated first. A PDO is activated with bit 31 (valid bit) in subindex 01h of the respective communication object:




Figure 3.15: Activating PDOs via subindex 01_h, bit 31

Example **Setting for R_PDO3 in object 1402_h**

- Subindex 01_h = 8000 04xx_h: R_PDO3 not activated
 - Subindex 01_h = 0000 04xx_h: R_PDO3 activated.
- Values for “x” in the example depend on the COB ID setting.

PDO time intervals

The time intervals «inhibit time» and «event timer» can be set for each transmit PDO.

- The time interval «inhibit time» can be used to reduce the CAN bus load, which can be the result of continuous transmission of T_PDOs. If an inhibit time not equal to zero is entered, a transmitted PDO will only be re-transmitted after the inhibit time has elapsed. The time is set with subindex 03h.
- The time interval «event timer» cyclically triggers an event message. After the time intervals has elapsed, the device transmits the event controlled T_PDO. The time is set with subindex 05h.

Receive PDOs

The objects for R_PDO1, R_PDO2, R_PDO3 and R_PDO4 are preset. They may be re-mapped to suit the end-user application.




Figure 3.16: Receive PDOs

R_PDO1 R_PDO1 contains the control word, object `controlword` (6040_h), of the state machine which can be used to set the operating state of the device.

R_PDO1 is evaluated asynchronously, i.e. it is event-driven. R_PDO1 is preset.

R_PDO2 With R_PDO2, the control word and the target position of a motion command, object `target position` (607A_h), are received for a movement in the operating mode “Profile Position”.

R_PDO2 is evaluated asynchronously, i.e. it is event-driven. R_PDO2 is preset.

For details on the SYNC object see section 3.4 “Synchronization”.

R_PDO3 R_PDO3 contains the control word and the target velocity, object `Target velocity` (60FF_h), for the operating mode “Profile Velocity”.

R_PDO3 is evaluated asynchronously, i.e. it is event-driven. R_PDO3 is preset.

R_PDO4 R_PDO4 contains the control word and the target torque, object `Target torque` (6071_h), for the operating mode “Profile Torque” (closed loop LMD products only).

R_PDO4 is evaluated asynchronously, i.e. it is event-driven. R_PDO4 is preset.

Transmit PDOs The objects for T_PDO1, T_PDO2 and T_PDO3 can be changed by means of PDO mapping.




Figure 3.17: Transmit PDOs

- T_PDO1* T_PDO1 contains the status word, object `statusword` (6041_h), of the state machine.
- T_PDO1 is transmitted asynchronously and in an event-driven way whenever the status information changes.
- T_PDO2* T_PDO2 contains the status word and the actual position of the motor, object `Position actual value` (6064_h), to monitor movements in the operating mode “Profile Position”.
- T_PDO2 is transmitted after receipt of a SYNC object and in an eventdriven way.
- T_PDO3* T_PDO3 contains the status word and the actual velocity, object `Velocity actual value` (606C_h), for monitoring the velocity profile in the operating mode “Profile Velocity”.
- T_PDO3 is transmitted asynchronously and in an event-driven way whenever the status information changes.
- T_PDO4* T_PDO4 contains the status word, object `statusword` (6041_h), of the state machine.
- T_PDO4 is transmitted asynchronously and in an event-driven way whenever the status information changes.

3.3.4 PDO mapping

Up to 8 bytes of data from different areas of the object dictionary can be transmitted with a PDO message. Mapping of data to a PDO message is referred to as PDO mapping.

The diagram below shows the data exchange between PDOs and object dictionary on the basis of two examples of objects in T_PDO3 and R_PDO3 of the PDOs.




Figure 3.18:PDO mapping

Dynamic PDO mapping

The device uses dynamic PDO mapping. Dynamic PDO mapping means that objects can be mapped to the corresponding PDO using adjustable settings.

The settings for PDO mapping are defined in an assigned communication object for each PDO.

Object	PDO mapping for	Type
1st receive PDO mapping (1600 _h)	R_PDO1	Dynamic
2nd receive PDO mapping (1601 _h)	R_PDO2	Dynamic
3rd receive PDO mapping (1602 _h)	R_PDO3	Dynamic
4th receive PDO mapping (1603 _h)	R_PDO4	Dynamic
1st transmit PDO mapping (1A00 _h)	T_PDO1	Dynamic
2nd transmit PDO mapping (1A01 _h)	T_PDO2	Dynamic
3rd transmit PDO mapping (1A02 _h)	T_PDO3	Dynamic
4th transmit PDO mapping (1A03 _h)	T_PDO4	Dynamic

Table 3.7: Dynamic PDO mapping parameters

Structure of the entries Up to 8 bytes of 8 different objects can be mapped in a PDO. Each communication object for setting the PDO mapping provides 4 subindex entries. A subindex entry contains 3 pieces of information on the object: the index, the subindex and the number of bits that the object uses in the PDO.




Figure 3.19: Structure of entries for PDO mapping

Subindex 00h of the communication object contains the number of valid subindex entries.

Object length	Bit value
08 _h	8 bits
10 _h	16 bits
20 _h	30 bits

Table 3.8: Subindex object length entries

PDO mapping objects

Index	Subindex	Object	PDO	Data type	Parameter name
2009 _h	1	Read value of output fault	T_PDO	UINT8	Out_Fault
2010 _h	1	Read value of analog input	T_PDO	UINT16	Analog_In_Reading
2014 _h	1	Read Aux voltage level	T_PDO	UINT16	AuxPower_Voltage
2015 _h		Read +V level	T_PDO	UINT16	Vin_Voltage
2018 _h	1	Read internal temperature	T_PDO	INT8	Temperature_Reading
2019 _h	1	Read bridge temperature	T_PDO	UINT16	TempC_Bridge_Reading
2033 _h	4	Read captured position	T_PDO	INT32	CaptureInPositn_user
2741 _h	0	Read hybrid status byte	T_PDO	UINT8	HybridStatusByte

Index	Subindex	Object	PDO	Data type	Parameter name
603F _h	0	Read error code	T_PDO	UINT16	ErrorCode
6040 _h	0	Controlword	R_PDO	UINT16	Controlword
6041 _h	0	Statusword	T_PDO	UINT16	Statusword
6060 _h	0	Modes of operation	R_PDO	INT8	Modes_of_operation
6061 _h	0	Read mode of operation	T_PDO	INT8	Modes_of_operation_display
6062 _h	0	Read position value	T_PDO	INT32	Position_demand_value_user
6063 _h	0	Position actual value	T_PDO	INT32	Position_actual_value_inc
6064 _h	0	Position actual value	T_PDO	INT32	Position_actual_value
606C _h	0	Velocity actual value	T_PDO	INT32	Velocity_actual_value
6071 _h	0	Target torque	R_PDO	INT16	Target_torque
607A _h	0	Target position	R_PDO	INT32	Target_position
607E _h	0	Polarity	R_PDO	UINT8	Polarity
6081 _h	0	Profile velocity	R_PDO	UINT32	Profile_velocity
6082 _h	0	End velocity	R_PDO	UINT32	End_velocity
6083 _h	0	Profile acceleration	R_PDO	UINT32	Profile_acceleration
6084 _h	0	Profile deceleration	R_PDO	UINT32	Profile_deceleration
6086 _h	0	Motion profile type	R_PDO	INT16	Motion_profile_type
60FD _h	0	Digital inputs	T_PDO	UINT32	Digital_inputs
60FE _h	1	Digital outputs	R_PDO	UINT32	Digital_outputs
60FF _h	0	Target velocity	R_PDO	INT32	Target_velocity

Table 3.9: Supported PDO mapping objects

3.4 Synchronization

The synchronization object SYNC controls the synchronous exchange of messages between network devices for purposes such as the simultaneous start of multiple drives.

The data exchange conforms to the producer-consumer relationship. The SYNC object is transmitted to all reachable devices by a network device and can be evaluated by the devices that support synchronous PDOs.




Figure 3.20: SYNC message

Time values for synchronization

Two time values define the behavior of synchronous data transmission:

- The cycle time specifies the time intervals between 2 SYNC messages. It is set with the object *Communication cycle period* (1006h).
- The synchronous time window specifies the time span during which the synchronous PDO messages must be received and transmitted. The time window is defined with the object *Synchronous window length* (1007h).




Figure 3.21: Synchronization times

Synchronous data transmission

From the perspective of a SYNC recipient, in one time window the status data is transmitted first in a T_PDO, then new control data is received via an R_PDO. However, the control data is only processed when the next SYNC message is received. The SYNC object itself does not transmit data.

Cyclic and acyclic data transmission Synchronous exchange of messages can be cyclic or acyclic.




Figure 3.22: Cyclic and acyclic transmission

In the case of cyclic transmission, PDO messages are exchanged continuously in a specified cycle, for example with each SYNC message.

If a synchronous PDO message is transmitted acyclically, it can be transmitted or received at any time; however, it will not be valid until the next SYNC message.

Cyclic or acyclic behavior of a PDO is specified in the subindex transmission type (02h) of the corresponding PDO parameter, for example, in the object 1st receive PDO parameter (1400h:02h) for R_PDO1.

COB ID, SYNC object

For fast transmission, the SYNC object is transmitted unconfirmed and with high priority.

The COB ID of the SYNC object is set to the value 128 (80h) by default. The value can be changed after initialization of the network with the object COB-ID SYNC Message (1005h) .

“Start” PDO

With the default settings of the PDOs, R_PDO1 ... R_PDO4 and T_PDO1 ... T_PDO4 are received and transmitted asynchronously.

T_PDO2 ... T_PDO3 are transmitted additionally after the event timer has elapsed. The synchronization allows an operating mode to be started simultaneously on multiple devices so that, for example, the feed of a portal drive with several motors can be synchronized.

3.5 Emergency service

The Emergency Service signals internal device errors via the CAN bus. The error message is transmitted to the network devices with an EMCY object according to the Consumer-Producer relationship.




Figure 3.23: Error message via EMCY objects

Boot-up message

The communication profile DS301, version 3.0, defines an additional task for the EMCY object: sending a boot-up message. A boot-up message informs the network devices that the device that transmitted the message is ready for operation in the CAN network.

The boot-up message is transmitted with the COB ID 700h + node ID and one data byte (00h).

3.5.1 Error evaluation and handling

EMCY message If an internal device error occurs, the device switches to the operating state 9 Fault as per the CANopen state machine. At the same time, it transmits an EMCY message with error register and error code.




Figure 3.24: EMCY message

Bytes 0, 1 - Error code, value is also saved in the object `Error code` (603Fh)

Byte 2 - Error register, value is also saved in the object `Error register` (1001h)

Bytes 3, 4 - Reserved

Byte 5 - PDO: Number of the PDO

Bytes 6, 7 - Vendor-specific error code

COB ID The COB ID for each device on the network supporting an EMCY object is determined on the basis of the node address:

COB ID = Function code EMCY object (80h) + node ID

The function code of the COB ID can be changed with the object `COBID emergency (1014h)` .

Error register and error code The error register contains bit-coded information on the error. Bit 0 remains set as long as an error is active. The remaining bits identify the error type. The exact cause of error can be determined on the basis of the error code. The error code is transmitted in Intel format as a 2 byte value; the bytes must be reversed for evaluation.

See chapter 7 «Diagnostics and troubleshooting» for a list of the error messages and error responses by the device as well as remedies.

Error memory The device saves the error register in the object `Error register (1001h)` and the last error that occurred in the object `Error code (603Fh)` .

3.6 Network management services

Network management (NMT) is part of the CANopen communication profile; it is used to initialize the network and the network devices and to start, stop and monitor the network devices during operation on the network.

NMT services are executed in a master-slave relationship. The NMT master addresses individual NMT slaves via their node address. A message with node address «0» is broadcast to all reachable NMT slaves simultaneously.




Figure 3.25: NMT services via the master-slave relationship

Lexium MDrive and Lexium MDrive devices can only take on the function of an NMT slave.

NMT services NMT services can be divided into 2 groups:

- Services for device control, to initialize devices for CANopen communication and to control the behavior of devices during operation on the network
- Services:for connection monitoring

3.6.1 NMT services for device control

NMT state machine The NMT state machine describes the initialization and states of an NMT slave during operation on the network.




Figure 3.26: NMT state machine and available communication objects

To the right, the graphic shows the communication objects that can be used in the specific network state.

Initialization

An NMT slave automatically runs through an initialization phase after the supply voltage is switched on (power on) to prepare it for CAN bus operation. On completion of the initialization, the slave switches to the operating state “Pre Operational” and sends a boot-up message. From now on, an NMT master can control the operational behavior of an NMT slave on the network via 5 NMT services, represented in Figure 3.26 by the letters A to E.

NMT service	Transition	Meaning
Start remote node (Start network node)	A	Transition to operating state “Operational” Start normal operation on the network
Stop remote node (Stop network node)	B	Transition to operating state “Stopped” Stops communication of the network device on the network. If connection monitoring is active, it remains on. If the power stage is enabled (operating state “Operation Enabled” or “Quick Stop”), an error of error class 2 is triggered. The motor is stopped and the power stage disabled.
Enter Pre-Operational (Transition to “Pre-Operational”)	C	Transition to operating state “Pre-Operational” The communication objects except for PDOs can be used. The operating state “Pre-Operational” can be used for configuration via SDOs: <ul style="list-style-type: none"> - PDO mapping - Start of synchronization - Start of connection monitoring
Reset node (Reset node)	D	Transition to operating state “Reset application” Load stored data of the device profiles and automatically switch via operating state “Reset communication” to “Pre-Operational”.
Reset communication (Reset communication data)	E	Transition to operating state “Reset communication” Load stored data of the communication profile and automatically transition to operating state “Pre-Operational”. If the power stage is enabled (operating state “Operation Enabled” or “Quick Stop”), an error of error class 2 is triggered. The motor is stopped and the power stage disabled.

Table 3.10: NMT state machine transitions

Persistent data memory When the supply voltage is switched on (power on), the device loads the saved object data from the non-volatile EEPROM for persistent data to the RAM.

NMT message The NMT services for device control are transmitted as unconfirmed messages with the COB ID = 0 . By default, they have the highest priority on the CAN bus.

The data frame of the NMT device service consists of 2 bytes.




Figure 3.27: NMT message

The first byte, the “Command specifier”, indicates the NMT service used

Command specifier	NMT service	Transition
1 (01 _h)	Start remote node	A
2 (02 _h)	Stop remote node	B
128 (80 _h)	Enter pre-operational	C
129 (81 _h)	Reset node	D
130 (82 _h)	Reset communication	E

Table 3.10: NMT command specifiers.

The second byte addresses the recipient of an NMT message with a node address between 1 and 127 (7F_h). A message with node address “0” is broadcast to all reachable NMT slaves.

3.6.2 NMT services for connection monitoring

Connection monitoring monitors the communication status of network devices.

3 NMT services for connection monitoring are available:

- «Node guarding» for monitoring the connection of an NMT slave
- «Life guarding» for monitoring the connection of an NMT master
- «Heartbeat» for unconfirmed connection messages from network devices.

3.6.2.1 Node guarding / Life guarding

COB ID The communication object `NMT error control (700h+node-Id)` is used for connection monitoring. The COB ID for each NMT slave is determined on the basis of the node address:

$\text{COB ID} = \text{function code NMT error control (700h)} + \text{node-Id}.$

Structure of the NMT message

After a request from the NMT master, the NMT slave responds with one data byte.




Figure 3.28: Acknowledgement of the NMT slave

Bits 0 to 6 identify the NMT state of the slave:

- 4 (04h): "Stopped"
- 5 (05h): "Operational"
- 127 (7Fh): "Pre-Operational"

After each "guard time" interval, bit 7 switches toggles between "0" and "1", so the NMT master can detect and ignore a second response within the "guard time" interval. The first request when connection monitoring is started begins with bit 7 = 0.

Connection monitoring must not be active during the initialization phase of a device. The status of bit 7 is reset as soon as the device runs through the NMT state "Reset communication".

Connection monitoring remains active in the NMT state "Stopped".

Configuration

Node Guarding/Life Guarding is configured via:

- Guard time (100Ch)
- Life time factor (100Dh)

Connection error The NMT master signals a connection error to the master program if:

- the slave does not respond within the «guard time» period
- the NMT state of the slave has changed without a request by the NMT master.

Figure 3.29 shows an error message after the end of the third cycle because of a missing response from an NMT slave.




Figure 3.29: «Node Guarding» and «Life Guarding» with time intervals

3.6.2.2 Heartbeat

The optional Heartbeat protocol replaces the node guarding/life guarding protocol. It is recommended for new device versions.

A heartbeat producer transmits a heartbeat message cyclically at the frequency defined in the object `Producer heartbeat time (1017h)`. One or several consumers can receive this message. `Producer heartbeat time (1016h) = 0` deactivates heartbeat monitoring.

The relationship between producer and consumer can be configured with objects. If a consumer does not receive a signal within the period of time set with `Consumer heartbeat time (1016h)`, it generates an error message (heartbeat event). `Consumer heartbeat time (1016h) = 0` deactivates monitoring by a consumer.




Figure 3.30: «Heartbeat» monitoring

Data byte for NMT state evaluation of the “Heartbeat” producer:

- 0 (00_h): “Boot-Up”
- 4 (04_h): “Stopped”
- 5 (05_h): “Operational”
- 127 (7F_h): “Pre-Operational”

Time intervals

The time intervals are set in increments of 1 ms steps; the values for the consumer must not be less than the values for the producer. Whenever the “Heartbeat” message is received, the time interval of the producer is restarted.

Start of monitoring

“Heartbeat” monitoring starts as soon as the time interval of the producer is greater than zero. If “Heartbeat” monitoring is already active during the NMT state transition to “Pre-Operational”, “Heartbeat” monitoring starts with sending of the boot-up message. The boot-up message is a Heartbeat message with one data byte 00_h.

Devices can monitor each other via “Heartbeat” messages. They assume the function of consumer and producer at the same time.

Page intentionally left blank

4 Installation

4

▲ WARNING

SIGNAL AND DEVICE INTERFERENCE

Signal interference can cause unexpected responses of device.

- Install the wiring in accordance with the EMC requirements.
- Verify compliance with the EMC requirements.

Failure to follow these instructions can result in death, serious injury or equipment damage.

For information on installation of the device and connecting the device to the fieldbus see the product hardware manual.

Page intentionally left blank

5 Commissioning

5

▲ WARNING

LOSS OF CONTROL

The product is unable to detect an interruption of the network link if

- Verify that connection monitoring is on.
- The shorter the time for monitoring, the faster the detection of the interruption.

Failure to follow these instructions can result in death, serious injury or equipment damage.

▲ WARNING

UNINTENDED OPERATION

The product is unable to detect an interruption of the network link if

- Do not write values to reserved parameters.
- Do not write values to parameters unless you fully understand the function.
- Run initial tests without coupled loads.
- Verify that the system is free and ready for the movement before changing parameters.
- Verify the use of the word sequence with fieldbus communication.
- Do not establish a fieldbus connection unless you have fully understood the communication principles.

Failure to follow these instructions can result in death, serious injury or equipment damage.

5.1 Commissioning the device

For installation in the network, the device must first be properly installed (mechanically and electrically) and commissioned. Commission the device as per product manual.

Two conditions must be fulfilled in order for a CANopen device to operate on a network:

- It must have a unique Node ID
- It must have the same communication Baud rate as all other devices on the network

5.2 Address and baud rate

Up to 64 devices can be addressed in one CAN bus network branch and up to 127 devices in the extended network. Each device is identified by a unique address or Node ID. The default Node ID for a Lexium MDrive is 41_h.



The default baud rate is 1 MBaud (1000 kbps).

Each device must be assigned a unique node address, i.e. any given node address may be assigned only once in the network.

The baud rate MUS match the baud rate setting of the network into which the device is being installed.

5.3 Commissioning via supplied utility

The NODE ID and BAUD rate may be configured using the supplied utility: The CANOpen Configuration Utility, which is part of the Lexium MDrive Software Suite.

Instructions for installing and using this tool to commission your Lexium MDrive CANopen device are found in the Lexium MDrive Software Suite Manual.

Both the software and user manual are available for download at:

www.motion.shneider-electric.com

5.4 Commissioning via Layer Setting Services (LSS)

The device may be commissioned using CAN Layer Setting Services (LSS). Reference CiA DSP305.

The scope of LSS is to allow the Node ID and communication baud rate to be read or written through the network.

The Node ID and baud rate must be set using LSS commands. It is recommended that the parameters be set prior to the installation of the device into a network.

LSS messages are 8 bytes in length.




Figure 5.1: LSS message structure

The LSS message consists of a COB IDs specific toe the LSS master and LSS slave.

The command specifier identifies the action to be taken.

COB ID LSS commands use two specific COB IDs to request and respond to LSS commands:

- 07E5_h – COB ID of the LSS slave device
- 07E4_h – COB ID of the LSS master device to which message

responses are sent


- Switch Modes
- There are two methods of initiating communications with the device to be commissioned:
- Switch mode global: can set all connected devices into configuration mode. Can be used to set the baud rate of multiple connected devices, can only be used to set the Node ID if one device is connected.
 - Switch mode selective: can be used to set the parameters of a single device in the network using vendor specific objects such as the serial number to communicate directly to the device.

The switch mode commands are used to set the device into either and operational mode, or in configuration mode. In order to make changes to the parameters it must be in configuration mode.

5.5 Commissioning via switch mode global


Procedure The following procedure will step through configuring the Node ID and Baud rate parameters from the perspective of a single device connected to the LSS master.

- 1) Transmit the command to the device setting it into switch mode global — configuration mode:



This will place the device in configuration mode. Because this is an unacknowledged LSS service there will be no response.

- 2) Set the new Node ID (42h used as an example).





- 3) Set the desired baud rate using the table below as a reference, for example purposes a bitrate of 50 kbps will be used):



Table index	Baud rate (kbps)
00h	1000 (default)

01 _h	800*
02 _h	500
03 _h	250
04 _h	125
05 _h	100
06 _h	50
07 _h	20
08 _h	10


*Not available if using MD-CC500-000 USB to CANopen converter cable.



- 4) Save the changed parameters using the “Store configuration” service (17_h)



- 5) Change the mode from configuration to operational



- 6) The new Node ID is now active. To make the new bit rate active, cycle power to the device.
- 7) The device is now commissioned and ready to be placed in a network having a Node ID of 42_h and a bitrate of 50 kbps.

5.6 Commissioning via switch mode selective

Using switch mode selective it is possible to isolate a single unit installed on a CANopen network and commission it alone by sending out a four-part signature.

The signature consists of


- VendorID = 0800005A_h
- Product code = 00
- Revision number = 507_h
- Serial number

The first three parameters are identical throughout the product line. The serial number may be retrieved from the label on the device or from the Indexes 1018_h4 or 5002_h1.

Using only the numeric portion of the serial, convert it to a 4 byte hex number, for example:

341070398 = 1454523E

Procedure 8) Send the four parameters to place the desired device in configuration mode.



9) Perform steps 2 – 7 of the Switch Mode Global procedure to commission the device.

6 Operation

6

▲ WARNING

UNINTENDED OPERATION

The product is unable to detect an interruption of the network link if

- Do not write values to reserved parameters.
- Do not write values to parameters unless you fully understand the function.
- Run initial tests without coupled loads.
- Verify that the system is free and ready for the movement before changing parameters.
- Verify the use of the word sequence with fieldbus communication.
- Do not establish a fieldbus connection unless you have fully understood the communication principles.

Failure to follow these instructions can result in death, serious injury or equipment damage.

The section “Operation” describes the basic operating states, operating modes and functions of the device.

6.1 Operating states

6.1.1 State diagram

After switching on and when an operating mode is started, the product goes through a number of operating states.

The state diagram (state machine) shows the relationships between the operating states and the state transitions.

The operating states are monitored and influenced by internal monitoring functions and system functions such as temperature monitoring or current monitoring.

Graphical representation The state diagram is represented as a flowchart




Figure 6.1: State diagram

Operating states

Operating state		Description
1	Start	Controller supply voltage switched on Electronics are initialized
2	Not Ready To Switch On	The power stage is not ready to switch on
3	Switch On Disable	Impossible to enable the power stage
4	Ready To Switch On	The power stage is ready to switch on.
5	Switched On	Power stage is switched on
6	Operation Enabled	Power stage is enabled Selected operating mode is active
7	Quick Stop Active	“Quick Stop” is being executed
8	Fault Reaction Active	Error response is active
9	Fault	Error response terminated Power stage is disabled

Table 6.1: Operating states

Error class

The product triggers an error response if an error occurs. Depending upon the severity of the error, the device responds in accordance with one of the following error classes:

Error Class	Response	Description
0	Warning	A monitoring function has detected a problem. No interruption of the movement.
1	“Quick Stop”	Motor stops with “Quick Stop”, the power stage remains enabled.
2	Quick Stop” with switch-off	Motor stops with “Quick Stop”, the power stage is disabled after standstill has been achieved.
3	Fatal error	The power stage is immediately disabled without stopping the motor first.
4	Uncontrolled operation	The power stage is immediately disabled without stopping the motor first. The error can only be reset by switching off the product.

Table 6.2: Error class

Error response

The state transition T13 (error class 2, 3 or 4) initiates an error response as soon as an internal occurrence signals an error to which the device must react.

Error Class	State from -> to	Description
2	x -> 8	Stop movement with “Quick Stop” Power stage is disabled
3, 4 or Safety function STO	x -> 8 -> 9	Power stage is disabled immediately, even if “Quick Stop” is still active.


An error can be triggered by a temperature sensor, for example. The product cancels the running movement and performs an error response, for example stopping with «Quick Stop» or disabling the power stage. Subsequently, the operating state changes to 9 Fault. To exit the 9 Fault operating state, the cause of the error must be remedied and a Fault Reset must be executed.

Resetting an error message A “Fault Reset” resets an error message.

6.2 Control and status

6.2.1 Controlling the state machine (control word 6040_h)

Control word 6040_h is a mandatory index which sets the operating states and modes of the state machine.



Command	Bits of the control word					Transitions
	Bit 7	Bit 3	Bit 2	Bit 1	Bit 0	
Shutdown	0	X	1	1	0	2, 6, 8
Switch on	0	0	1	1	1	3
Switch on + enable operation	0	1	1	1	1	3 + 4
Disable voltage	0	X	X	0	X	7, 9, 10, 12
Quick stop	0	X	0	1	X	7, 10, 11
Disable operation	0	0	1	1	1	5
Enable operation	0	1	1	1	1	4, 16
Fault reset	0 → 1	X	X	X	X	15

Op mode	Bits of the control word			
	Bit 8	Bit 6	Bit 5	Bit 4
Profile position	Halt	Abs/rel	Change set	New setpoint
Profile velocity	Halt	Reserved	Reserved	Reserved
Homing	Halt	Homing start	Reserved	Reserved

Table 6.3: Control word value range

Object description

Index	6040 _h
Name	Control word
Object code	VAR
Data type	Unsigned16
Category	Mandatory

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	Yes
Value range	See table 6.3
Default value	Device and operation mode specific

6.2.2 Indication of the operating state (status word 6041:0h)

The status word 6041:0_h provides information on the operating state of the device and the processing status of the operating mode

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
mfg specific		op mode specific		Int limit active	target reached	remote	mfg specific	warn	status bits	voltage enabled		status bits			
MSB											LSB				

Status bits Bit 6: Switch on disabled
 Bit 5: Quick stop
 Bit 3: Fault
 Bit 2: Operation enabled
 Bit 1: Switch on
 Bit 0: Ready to switch on

Status	Bits of the status word					
	Bit 6	Bit 5	Bit 3	Bit 2	Bit 1	Bit 0
Not Ready To Switch On	0	X	0	0	0	0
Switch On Disabled	1	X	0	0	0	0
Ready To Switch On	0	1	0	0	0	1
Switched On	0	1	0	0	1	1
Operation Enabled	0	1	0	1	1	1
Quick Stop Active	0	0	0	1	1	1
Fault Reaction Active	0	X	1	1	1	1
Fault	0	X	1	0	0	0

Table 6.4: Status word status bit states

Bit 4: Voltage Enabled Bit 4=1 indicates whether the DC bus voltage is correct. If the voltage is missing or is too low, the device does not transition from operating state 3 to operating state 4.

Bit 5: Quick Stop Active When reset, this bit indicates that the drive is reacting on a quick stop request. Bits 0, 1 and 2 of the `statusword` must be set to 1 to indicate that the drive is capable to regenerate. The setting of the other bits indicates the status of the drive (e.g. the drive is performing a quick stop as result of a reaction to a non-fatal fault. The fault bit is set as well as bits 0, 1 and 2).

Bit 7: Warning A drive warning is present if bit 7 is set. The cause means no error but a state that has to be mentioned, e.g. temperature limit, job refused. The status of the drive does not change. The cause of this warning may be found by reading the fault code parameter. The bit is set and reset by the device.

Bit 8: Manufacturer Specific This bit may be used by a drive manufacturer to implement any manufacturer specific functionality. Not used by Lexium MDrive products.

Bit 9: Remote If bit 9 is set, then parameters may be modified via the CAN-network, and the drive executes the content of a command message. If the bit remote is reset, then the drive is in local mode and will not execute the command message. The drive may transmit messages containing valid actual values like a `position_actual_value`, depending on the actual drive configuration. The drive will accept accesses via service data objects (SDOs) in local mode.

Bit 10: Target Reached If bit 10 is set by the drive, then a setpoint has been reached (torque, speed or position depending on the `modes_of_operation`). The change of a target value by software alters this bit. If `quickstop_option_code` is 5, 6, 7 or 8, this bit must be set, when the quick stop operation is finished and the drive is halted. If Halt occurred and the drive has halted then this bit is set too.

Bit 11: Internal Limit Active This bit set by the drive indicates, that an internal limitation is active (e.g. `position_range_limit`).

Bits 12-13: Operation Mode Specific

Op mode	Bits of the control word	
	Bit 13	Bit 12
Profile position	Following error	Set point acknowledge
Profile velocity	Max slippage error	Speed
Homing	Homing error	Homing attained

Table 6.5: Operation mode status

Bit 14-15: Unused

6.3 Option code objects

6.3.1 Abort connection (6007_h)

This object shall indicate what action shall be performed when one of the following events occurs: bus-off, heartbeat, life guarding, NMT stopped state entered, reset application, and reset communication

Object description

Index	6007 _h
Name	Abort connection
Object code	VAR
Data type	Integer16
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	Yes
Value range	0 to 3
Default value	0

Value	Meaning
0	No action
1	Fault signal
2	Disable voltage command
3	Quick stop command

Table 6.6: Abort Connection Option Code

6.3.2 Error code (603F_h)

This object shall provide the error code of the last error occurred in the drive device. This object provides the same information as the lower 16-bit of sub-index 01h of the pre-defined error field (1003_h).

Object description

Index	603F _h
Name	Error code
Object code	VAR
Data type	Unsigned16
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	Yes
Value range	Unsigned16
Default value	0

6.3.3 Quick stop (605A_h)

This object shall indicate what action is performed when the quick stop function is executed. The slow down ramp is the deceleration value of the used mode of operations.

<i>Object description</i>	Index	605A _h
	Name	Quick stop
	Object code	VAR
	Data type	Integer16
	Category	Optional
<i>Entry description</i>	Sub-index	00 _h
	Access	rw
	PDO mapping	No
	Value range	0 to 6
	Default value	2

Value	Meaning
0	Disable drive function
1	Slow down on slow down ramp and transit into Switch On Disabled
2	Slow down on quick stop ramp and transit into Switch On Disabled
3	Slow down on current limit and transit into Switch On Disabled
4	Slow down on voltage limit and transit into Switch On Disable
5	Slow down on slow down ramp and stay in Quick Stop Active
6	Slow down on quick stop ramp and stay in Quick Stop Active

Table 6.7: Quick stop option codes

6.3.4 Shutdown (605B_h)

This object shall indicate what action is performed if there is a transition from Operation Enabled state to Ready To Switch On state. The slow down ramp is the deceleration value of the used mode of operations.

Object description

Index	605B _h
Name	Shutdown
Object code	VAR
Data type	Integer16
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	No
Value range	0 to 1
Default value	0

Value	Meaning
0	Disable drive function (Switch off the drive power stage)
1	Slow down with slow down ramp; disable of the drive function

Table 6.8: Shutdown option codes

6.3.5 Disable operation (605C_h)

This object shall indicate what action is performed if there is a transition from Operation Enabled state to Switched on state. The slow down ramp is the deceleration value of the used mode of operation.

Object description

Index	605C _h
Name	Disable operation
Object code	VAR
Data type	Integer16
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	No
Value range	0 to 1
Default value	0

Value	Meaning
0	Disable drive function (Switch off the drive power stage)
1	Slow down with slow down ramp; disable of the drive function

Table 6.9: Disable operation option codes

6.3.6 Halt (605D_h)

Indicates what action is performed if there is a transition from Operation Enabled state to Switched on state. The slow down ramp is the deceleration value of the used mode of operations.

Object description

Index	605D _h
Name	Halt
Object code	VAR
Data type	Integer16
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	No
Value range	1 or 2
Default value	2

Value	Meaning
1	Slow down on slow down ramp and stay in Operation Enabled
2	Slow down on quick stop ramp and stay in Operation Enabled

Table 6.10: Halt option codes

6.3.7 Fault reaction (605E_h)

Indicates what action is performed when fault is detected in the PDS. The slow down ramp is the deceleration value of the used mode of operations.

Object description

Index	605E _h
Name	Halt
Object code	VAR
Data type	Integer16
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	No
Value range	0 to 2
Default value	2

Value	Meaning
0	Disable drive function, motor is free to rotate
1	Slow down on slow down ramp
2	Slow down on quick stop ramp

Table 6.11: Fault reaction option codes

6.4 Supported modes of operation

The function of the product depends on the selected modes of operation. It is not possible to operate the modes in parallel. The user must select a mode to operate in. An example of exclusive functions are Profile Velocity and Profile Position modes. Supported modes are:

- 1) Profile position
- 2) Homing mode
- 3) Profile velocity

The product allows the user to switch dynamically from operation mode to operation mode.

The mode of operation is set or read using Mode of Operation (6060_h) and Mode of Operation display (6061_h).

6.4.1 Mode of operation (6060_h)

This object shall indicate the requested operation mode.

Object description

Index	6060 _h
Name	Mode of operation
Object code	VAR
Data type	Integer8
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	No
Value range	1, 3 or 6
Default value	1

Value	Meaning
1	Profile Position
3	Profile Velocity
6	Homing

Table 6.12: Mode of operation

6.4.2 Mode of operation display (6061_h)

The Modes of Operation Display shows the current mode of operation. The meaning of the returned value corresponds to that of the Modes of Operation option code (index 6060_h).

<i>Object description</i>	Index	6061 _h
	Name	Mode of operation display
	Object code	VAR
	Data type	Integer8
	Category	Optional
<i>Entry description</i>	Sub-index	00 _h
	Access	ro
	PDO mapping	Yes
	Value range	1, 3 or 6
	Default value	1

6.4.3 Supported drive modes (6502_h)

This object shall provide information on the supported drive modes.

31	16	15	10	9	8	7	6	5	4	3	2	1	0
Mfg specific	Reserved			ns	Cyclic sync position		ns	Homing	ns	Profile torque	Profile velocity	ns	Profile position
MSB													LSB
ns = not supported													

<i>Object description</i>	Index	6502 _h
	Name	Supported drive modes
	Object code	VAR
	Data type	Unsigned32
	Category	Optional
<i>Entry description</i>	Sub-index	00 _h
	Access	ro
	PDO mapping	No
	Value range	Unsigned32
	Default value	00000025 _h

6.5 Profile position mode

6.5.1 Overview

A `target_position` is applied to the trajectory generator. It is generating a `position_demand_value` for the position control loop described in the position control function section. These two function blocks are optionally controlled by individual parameter sets.

At the input to the trajectory generator, parameters may have optional limits applied before being normalized to internal units. Normalized parameters are denoted with an asterisk. The simplest form of a trajectory generator is just to pass through a `target_position` and to transform it to a `position_demand_value` with internal units (increments) only.




Figure 6.2: Trajectory generator for profile position block diagram

Input data The input data objects for profile position:

Object	Name	Description
607A _h	<code>target_position</code>	Defines the targeted absolute or relative position for a move
607E _h	<code>polarity</code>	Sets the polarity for a position or speed commands
6081 _h	<code>profile_velocity</code>	Sets the velocity for profile position motion
6082 _h	<code>end_velocity</code>	Sets the velocity upon reaching target.
6083 _h	<code>profile_acceleration</code>	Sets the acceleration for profile position and profile velocity
6084 _h	<code>profile_deceleration</code>	Sets the deceleration for profile position and profile velocity
6085 _h	<code>quick_stop_decel</code>	Sets the deceleration for quick stop active

Table 6.13: Input data objects for profile position

Output data The output data objects for profile position:

Object	Name	Description
607A _h	position_ demand_value	Displays the motor position

Table 6.13: Input data objects for profile position

6.5.2 Functional description

There are two different ways to apply `target_positions` to a drive, are supported by this device profile.

1. Set of set-points:

After reaching the `target_position` the drive unit immediately processes the next `target_position` which results in a move where the velocity of the drive normally is not reduced to zero after achieving a set-point.

2. Single set-point:

After reaching the `target_position` the drive unit signals this status to a host computer and then receives a new set-point. After reaching a `target_position` the velocity normally is reduced to zero before starting a move to the next set-point.

The two modes are controlled by the timing of the bits `new_set-point` and `change_set_immediately` in the controlword and `set-point_acknowledge` in the statusword.

These bits allow to set up a request-response mechanism in order to prepare a set of set-points while another set still is processed in the drive unit. This minimizes reaction times within a control program on a host computer.





Figure 6.3: Set-point transmission from host (see table 6.14 for states)

Bit state #	Meaning
(1)	Single set-point is expected by device
(2)	Host signals "data is valid" new set-point = 1
(3)	Device response: sets bit 12, set-point acknowledge = 1
(4)	Data is validated, host may release new set-point
(5)	Device response: sets bit 12, set-point acknowledge = 0 Device ready to receive new data
(6)	Indicates state of change_set_immediately = 1

Table 6.14: Set-point transmission from host bit states

Figure 6.3, Figure 6.4 and Figure 6.5 illustrate the difference between the "set of set-points" mode and the "single set-point" mode. The initial status of the bit `change_set_immediately` in the controlword determines which mode is used. Trapezoidal moves are used as this is the only `motion_profile_type` the Lexium MDrive CANopen supports.

If the bit `change_set_immediately` is "0" (shaded area in Figure 6.3) a single set-point is expected by the drive (1). After data is applied to the drive, a host signals that the data is valid by changing the bit `new_setpoint` to "1" in the controlword (2). The drive responds with `setpoint_acknowledge` set to "1" in the statusword (3) after it recognized and buffered the new valid data. Now the host may release `new_setpoint` (4) and afterwards the drive signals with `setpoint_acknowledge` equal "0" its ability to accept new data again (5). In Figure 6.4 this mechanism results in a velocity of zero after ramping down in order to reach a `target_position X1` at T_1 . After signalling to the host, that the set-point is reached like described above, the next `target_position X2` is processed at T_2 and reached at T_3 .

Figure 6.4: Single set-point mode (move after a move) 6040_h bit 5=0

With `change_set_immediately` set to "1" (6), symbolized by the clear area in Figure 6.3, the host advises the drive to apply a new set-point immediately after reaching the last one. The relative timing of the other signals is unchanged. This behavior causes the drive to already process the next set-point X_2 and to keep its velocity when it reaches the `target_position X1` at T_1 . Then drive moves immediately to the already calculated next `target_position X2`.




Figure 6.5: Set of set-points (move on a move) 6040h bit 5=1

6.5.3 Control word definition for profile position

15 ... 9	8	7	6	5	4	3 ... 0
See 6.2.1	halt	See 6.2.1	abs/rel	change set immediately	new set point	See 6.2.1

Bit	Name	Value	Meaning
4	New set-point	0	Does not assume target position
		1	Assume target position
5	Change set immediately	0	Finish the actual positioning and then start the next positioning
		1	Interrupt the actual positioning and start the next positioning
6	abs/rel	0	Target position is an absolute value
		1	Target position is a relative value
8	Halt	0	Execute positioning
		1	Stop motion with profile deceleration

Table 6.15: Profile position mode control word (6040_h) bit state meanings

6.5.4 Status word definition for profile position

15 ... 14	13	12	11	10	9 ... 0
See 6.2.2	following error	set-point acknowledge	See 6.2.2	target reached	See 6.2.2

Bit	Name	Value	Meaning
10	Target reached	0	Halt=0: Target position not reached Halt=1: Axis decelerating
		1	Halt=0: Target position reached Halt=1: Axis velocity is 0
12	Set-point acknowledge	0	Trajectory generator has not assumed the positioning values yet
		1	Trajectory generator has assumed the positioning values
13	Following error	0	No following error
		1	Following error

Table 6.16: Profile position mode status word (6041_h) bit state meanings

Position, velocity and acceleration objects

6.5.5 607A_h Target position

The target position is the position that the drive should move to in position profile mode using parameters such as velocity, acceleration, deceleration, motion profile type etc. The target position is given in terms of 51,200 units per motor shaft revolution. The target position will be interpreted as absolute or relative depending on the absolute relative flag (bit 6) in the controlword.

Object description

Index	607A _h
Name	Target position
Object code	VAR
Data type	Integer32
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	Yes
Value range	8000 0000 _h to 7FFF FFFF _h
Default value	0000 0000 _h

6.5.6 607E_h Polarity

Position demand value and position actual value are multiplied by 1 or -1, depending on the value of the polarity flag.

7	6	5 ... 0
position polarity	velocity polarity	reserved

Object description

Index	607E _h
Name	Polarity
Object code	VAR
Data type	Unsigned8
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	Yes
Value range	Unsigned8
Default value	00 _h

6.5.7 6081_h Profile velocity

The profile velocity is the velocity normally attained at the end of the acceleration ramp during a profiled move and is valid for both directions of motion. The profile velocity is given in steps per second.

Object description

Index	6081 _h
Name	Profile velocity
Object code	VAR
Data type	Unsigned32
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	Yes
Value range	Unsigned32
Default value	512000 _d

6.5.8 6082_h End velocity

The end velocity defines the velocity which the drive must have on reaching the target position. Normally, the drive stops at the target position, i.e. the `end_velocity` = 0. The end velocity is given in the same units as profile velocity.

Object description

Index	6082 _h
Name	Polarity
Object code	VAR
Data type	Unsigned32
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	Yes
Value range	Unsigned32
Default value	51200 _d

6.5.9 6083_h Profile acceleration

Profile acceleration is given in steps/sec²

Object description

Index	6083 _h
Name	Profile acceleration
Object code	VAR
Data type	Unsigned32
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	Yes
Value range	Unsigned32
Default value	100000 _d

6.5.10 6084_h Profile deceleration

Profile deceleration is given in steps/sec²

Object description

Index	6084 _h
Name	Profile deceleration
Object code	VAR
Data type	Unsigned32
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	Yes
Value range	Unsigned32
Default value	100000 _d

6.5.11 6085_h Quick stop deceleration

This object shall indicate the configured deceleration used to stop the motor when the quick stop function is activated and the quick stop code object (Idx 605A_h) is set to 2 or 6. The quick stop deceleration is also used if the fault reaction code object (Idx 605E_h) is 2 and the halt option code object (Idx 605D_h) is 2. The value shall be given in the same physical unit as profile acceleration object (Idx 6083_h).

<i>Object description</i>	Index	6085 _h
	Name	Quick stop deceleration
	Object code	VAR
	Data type	Unsigned32
	Category	Optional
<i>Entry description</i>	Sub-index	00 _h
	Access	rw
	PDO mapping	Yes
	Value range	Unsigned32
	Default value	200000 _d

6.5.12 6086_h Motion profile type

The motion profile type is used to select the type of motion profile used to perform a move. The represented devices are fixed at value 0: linear ramp (trapezoidal profile)

<i>Object description</i>	Index	6086 _h
	Name	Motion profile type
	Object code	VAR
	Data type	Integer16
	Category	Optional
<i>Entry description</i>	Sub-index	00 _h
	Access	rw
	PDO mapping	Yes
	Value range	0 _d
	Default value	0 _d

6.5.13 Profile position application example

The represented device(s) support relative and absolute moves to position. Using either relative or absolute moves, the user can also select (by the control word data) if the target position should be reached before another target position is allowed (finish first) or if the product should execute a newly received target position even if still in motion (immediate).

The below example sets typical motion profile commands a system would configure¹, enabling the motor power² and the four different move types³ supported in profile position mode using SDOs with Node ID41_h.

¹ Typical motion profile commands could be set each time on power up from host or set using a configuration file and stored to NVM once.

² Enabling the motor power only has to be done once on power up.

³ The Control Word data selects the move type.

All values shown are hexadecimal.

ID	RTR	Data String	Action
Typical motion parameters			
0641	00	2F 04 22 00 50 00 00 00	Set run current to 80%
0641	00	23 84 60 00 40 42 0F 00	Set deceleration to 1M steps/sec ²
0641	00	23 83 60 00 40 42 0F 00	Set acceleration to 1M steps/sec ²
0641	00	23 81 60 00 00 D0 07 00	Set max velocity to 512000 steps/sec
Enable motor power - DSP402 state machine			
0641	00	2B 40 60 00 06 00 00 00	Ready to switch on
0641	00	2B 40 60 00 07 00 00 00	Switched on
0641	00	2B 40 60 00 0F 00 00 00	Operation enable
Set to profile position mode			
0641	00	2F 60 60 00 01 00 00 00	Set to profile position mode
Perform absolute move, finish before performing additional moves			
0641	00	23 7A 60 00 30 75 00 00	Set target position to 30000 steps
0641	00	2B 40 60 00 1F 00 00 00	Set control word bit 4 to 1
0641	00	2B 40 60 00 0F 00 00 00	Set control word bit 4 to 0
Perform absolute move, move immediate			
0641	00	23 7A 60 00 B8 0B 00 00	Set target position to 3000 steps
0641	00	2B 40 60 00 3F 00 00 00	Set control word bit 4 to 1
0641	00	2B 40 60 00 2F 00 00 00	Set control word bit 4 to 0
Perform relative move, finish before performing additional moves			
0641	00	23 7A 60 00 A0 86 01 0	Set target position to 100000
0641	00	2B 40 60 00 5F 00 00 00	Set control word bit 4 to 1
0641	00	2B 40 60 00 4F 00 00 00	Set control word bit 4 to 0
Perform relative move, move immediate			
0641	00	23 7A 60 00 B8 0B 00 00	Set target position to 3000 steps
0641	00	2B 40 60 00 7F 00 00 00	Set control word bit 4 to 1
0641	00	2B 40 60 00 6F 00 00 00	Set control word bit 4 to 0

Table 6.17: Profile position mode application example

6.6 Profile velocity mode

6.6.1 Overview

The profile velocity mode covers the following sub-functions:

- Demand value input via trajectory generator
- Velocity capture using position sensor or velocity sensor
- Velocity control function with appropriate input and output signals
- Monitoring of the profile velocity using a window-function
- Monitoring of velocity actual value using a threshold




Figure 6.6: Profile velocity control function

6.6.2 Control word definition for profile velocity

15 ... 9	8	7	6 ... 4	3 ... 0
See 6.2.1	halt	See 6.2.1	reserved	See 6.2.1

Bit	Name	Value	Meaning
8	Halt	0	Execute the motion
		1	Stop axis

Table 6.18: Profile velocity mode control word (6040h) bit state meanings

6.6.3 Status word definition for profile velocity

15 ... 14	13	12	11	10	9 ... 0
See 6.2.2	max slippage error	speed	See 6.2.2	target reached	See 6.2.2

Bit	Name	Value	Meaning
10	Target reached	0	Halt=0: Target position not reached Halt=1: Axis decelerating
		1	Halt=0: Target position reached Halt=1: Axis velocity is 0
12	Speed	0	Speed is not equal to 0
		1	Speed is equal to 0
13	Max slippage error	0	Maximum slippage not reached
		1	Maximum slippage reached

Table 6.19: Profile velocity mode status word (6041h) bit state meanings

Profile velocity mode objects

6.6.4 606C_h Velocity actual value

This object shall provide the actual velocity value derived either from the velocity sensor or the position sensor. The value shall be given in microsteps per second.

<i>Object description</i>	Index	606C _h
	Name	Velocity actual value
	Object code	VAR
	Data type	Integer32
	Category	Optional
<i>Entry description</i>	Sub-index	00 _h
	Access	rw
	PDO mapping	Yes
	Value range	Integer32
	Default value	0000 0000 _h

6.6.5 60F8_h Maximum slippage

This object shall indicate the configured maximal slippage of an asynchronous motor. When the max slippage has been reached, the corresponding bit 13 max slippage error in the statusword shall be set to 1. The reaction of the drive device, when the max slippage error occurs, is manufacturer-specific. This value shall be given in microsteps.

<i>Object description</i>	Index	60FF _h
	Name	Maximum slippage
	Object code	VAR
	Data type	Integer32
	Category	Optional
<i>Entry description</i>	Sub-index	00 _h
	Access	rw
	PDO mapping	Yes
	Value range	Integer32
	Default value	512 _d

6.6.6 60FF_h Target velocity

The Target Velocity is the input to the trajectory generator and the value is given in microsteps/second.

Object description

Index	60FF _h
Name	Target velocity
Object code	VAR
Data type	Integer32
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	Yes
Value range	8000 0000 _h to 7FFF FFFF _h
Default value	0000 0000 _h

6.6.7 Profile velocity application example

The represented device(s) support the ability to move in velocity mode. Once in Profile Velocity Mode, any new target velocity will be executed immediately.

The below example sets typical motion profile commands a system would configure¹, enabling the motor power² and sending a new target velocity using SDOs with Node ID41_h.

¹ Typical motion profile commands could be set each time on power up from host or set using a configuration file and stored to NVM once.

² Enabling the motor power only has to be done once on power up.

All values shown are hexadecimal.

ID	RTR	Data String	Action
Typical motion parameters			
0641	00	2F 04 22 00 50 00 00 00	Set run current to 80%
0641	00	23 84 60 00 40 42 0F 00	Set deceleration to 1M steps/sec ²
0641	00	23 83 60 00 40 42 0F 00	Set acceleration to 1M steps/sec ²
0641	00	23 81 60 00 00 D0 07 00	Set max velocity to 512000 steps/sec
Enable motor power - DSP402 state machine			
0641	00	2B 40 60 00 06 00 00 00	Ready to switch on
0641	00	2B 40 60 00 07 00 00 00	Switched on
0641	00	2B 40 60 00 0F 00 00 00	Operation enable
Set to profile velocity mode			
0641	00	2F 60 60 00 03 00 00 00	Set to profile velocity mode
Send new target velocity			
0641	00	23 FF 60 00 50 C3 00 00	Set target velocity 50000 steps/sec

Table 6.20: Profile velocity mode application example

6.7 Homing mode

6.7.1 Overview

This subsection describes the method by which a drive seeks the home position (also called, the datum, reference point or zero point). There are various methods of achieving this using limit switches at the ends of travel or a home switch (zero point switch) in mid-travel, most of the methods also use the index (zero) pulse train from an incremental encoder.




Figure 6.8 : The homing function

Input data description The user can specify the speeds and the method of homing. There are two homing_speeds; in a typical cycle the faster speed is used to find the home switch and the slower speed is used to find the index pulse. The manufacturer is allowed some discretion in the use of these speeds as the response to the signals may be dependent upon the hardware used.

Output data description There is no output data except for those bits in the statusword which return the status or result of the homing process and the demand to the position control loops.

6.7.2 Control word definition for homing mode

15 ... 9	8	7	6 ... 5	4	3 ... 0
See 6.2.1	halt	See 6.2.1	reserved	homing operation start	See 6.2.1

Bit	Name	Value	Meaning
4	Homing operation start	0	Execute the motion
		0 ⇔ 1	Start homing mode
		1	Homing mode active
		1 ⇔ 0	Interrupt homing mode
8	Halt	0	Execute the instruction of bit 4
		1	Stop axis

Table 6.21: Homing mode control word (6040h) bit state meanings

6.7.3 Status word definition for homing mode

15 ... 14	13	12	11	10	9 ... 0
See 6.2.2	homing error	homing attained	See 6.2.2	target reached	See 6.2.2

Bit	Name	Value	Meaning
10	Target reached	0	Halt=0: Target position not reached Halt=1: Axis decelerating
		1	Halt=0: Target position reached Halt=1: Axis velocity is 0
12	Homing Attained	0	Homing mode not yet complete
		1	Homing mode carried out successfully
13	Following error	0	No homing error
		1	Homing error

Table 6.22: Homing mode status word (6041h) bit state meanings

Homing mode objects

6.7.4 607C_h Homing offset

This object shall indicate the configured difference between the zero position for the application and the machine home position (found during homing). During homing the machine home position is found and once the homing is completed the zero position is offset from the home position by adding the home offset to the home position. All subsequent absolute moves shall be taken relative to this new zero position. If this object is not implemented then the home offset shall be regarded as zero. The value of this object shall be given in micro steps. Negative values shall indicate the opposite direction.




Figure 6.7: The homing offset

Object description

Index	607C _h
Name	Homing offset
Object code	VAR
Data type	Unsigned32
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	Yes
Value range	Unsigned32
Default value	0 _d

6.7.5 6098_h Homing method

The homing method object determines the method that will be used during homing.

<i>Object description</i>	Index	6098 _h
	Name	Homing method
	Object code	VAR
	Data type	Integer8
	Category	Optional
<i>Entry description</i>	Sub-index	00 _h
	Access	rw
	PDO mapping	Yes
	Value range	0 _d (no homing) 1 – 35 _d (method)
	Default value	0 _d

Functional description of homing methods

Method 1: Homing on the negative limit switch and index pulse

Using this method the initial direction of movement is leftward if the negative limit switch is inactive (here shown as low). The home position is at the first index pulse to the right of the position where the negative limit switch becomes inactive.




Figure 6.9: Homing on the negative limit switch and index pulse

Method 2: Homing on the positive limit switch and index pulse

Using this method the initial direction of movement is rightward if the positive limit switch is inactive (here shown as low). The position of home is at the first index pulse to the left of the position where the positive limit switch becomes inactive.




Figure 6.10: Homing on the positive limit switch and index pulse

Methods 3 and 4: Homing on the positive home switch and index pulse

Using methods 3 or 4 the initial direction of movement is dependent on the state of the home switch. The home position is at the index pulse to either to the left or the right of the point where the home switch changes state. If the initial position is sited so that the direction of movement must reverse during homing, the point at which the reversal takes place is anywhere after a change of state of the home switch.




Figure 6.11: Homing on the positive home switch and index pulse

Methods 5 and 6: Homing on the negative home switch and index pulse

Using methods 5 or 6 the initial direction of movement is dependent on the state of the home switch. The home position is at the index pulse to either to the left or the right of the point where the home switch changes state. If the initial position is sited so that the direction of movement must reverse during homing, the point at which the reversal takes place is anywhere after a change of state of the home switch.




Figure 6.12: Homing on the negative home switch and index pulse

Methods 7 to 14: Homing on the Home Switch and Index Pulse

These methods use a home switch which is active over only portion of the travel, in effect the switch has a 'momentary' action as the axle's position sweeps past the switch.

Using methods 7 to 10 the initial direction of movement is to the right, and using methods 11 to 14 the initial direction of movement is to the left except if the home switch is active at the start of the motion. In this case the initial direction of motion is Dependent on the edge being sought. The home position is at the index pulse on either side of the rising or falling edges of the home switch, as shown in the following two diagrams. If the initial direction of movement




Figure 6.13: Homing on the home switch and index pulse - positive initial move




Figure 6.14: Homing on the home switch and index pulse - negative initial move

Methods 15 and 16: Reserved

These methods are reserved for future expansion of the homing mode.

Methods 17 to 30: Homing without an index pulse

These methods are similar to methods 1 to 14 except that the home position is not dependent on the index pulse but only dependent on the relevant home or limit switch transitions. For example methods 19 and 20 are similar to methods 3 and 4 as shown in the following diagram.




Figure 6.15: Homing without and index pulse

Methods 31 and 32: Reserved

These methods are reserved for future expansion of the homing mode.

Methods 33 and 34: Homing on an index pulse

Using methods 33 or 34 the direction of homing is negative or positive respectively. The home position is at the index pulse found in the selected direction.




Figure 6.16: Homing on an index pulse

Method 35: Homing on the current position

In method 35 the current position is taken to be the home position.

6.7.5 6099_h Homing speeds

The homing speeds object determines the fast and slow speeds that will be used during homing.

Object description

Index	6098 _h
Name	Homing speeds
Object code	ARRAY
Data type	Unsigned32
Category	Optional

Entry description

Sub-index	00 _h
Name	Number of entries
Access	ro
PDO mapping	—
Value range	—
Default value	02 _h

Sub-index	01 _h
Name	Homing speed fast
Access	rw
PDO mapping	—
Value range	0000 0000 _h to 7FFF FFFF _h
Default value	102400 _d

Sub-index	02 _h
Name	Homing speed slow
Access	rw
PDO mapping	—
Value range	0000 0000 _h to 7FFF FFFF _h
Default value	6400 _d

6.7.6 Homing mode application example

Homing Mode – demonstrates home method 18 decimal using Service Data Objects (SDOs).

Devices represented by this manual support the ability to move in homing mode.

The below example sets typical motion profile commands a system would configure¹, enabling the motor power² and executing a homing function using SDOs with Node ID 41_H.

¹ Typical motion profile commands could be set each time on power up from host or set using a configuration file and stored to NVM once.

² Enabling the motor power only has to be done once on power up.

All values shown are hexadecimal.

ID	RTR	Data String	Action
Typical motion parameters			
0641	00	2F 04 22 00 50 00 00 00	Set run current to 80%
0641	00	23 84 60 00 40 42 0F 00	Set deceleration to 1M steps/sec ²
0641	00	23 83 60 00 40 42 0F 00	Set acceleration to 1M steps/sec ²
0641	00	23 81 60 00 00 D0 07 00	Set max velocity to 512000 steps/sec
Enable motor power - DSP402 state machine			
0641	00	2B 40 60 00 06 00 00 00	Ready to switch on
0641	00	2B 40 60 00 07 00 00 00	Switched on
0641	00	2B 40 60 00 0F 00 00 00	Operation enable
Set to homing mode			
0641	00	2F 60 60 00 06 00 00 00	Set to homing mode
Configure I/O and homing method			
0641	00	22 00 20 01 00 00 00 00	Set I/O as inputs
0641	00	22 00 20 02 00 00 00 00	Set I/O as sinking
0641	00	22 00 20 04 01 00 00 00	Set I1 as polarity
0641	00	22 02 20 01 01 00 00 00	Set I1 as home switch
0641	00	22 06 20 01 0A 00 00 00	Set I1 filter to 10ms
Set homing method, offset and speeds			
0641	00	22 98 60 00 13 00 00 00	Homing Method 19 decimal
0641	00	2F 98 20 00 01 00 00 00	Apply home offset to pos counter
0641	00	22 7C 60 00 00 00 00 00	Home offset = 0
0641	00	22 99 60 01 00 C8 00 00	Home speed fast
0641	00	22 99 60 02 00 14 00 00	Home speed slow
Start homing			
0641	00	2B 40 60 00 1F 00 00 00	Start homing
After home switch toggles			
0641	00	2B 40 60 00 00 00 00 00	Stop homing

Table 6.23: Homing mode application example

6.8 Torque mode (Closed loop models only)

6.8.1 Overview

The profile torque mode allows the Lexium MDrive to transmit the target torque value, which is processed via the trajectory generator and the hM-Technology logic.

The axis will ramp to the `TARGET_TORQUE` (6071h) as specified by the `TORQUE_RAMP` (6087h).

The manufacturer-specific `TORQUE_SPEED` (2704h) specifies the axis velocity at which the `TARGET_TORQUE` will be maintained.




Figure 6:17: Profile torque mode

6.8.2 Control word definition for profile torque mode

15 ... 9	8	7	6	4	3	0
See 6.2.1	halt	See 6.2.1	reserved	See 6.2.1		

Bit	Value	Meaning
8	0	The motion shall be executed 8 or continued
	1	1 Axis shall be stopped according to the halt option code (605Dh)

Table 6.24: Profile torque mode control word (6040h) bit state meanings

6.8.2 Control word definition for profile torque mode

15	14	13	12	11	10	9	0
See 6.2.1		reserved		See 6.2.1	Target reached	See 6.2.1	

Bit	Value	Meaning
10	0	Halt (Bit 8 in controlword) = 0: Target torque not reached Halt (Bit 8 in controlword) = 1: Axis decelerates
	1	Halt (Bit 8 in controlword) = 0: Target torque reached Halt (Bit 8 in controlword) = 1: Velocity of axis is 0

Table 6.25: Profile torque mode status word (6041h) bit state meanings

Torque Mode objects

6.8.3 Object 6071_h: Target torque

This object shall indicate the configured input value for the torque controller in profile torque mode. The value shall be given per thousand of rated torque.

<i>Object description</i>	Index	6071 _h
	Name	Target torque
	Object code	VAR
	Data type	Integer16
	Category	Mandatory

<i>Entry description</i>	Sub-index	00 _h
	Access	rw
	PDO mapping	Yes
	Value range	-1000 _d to 1000 _d
	Default value	0 _d

6.8.4 Object 6077_h: Torque actual value

Provides the actual value of the torque. It shall correspond to the instantaneous torque in the motor. The value shall be given per thousand of rated torque.

Object description

Index	6077 _h
Name	Torque actual value
Object code	VAR
Data type	Integer16
Category	Optional

Entry description

Sub-index	00 _h
Access	ro
PDO mapping	Yes
Value range	-1000 _d to 1000 _d
Default value	0 _d

6.8.5 Object 6087_h: Torque slope

This object shall indicate the configured rate of change of torque. The value shall be given in units of per thousand of rated torque per second.

Object description

Index	6087 _h
Name	Torque slope
Object code	VAR
Data type	Unsigned32
Category	Mandatory

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	Yes
Value range	Unsigned32
Default value	1000 _d

6.8.6 Profile torque example

This example will enter profile torque, set the target torque, speed and torque ramp.

ID	RTR	Data String	Action
0641	00	2F 60 60 00 04 00 00 00	Enable profile torque mode
0641	00	23 87 60 00 E8 03 00 00	Set torque ramp to 100%/sec
0641	00	2F 04 27 00 62 00 00 00	Set max torque speed to 120000 usteps/sec
0641	00	2B 71 60 00 F4 01 00 00	Set torque to 50%

Table 6.25: Profile torque application example

6.9 Cyclic synchronous position

6.9.1 Overview

With this mode, the trajectory generator is located in the control device, not in the drive device. In cyclic synchronous manner it provides a target position to the drive device, which performs position control and velocity control. Optionally, additive velocity values can be provided by the control system in order to allow for velocity feed-forward.

The behavior of the control function is influenced by control parameters, which are externally applicable. The interpolation time period defines the time period between two updates of the target position and/or additive position and shall be used for inter-cycle interpolation.

The target position is interpreted as absolute value. The position actual value is used as mandatory output to the control device. Additionally, the velocity actual value is output.

The following error is used to set an error bit in the Status word (6041h).




Figure 6.18: Cyclic synchronous position control function

6.9.2 Controlword and statusword for cyclic synch position

The cyclic synchronous position mode uses no mode specific bits of the controlword and three bits of the statusword for mode-specific purposes.

15 ... 14	13	12	11	10	9	0
See 6.2.1	following error	See 6.2.1	Target position ignored	reserved	See 6.2.1	

Bit	Value	Meaning
10	0	reserved
	1	reserved
11	0	Target position ignored
	1	Target position shall be used as input to position control loop
13	0	No following error
	1	Following error

Table 6.26: Statusword bits for Cyclic Synchronous Position mode

6.10 Position control function

6.10.1 Overview

In this section, all parameters are described which are necessary for a closed loop position control. The control loop is fed with the `position_demand_value` as one of the outputs of the Trajectory Generator and with the output of the position detection unit (`position_actual_value`) like a resolver or encoder as input parameters.

6.10.2 6062_h Position demand actual value

This object shall provide the demanded position value. The value shall be given in motor steps.

Object description

Index	6062 _h
Name	Position demand actual value
Object code	VAR
Data type	Integer32
Category	Optional

Entry description

Sub-index	00 _h
Access	ro
PDO mapping	Yes
Value range	Integer32
Default value	0000 0000 _h

6.10.3 6063_h Position actual value internal

This object shall provide the actual value of the position measurement device, which shall be one of the two input values of the closed-loop position control.

Object description

Index	6063 _h
Name	Position actual value internal
Object code	VAR
Data type	Integer32
Category	Optional

Entry description

Sub-index	00 _h
Access	ro
PDO mapping	Yes
Value range	Integer32
Default value	0000 0000 _h

6.10.4 6064_h Position actual value

This object represents the actual value of the position measurement device microsteps.

Object description

Index	6064 _h
Name	Position actual value
Object code	VAR
Data type	Integer32
Category	Optional

Entry description

Sub-index	00 _h
Access	ro
PDO mapping	Yes
Value range	Integer32
Default value	0000 0000 _h

6.10.5 6065_h Following error window

This object shall indicate the configured range of tolerated position values symmetrically to the position demand value. If the position actual value is out of the following error window, a following error occurs. A following error may occur when a drive is blocked, unreachable profile velocity occurs, or at wrong closed-loop coefficients. The value shall be given in user defined position units. If the value of the following error window is FFFF FFFF_h, the following control shall be switched off.

Object description

Index	6065 _h
Name	Following error window
Object code	VAR
Data type	Unsigned32
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	No
Value range	Unsigned32
Default value	0000 0512 _h

6.10.6 6066_h Following error timeout

This object shall indicate the configured time for a following error condition, after that the bit 13 of the statusword shall be set to 1. The reaction of the drive when a following error occurs is manufacturer-specific. The value shall be given in milliseconds.

Object description

Index	6066 _h
Name	Following error timeout
Object code	VAR
Data type	Unsigned16
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	No
Value range	Unsigned16
Default value	0000 _h

6.10.7 6067_h Position window

This object shall indicate the configured symmetrical range of accepted positions relatively to the target position. If the actual value of the position encoder is within the position window, this target position shall be regarded as reached. The target position shall be handled in the same manner as in the trajectory generator concerning limiting functions and transformation into internal machine units before it may be used with this function. The value shall be given in user-defined position units. If the value of the position window is FFFF FFFF_h, the position window control shall be switched off.

Object description

Index	6067 _h
Name	Position window
Object code	VAR
Data type	Unsigned32
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	No
Value range	Unsigned32
Default value	0FFF FFFF _h

6.10.8 6068_h Position window time

This object shall indicate the configured time, during which the actual position within the position window is measured. The value shall be given in milliseconds.

Object description

Index	6066 _h
Name	Position window time
Object code	VAR
Data type	Unsigned16
Category	Optional

Entry description

Sub-index	00 _h
Access	rw
PDO mapping	No
Value range	Unsigned16
Default value	0000 _h

6.11 Factors

6.11.1 608F_h Position encoder resolution

This object defines the ratio of encoder increments per motor revolution:

$$\text{position encoder resolution} = \frac{\text{encoder increments (sub 01}_h\text{)}}{\text{motor revolutions (sub 02}_h\text{)}}$$

The default values assume a 512 line (2048 edges) encoder.

Object description

Index	608F _h
Name	Position encoder resolution
Object code	ARRAY
Data type	—
Category	Optional

Entry description

Sub-index	00 _h
Name	Number of entries
Access	ro
PDO mapping	—
Value range	—
Default value	02 _h
Sub-index	01 _h
Name	Resolution numerator
Access	rw
PDO mapping	—
Value range	Unsigned32 (1 to 65535 _d)
Default value	2048 _d
Sub-index	02 _h
Name	Resolution denominator
Access	rw
PDO mapping	—
Value range	Unsigned32 (1 to 65535 _d)
Default value	1 _d

6.11.2 6092_h Feed and drive shaft resolution

This object defines the ratio of user units per shaft revolution:

$$\text{feed and drive shaft resolution} = \frac{\text{feed user units (sub 01}_h\text{)}}{\text{shaft revolutions (sub 02}_h\text{)}}$$

The default values assume a 200 step/rev motor at a step resolution of 256, or 51200 steps per rev as the factor.

Object description

Index	6092 _h
Name	Feed and drive shaft resolution
Object code	ARRAY
Data type	—
Category	Optional

Entry description

Sub-index	00 _h
Name	Number of entries
Access	ro
PDO mapping	—
Value range	—
Default value	02 _h
Sub-index	01 _h
Name	Feed user units numerator
Access	rw
PDO mapping	—
Value range	Unsigned32
Default value	51200 _d
Sub-index	02 _h
Name	Shaft revolutions denominator
Access	rw
PDO mapping	—
Value range	Unsigned32
Default value	1 _d

6.12 Optional application FE (general I/O)

6.12.1 60FD_h Digital inputs

This object reads the digital inputs.

31 ... 24	23	22	21	20	19	18	17	16	15 ... 4	3	2	1	0
X	X	X	X	X	4	3	2	1	reserved	X	home switch	+ limit	– limit
MSB		Input points										LSb	

Object description

Index	60FD _h
Name	Digital inputs
Object code	VAR
Data type	Unsigned32
Category	Optional

Entry description

Sub-index	00 _h
Access	ro
PDO mapping	Yes
Value range	Unsigned32
Default value	0000 0000 _h

6.12.1 60FE_h Digital outputs

This object reads the digital inputs.

31 ... 24	23	22	21	20	19	18	17	16	15 ... 1	0
X	X	X	X	X	X	3	2	1	reserved	brake
MSB			Output points						LSb	

Object description

Index	60FE _h
Name	Digital outputs
Object code	ARRAY
Data type	Unsigned32
Category	Optional

Entry description

Sub-index	00 _h
Name	Number of entries
Access	ro
PDO mapping	No
Value range	01 _h
Default value	01 _h

Sub-index	01 _h
Name	Digital outputs
Access	rw
PDO mapping	Yes
Value range	Unsigned32
Default value	0000 0000 _h

Page intentionally left blank

7 Diagnostics and Troubleshooting

7

7.1 Fieldbus communication error diagnostics

A properly operating fieldbus is essential for evaluating operating and error messages.

Connections for fieldbus mode

If the product cannot be addressed via the fieldbus, first check the connections. The product manual contains the technical data of the device and information on network and device installation. Check the following:

- Power connections to the device
- Fieldbus cable and fieldbus wiring

Baud rate and address

If it is impossible to connect to a device, check the baud rate and node address.

- The baud rate must be the same for all devices in the network.
- The node address of each device must be between 1 and 127 and unique for each device.

To set the baud rate and node address see Section 5: Commissioning.

Fieldbus function test

After correct configuration of the transmission data, test fieldbus mode. This requires installation of a CAN configuration tool that displays CAN messages. Feedback from the product is indicated in the form of a bootup message:

- Switch the power supply off and on again.
- Observe the network messages after switching on. After initialization of the bus, the device sends a boot-up message (COB ID 700h + node ID and 1 data byte with the content 00h).
- With the factory setting 65 (41h) for the node address, the boot-up message is sent via the bus. The device can then be put into operation via NMT services.

7.2 Error diagnostics via fieldbus

7.2.1 Message objects

A number of objects provide information on the operating state and on errors:

- Object `Statusword` (6041h) Operating states, see Section 6.2.2.
- Object `EMCY` (80h+ Node-ID) Error message from a device with error and error code.
- Object `Error register` (1001h) Error
- Object `Error code` (603Fh) Error code of the most recent error. See Section 6.3.2.

7.2.2 Messages on device status

Synchronous and asynchronous errors are distinguished in terms of evaluation and handling of errors.

Synchronous errors The device signals a synchronous error directly as a response to a message that cannot be evaluated. Possible causes comprise transmission errors or invalid data. See Section 7.4.1 “Error register” for a list of synchronous errors.

Asynchronous errors Asynchronous errors are signaled by the monitoring units in the device as soon as a device error occurs. An asynchronous error is signaled via bit 3, Fault, of the object `statusword` (6041h). In the case of errors that cause an interruption of the movement, the device transmits an EMCY message.

7.3 CANopen error messages

CANopen error messages are signaled in the form of EMCY messages. They are evaluated via the objects `Error register` (1001h) and `Error code` (603Fh).

CANopen signals errors that occur during data exchange via SDO with the special SDO error message ABORT.

7.3.1 Error register (1001_h)

This object is an error register for the device. The device can map internal errors in this byte. This entry is mandatory for all devices. It is a part of an Emergency object.

Object description

Index	1001 _h
Name	Error register
Object code	VAR
Data type	Unsigned8
Category	Mandatory

Entry description

Sub-index	00 _h
Access	ro
PDO mapping	Optional
Value range	Unsigned8
Default value	—

Bit	M/O	Meaning
0	M	Generic Error
1	O	Current
2	O	Voltage
3	O	Temperature
4	O	Communication error (Overrun, Error State)
5	O	Device profile specific
6	O	Reserved (always 0)
7	O	Manufacturer specific

Table 7.1: Abort Connection Option Code

7.3.2 Pre-defined error (1003_h)

The object at index 1003h holds the errors that have occurred on the device and have been signaled via the Emergency Object. In doing so it provides an error history.

- 1) The entry at sub-index 0 contains the number of actual errors that are recorded in the array starting at sub-index 1.
- 2) Every new error is stored at sub-index 1, the older ones move down the list.
- 3) Writing a „0“ to sub-index 0 deletes the entire error history (empties the array). Values higher than 0 are not allowed to write. This have to lead to an abort message (error code: 0609 0030h).
- 4) The error numbers are of type UNSIGNED32 and are composed of a 16 bit error code and a 16 bit additional error information field which is manufacturer specific. The error code is contained in the lower 2 bytes (LSB) and the additional information is included in the upper 2 bytes (MSB). If this object is supported it must consist of two entries at least. The length entry on subindex 0h and at least one error entry at sub-index 1H.

V1.00, 09.2014

Object description

Index	1003 _h
Name	Pre-defined error field
Object code	ARRAY
Data type	Unsigned32
Category	Optional

Entry description

Sub-index	00 _h
Description	Number of errors
Access	rw
Entry category	Mandatory
PDO mapping	No
Value range	0 – 254
Default value	0

Sub-index	01 _h
Description	Standard error field
Access	ro
Entry category	Optional
PDO mapping	No
Value range	Unsigned32
Default value	—

Sub-index	02 _h – FE _h
Description	Standard error field
Access	ro
Entry category	Optional
PDO mapping	No
Value range	Unsigned32
Default value	—

Error description	Add'tl info byte	Error code byte
No error	0 _h	0000 _h
CAN overrun	0 _h	8110 _h
Can in error passive mode	0 _h	8120 _h
Lifeguard or heartbeat error	0 _h	8130 _h
Recovered from "bus off" state	0 _h	8140 _h
Bus off state occurred	0 _h	8141 _h
PDO not processed - length error	0 _h	8210 _h
Over temperature error	8 _h	4210 _h
Pending over temperature warning	16 _h	4210 _h
Motor idle during commanded move	1 _h	FF01 _h
Motor should be idle	2 – 8 _h	FF01 _h
Undershot warning	9 _h	FF01 _h

Table 7.2: Description of the error codes

7.4 Status LED

he Lexium MDrive has two LEDs for status indication.

- LED 1: Status of the power supply
- LED 2: The CANopen status LED shows the states as specified in CiA DR-303-3 Indicator specification.

LED 1 power indication

Color	Status
Off	No Power
Green	+VDC supply in range
Flashing green	+VDC off, drive on AUX power
Red	+VDC supply out of range
Flashing red	+VDC off, AUX power out of range

LED 2 CANopen status

Color	Status
Red - single Flash	At least one of the error counters of the CAN controller has reached or exceeded the warning level (too many error frames).
Red - double flash	A guard event (NMT-Slave or NMT-master) or a heartbeat event (Heartbeat consumer) has occurred.
Red - triple flash	The SYNC message has not been received within the configured communication cycle period time out (see Object Dictionary Entry 0x1006).
Red - on	The CAN controller is bus off
Green - single flash	The Device is in STOPPED state
Green - blinking	The Device is in the PREOPERATIONAL state
Green - on	The Device is in the OPERATIONAL state

Page intentionally left blank

8 Object Dictionary

8

8.1 Specification for the objects

Index The index specifies the position of the object in the object dictionary. The index value is specified as a hexadecimal value.

Object code & data types The object code specifies the data structure of the object.

Object code	Meaning	Coding
VAR	A simple value, for example of the type Integer8 or Unsigned32	7
ARR (ARRAY)	A data field in which the entries have the same data type.	8
REC (RECORD)	A data field that contains entries that are a combination of simple data types.	9

Table 8.1: CANopen object codes

Data type	Value range	Data length	DS301 coding
Boolean	0 = false, 1 = true	1 byte	0001
Integer8	−128 ... +127	1 byte	0002
Integer16	−32768 ... +32767	2 byte	0003
Integer32	−2147483648 ... 2147483647	4 byte	0004
Unsigned8	0 ... 255	1 byte	0005
Unsigned16	0 ... 65535	2 byte	0006
Unsigned32	0 ... 4294967295	4 byte	0007
Visible String8	ASCII chars	8 byte	0009
Visible String168	ASCII chars	16 byte	0010

Table 8.2: CANopen data types

RO/RW Indicates read and/or write values
 RO: values can only be read
 RW: values can be read and written.

PDO R_PDO: Mapping for R_PDO possible
 T_PDO: Mapping for T_PDO possible
 No specification: PDO mapping not possible with the object

Min/max values Specifies the permissible range in which the object value is defined and valid.

Factory default Factory default settings when the product is shipped

8.2 Overview of object group 1000_h

No objects from object group 1000_h are PDO mappable.

Index	Sub-index	Name	Obj. code	Data type	Access	Description
1000 _h		Device type	VAR	Unsigned32	ro	Device type and profile
1001 _h		Error register	VAR	Unsigned8	ro	Error register
1003 _h		Predefined error field	ARR		rw	Error history, memory for error messages
	00 _h	Number of errors	VAR	Unsigned8	rw	Number of error entries
	01 _h - 04 _h	Error field	VAR	Unsigned32	ro	Error number
1005 _h		COB-ID SYNC	VAR	Unsigned32	rw	Identifier of the synchronization object
1007 _h		Sync window length	VAR	Unsigned32	rw	Time window for synchronous PDOs in µS
1008 _h		Mfg. device name	VAR	Vis String8	ro	Manufacturer's designation
1009 _h		Mfg. hardware version	VAR	Vis String8	ro	Hardware version
100A _h		Mfg. software version	VAR	Vis String8	ro	Software version
100C _h		Guard time	VAR	Unsigned16	rw	Time span for Node Guarding [ms]
100D _h		Life time factor	VAR	Unsigned8	rw	Repeat factor for Node Guarding
1010 _h		Store parameters	ARR	Unsigned32		Store parameters
	00 _h	Largest sub-index	VAR	Unsigned8	ro	Largest sub-index supported» 04 _h
	01 _h	Save all parameters	VAR	Unsigned32	rw	Save all parameters
	02 _h	Save communication	VAR	Unsigned32	rw	Save Communication Parameters
	03 _h	Save application	VAR	Unsigned32	rw	Save Application Parameters
	04 _h	Save manufacturer	VAR	Unsigned32	rw	Save Manufacturer Parameters
1011 _h		Restore defaults	ARR	Unsigned32		Restore defaults as group
	00 _h	Largest sub-index	VAR	Unsigned8	ro	Largest sub-index supported» 04 _h
	01 _h	Restore all defaults	VAR	Unsigned32	rw	Restore all defaults
	02 _h	Restore communication	VAR	Unsigned32	rw	Restore Communication defaults
	03 _h	Restore application	VAR	Unsigned32	rw	Restore Application defaults
	04 _h	Restore manufacturer	VAR	Unsigned32	rw	Restore Manufacturer defaults
1012 _h		COB-ID time stamp	VAR	Unsigned32	rw	COB-ID time stamp message
1014 _h		COB-ID EMCY	VAR	Unsigned32	rw	80 _h + Node ID
1015 _h		Inhibit time EMCY	VAR	Unsigned16	rw	Wait time for the repeated transmission of EMCY x 100 µS
1017 _h		Producer Heartbeat Time	VAR	Unsigned16	rw	Time interval for producer «Heartbeat»
1018 _h		Identity	REC		ro	Identification object
	00 _h	Largest sub-index	VAR	Unsigned8	ro	Largest sub-index supported» 04 _h
	01 _h	Vendor ID	VAR	Unsigned32	ro	Vendor ID
	02 _h	Product code	VAR	Unsigned32	ro	Product code
	03 _h	Revision number	VAR	Unsigned32	ro	Revision number
	04 _h	Serial number	VAR	Unsigned32	ro	Serial number
1400 _h		1st R_PDO parameter	REC			1st receive PDO parameter
	00 _h	Largest sub-index	VAR	Unsigned8	ro	Largest sub-index supported» 05 _h
	01 _h	COB-ID used	VAR	Unsigned32	rw	COB-ID used: 200 _h + Node ID
	02 _h	Transmission type	VAR	Unsigned8	rw	Default type = 255 (asynchronous)
	03 _h	Inhibit time	VAR	Unsigned16	rw	Default = 0
	05 _h	Event timer	VAR	Unsigned16	rw	Default = 0

Index	Sub-index	Name	Obj. code	Data type	Access	Description
1401 _h		2nd R_PDO parameter	REC			2nd receive PDO parameter
	00 _h	Largest sub-index	VAR	Unsigned8	ro	Largest sub-index supported» 05 _h
	01 _h	COB-ID used	VAR	Unsigned32	rw	COB-ID used: 300 _h + Node ID
	02 _h	Transmission type	VAR	Unsigned8	rw	Default type = 255 (asynchronous)
	03 _h	Inhibit time	VAR	Unsigned16	rw	Default = 0
	05 _h	Event timer	VAR	Unsigned16	rw	Default = 0
1402 _h		3rd R_PDO parameter	REC			3rd receive PDO parameter
	00 _h	Largest sub-index	VAR	Unsigned8	ro	Largest sub-index supported» 05 _h
	01 _h	COB-ID used	VAR	Unsigned32	rw	COB-ID used: 400 _h + Node ID
	02 _h	Transmission type	VAR	Unsigned8	rw	Default type = 255 (asynchronous)
	03 _h	Inhibit time	VAR	Unsigned16	rw	Default = 0
	05 _h	Event timer	VAR	Unsigned16	rw	Default = 0
1403 _h		4th R_PDO parameter	REC			4th receive PDO parameter
	00 _h	Largest sub-index	VAR	Unsigned8	ro	Largest sub-index supported» 05 _h
	01 _h	COB-ID used	VAR	Unsigned32	rw	COB-ID used: 500 _h + Node ID
	02 _h	Transmission type	VAR	Unsigned8	rw	Default type = 255 (asynchronous)
	03 _h	Inhibit time	VAR	Unsigned16	rw	Default = 0
	05 _h	Event timer	VAR	Unsigned16	rw	Default = 0
1600 _h		1st R_PDO mapping	REC		ro	PDO mapping for R_PDO1, settings
	00 _h	# of mapped objects	VAR	Unsigned8	rw	Number of mapped objects, range 1 – 64
	01 _h - 08 _h	Application Objects	VAR	Unsigned32	rw	R_PDO1 mapping application objects
1601 _h		2nd R_PDO mapping	REC		ro	PDO mapping for R_PDO2, settings
	00 _h	# of mapped objects	VAR	Unsigned8	rw	Number of mapped objects, range 1 – 64
	01 _h - 08 _h	Application Objects	VAR	Unsigned32	rw	R_PDO2 mapping application objects
1602 _h		3rd R_PDO mapping	REC		ro	PDO mapping for R_PDO3, settings
	00 _h	# of mapped objects	VAR	Unsigned8	rw	Number of mapped objects, range 1 – 64
	01 _h - 08 _h	Application Objects	VAR	Unsigned32	rw	R_PDO3 mapping application objects
1603 _h		4th R_PDO mapping	REC		ro	PDO mapping for R_PDO4, settings
	00 _h	# of mapped objects	VAR	Unsigned8	rw	Number of mapped objects, range 1 – 64
	01 _h - 08 _h	Application Objects	VAR	Unsigned32	rw	R_PDO4 mapping application objects
1800 _h		1st T_PDO parameter	REC			1st transmit PDO parameter
	00 _h	Largest sub-index	VAR	Unsigned8	ro	Largest sub-index supported» 05 _h
	01 _h	COB-ID used	VAR	Unsigned32	rw	COB-ID used: 180 _h + Node ID
	02 _h	Transmission type	VAR	Unsigned8	rw	Default type = 255 (asynchronous)
	03 _h	Inhibit time	VAR	Unsigned16	rw	Default = 0
	05 _h	Event timer	VAR	Unsigned16	rw	Default = 0
1801 _h		2nd T_PDO parameter	REC			2nd transmit PDO parameter
	00 _h	Largest sub-index	VAR	Unsigned8	ro	Largest sub-index supported» 05 _h
	01 _h	COB-ID used	VAR	Unsigned32	rw	COB-ID used: 280 _h + Node ID
	02 _h	Transmission type	VAR	Unsigned8	rw	Default type = 255 (asynchronous)
	03 _h	Inhibit time	VAR	Unsigned16	rw	Default = 0
	05 _h	Event timer	VAR	Unsigned16	rw	Default = 0

Index	Sub-index	Name	Obj. code	Data type	Access	Description
1802 _h		3rd T_PDO parameter	REC			3rd transmit PDO parameter
	00 _h	Largest sub-index	VAR	Unsigned8	ro	Largest sub-index supported» 05 _h
	01 _h	COB-ID used	VAR	Unsigned32	rw	COB-ID used: 380 _h + Node ID
	02 _h	Transmission type	VAR	Unsigned8	rw	Default type = 255 (asynchronous)
	03 _h	Inhibit time	VAR	Unsigned16	rw	Default = 0
	05 _h	Event timer	VAR	Unsigned16	rw	Default = 0
1803 _h		4th T_PDO parameter	REC			4th transmit PDO parameter
	00 _h	Largest sub-index	VAR	Unsigned8	ro	Largest sub-index supported» 05 _h
	01 _h	COB-ID used	VAR	Unsigned32	rw	COB-ID used: 480 _h + Node ID
	02 _h	Transmission type	VAR	Unsigned8	rw	Default type = 255 (asynchronous)
	03 _h	Inhibit time	VAR	Unsigned16	rw	Default = 0
	05 _h	Event timer	VAR	Unsigned16	rw	Default = 0
1A00 _h		1st T_PDO mapping	REC		ro	PDO mapping for T_PDO1, settings
	00 _h	# of mapped objects	VAR	Unsigned8	rw	Number of mapped objects, range 1 – 64
	01 _h - 08 _h	Application Objects	VAR	Unsigned32	rw	T_PDO1 mapping application objects
1A01 _h		2nd T_PDO mapping	REC		ro	PDO mapping for T_PDO2, settings
	00 _h	# of mapped objects	VAR	Unsigned8	rw	Number of mapped objects, range 1 – 64
	01 _h - 08 _h	Application Objects	VAR	Unsigned32	rw	T_PDO2 mapping application objects
1A02 _h		3rd T_PDO mapping	REC		ro	PDO mapping for T_PDO3, settings
	00 _h	# of mapped objects	VAR	Unsigned8	rw	Number of mapped objects, range 1 – 64
	01 _h - 08 _h	Application Objects	VAR	Unsigned32	rw	T_PDO3 mapping application objects
1A03 _h		4th T_PDO mapping	REC		ro	PDO mapping for T_PDO4, settings
	00 _h	# of mapped objects	VAR	Unsigned8	rw	Number of mapped objects, range 1 – 64
	01 _h - 08 _h	Application Objects	VAR	Unsigned32	rw	T_PDO4 mapping application objects

8.3 Overview of manufacturer specific objects group 2000_h

Index	Sub	Name	Obj. code	Data type	Access	PDO	Description
2000 _h		Configure GPIO	ARR				Configure the general purpose I/O points
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 05 _h
	01 _h	Reserved	VAR	Unsigned8	rw		Configure the I/O point as an output or input
	02 _h	Reserved	VAR	Unsigned8	rw		Configure the I/O point as sourcing or sinking
	03 _h	Reserved	VAR	Unsigned8	rw		Configure as both sink/source or source only
	04 _h	Configure polarity in	VAR	Unsigned8	rw		Configure input logic polarity
	05 _h	Reserved	VAR	Unsigned8	rw		Configure output logic polarity
2002 _h		Configure digital inputs	ARR				Configure the functions of inputs
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 04 _h
	01 _h	Define as Home switch	VAR	Unsigned8	rw		Configure input as homing switch
	02 _h	Define as positive limit	VAR	Unsigned8	rw		Configure input as positive limit switch
	03 _h	Define as negative limit	VAR	Unsigned8	rw		Configure input as negative limit switch
2004 _h	04 _h	Define as inhibit switch	VAR	Unsigned8	rw		Configure input as inhibit switch (see 2007 _h)
		Input mask	ARR				Configure input filter mask
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 08 _h
2006 _h	01 _h - 08 _h	Input filter mask	VAR	Unsigned8	rw		Defines inputs to apply filtering (see 2006 _h)
		Input filter time	ARR				Configure input filter time
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 08 _h
2007 _h	01 _h - 08 _h	Input filter time	VAR	Unsigned8	rw		Defines inputs filter time in ms
		Inhibit switch	ARR				Configure inhibit switch
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 01 _h
2008 _h	01 _h	Input switch action	VAR	Unsigned8	rw		Defines the action of the inhibit switch
		Configure digital outputs	ARR				Configure output functions
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 02 _h
	01 _h	Brake output defined	VAR	Unsigned8	rw		Defines the output(s) used for braking
2010 _h	02 _h	Target reached output	VAR	Unsigned8	rw		Defines the output used to indicate target reached
		Analog input configuration	ARR				Configure the analog input
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 03 _h
	01 _h	Analog input read value	VAR	Unsigned16	ro	T_PDO	Analog input value
	02 _h	Analog input scale	VAR	Unsigned8	rw		Sets the mode as 0 - 5V, 0 - 10V or 0 - 20mA
2014 _h	03 _h	Analog input filter	VAR	Unsigned8	rw		Defines the filtering for the analog input
		Aux-power monitoring	ARR				Monitor the level of the Aux-power input
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 03 _h
	01 _h	Aux-power voltage	VAR	Unsigned8	ro	T_PDO	Read Aux-power voltage value
	02 _h	Aux-power low warning	VAR	Unsigned8	ro		Read Aux-power low level warning
2015 _h	03 _h	Aux-power high warning	VAR	Unsigned8	ro		Read Aux-power high level warning
		Input voltage monitoring	ARR				Monitors the level of the +VDC input voltage
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 03 _h
	01 _h	Input +V	VAR	Unsigned8	ro	T_PDO	Read Input +V voltage value
	02 _h	Input +V low warning	VAR	Unsigned8	ro		Read Input +V low level warning
	03 _h	Input +V high warning	VAR	Unsigned8	ro		Read Input +V high level warning

Index	Sub	Name	Obj. code	Data type	Access	PDO	Description
2018 _h		Board Temperature	ARR				Set the board temperature parameters
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 03 _h
	01 _h	Board temperature	VAR	Integer8	ro	T_PDO	Board temperature reading
	02 _h	Set temperature warning	VAR	Integer8	rw		Set board temperature warning threshold
	03 _h	Set temperature fault	VAR	Integer8	rw		Set board temperature fault threshold
2019 _h		Bridge Temperature	ARR				Set the bridge temperature parameters
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 03 _h
	01 _h	Bridge temperature	VAR	Integer8	ro	T_PDO	Bridge temperature reading
	02 _h	Set temperature warning	VAR	Integer8	rw		Set bridge temperature warning threshold
	03 _h	Set temperature fault	VAR	Integer8	rw		Set board temperature fault threshold
2020 _h		Set temperature fault	VAR	Integer8	rw		Set bridge temperature fault threshold
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 02 _h
	01 _h	Limit reached flag	VAR	Unsigned8	rw		Indicates type of limit reached
	02 _h	Limit reached mask	VAR	Unsigned8	rw		Defines limits to act upon
2022 _h		Software limit	ARR				Actual position software limit
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 02 _h
	01 _h	Actual negative limit	VAR	Integer32	rw		Actual negative limit
	02 _h	Actual positive limit	VAR	Integer32	rw		Actual positive limit
2030 _h		Output bridge polarity	VAR	Integer8	rw		Defines the polarity of the output bridge
2031 _h		Unit options	VAR	Unsigned8	rw		Enable encoder, capture/trip functions
2033 _h		Capture input parameters	REC				Capture input parameters
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 04 _h
	01 _h	Capture input control	VAR	Unsigned8	rw		Enables the capture input
	02 _h	Capture input flag	VAR	Unsigned8	rw		Displays the status of a position capture
	03 _h	Capture input filter	VAR	Unsigned8	rw		Sets the filtering for the capture input
	04 _h	Captured position	VAR	Integer32	ro	T_PDO	Stores the captured position
2034 _h		Bridge on settle time	ARR				Settling time after bridge power on
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 01 _h
	01 _h	Bridge settle time	VAR	Unsigned8	rw		Bridge settling time in msec
2035 _h		Brake settle allow time					Settling time after brake on/off
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 02 _h
	01 _h	Brake on settle time	VAR	Unsigned8	rw		Brake on settling time in msec
	02 _h	Brake off settle time	VAR	Unsigned8	rw		Brake off settling time in msec
2036 _h		Hold current delay time	VAR	Unsigned16	rw		Defines time in msec to transition to hold current following cessation of motion
2037 _h		Bridge on to encoder settle time	VAR	Unsigned16	rw		Time between switching into operation enable to resynching the encoder position
2038 _h		Trip output configuration	REC				Trip output parameters
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 03 _h
	01 _h	Trip output control	VAR	Unsigned16	rw		Controls logic and trip points
	02 _h	1st position of a series	VAR	Integer32	rw		First trip position
	03 _h	Multiple trip point spacing	VAR	Integer32	rw		Defines the spacing between subsequent trip points

Index	Sub	Name	Obj. code	Data type	Access	PDO	Description
2098 _h		Homing configuration	VAR	Unsigned8	rw		Defines the counter status following a home
2204 _h		Run current	VAR	Unsigned8	rw		Sets the motor run current percent
2205 _h		Hold current	VAR	Unsigned8	rw		Sets the motor hold current percent
2211 _h		Position present point target	VAR	Integer32	ro		Position present point target
2212 _h		Position final point target	VAR	Integer32	ro		Position final point target
2221 _h		Following Error	ARR				Following Error reaction code
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 01 _h
	01 _h	Reaction code	VAR	Unsigned8	rw		Following error reaction code
2401 _h		Gen Purpose user variable	VAR	Unsigned8	rw		May be used to store 8 bits of data
2504 _h		SEM options	VAR	Unsigned8	rw		SEM control options for compatibility
2701 _h		hMTechnology enable	VAR	Unsigned8	rw		Enable/disable hMT control (closed loop only)
2702 _h		Make up mode	VAR	Unsigned8	rw		Defines hMT make up mode (closed loop only)
2703 _h		Make up velocity	VAR	Unsigned32	rw		Defines the velocity for make up (closed loop only)
2704 _h		Torque Speed	VAR	Unsigned8	rw		Defines the velocity for torque mode (closed loop only)
2710 _h		Locked Rotor Timeout	VAR	Unsigned8	rw		Defines the time period for a locked rotor condition to assert. (closed loop only)
2740 _h		hMTechnology control	VAR	Unsigned8	rw	R_PDO	Defines the control parameters for hMTechnology. (closed loop only)
2741 _h		hMTechnology status (filtered)	VAR	Unsigned8	ro	T_PDO	Reads the hMT status as filtered by 2743 _h (closed loop only)
2742 _h		hMTechnology status (unfiltered)	VAR	Unsigned8	ro		Reads the hMT status unfiltered (closed loop only)
2743 _h		hMTechnology status filter	VAR	Unsigned8	rw		Determines which bits of the status byte are filtered in 2741 _h

8.4 Overview of assignment objects group 6000_h

Index	Sub	Name	Obj. code	Data type	Access	PDO	Description
6007 _h		Abort connection opcode	VAR	Integer16	rw		Controls the process for abort connection
603F _h		Error code	VAR	Unsigned16	ro	T_PDO	Stores the last error
6040 _h		Control word	VAR	Unsigned16	rw	R_PDO	Control word
6041 _h		Status word	VAR	Unsigned16	ro	T_PDO	Status word
605A _h		Quick stop option code	VAR	Integer16	rw		Defines the method for quick stop
605B _h		Shutdown option code	VAR	Integer16	rw		Defines the method for shutdown
605C _h		Disable operation opcode	VAR	Integer16	rw		Defines the method for disable operation
605D _h		Halt operation opcode	VAR	Integer16	rw		Defines the method for halt operation
605E _h		Fault reaction opcode	VAR	Integer16	rw		Defines the reaction to a fault
6060 _h		Modes of operation	VAR	Integer8	rw	R_PDO	Set the mode of operation
6061 _h		Modes of operation display	VAR	Integer8	ro	T_PDO	read the mode of operation
6062 _h		Position demand value	VAR	Integer32	ro	T_PDO	Read the motor position in user units
6063 _h		Position actual value	VAR	Integer32	ro	T_PDO	Read the motor position
6064 _h		Position actual value	VAR	Integer32	ro	T_PDO	Read the motor position
6065 _h		Following error window	VAR	Unsigned32	rw		Defines range of tolerated positions symetrical to 6062 _h
6066 _h		Following error window time	VAR	Unsigned16	rw		Defines the timeout for the next error window
6067 _h		Position window	VAR	Unsigned32	rw		Defines accepted positions relative to target
6068 _h		Position window timeout	VAR	Unsigned16	rw		Defines time to indicate target reached
606C _h		Velocity actual value	VAR	Integer32	ro	T_PDO	Actual velocity of the motor
6071 _h		Target torque	VAR	Integer16	rw	R_PDO	Defines the target torque for Profile Torque mode
6077 _h		Torque actual value	VAR	Integer16	ro	T_PDO	Actual torque value for Profile Torque
607A _h		Profiled target position	VAR	Integer32	rw	R_PDO	Defines target position for absolute or relative move
607C _h		Homing offset	VAR	Integer32	rw		Defines offset from homing zero position
607E _h		Polarity	VAR	Unsigned8	rw	R_PDO	Sets polarity for position/speed commands
6081 _h		Profile velocity	VAR	Unsigned32	rw	R_PDO	Sets the velocity for the profile position motion
6082 _h		End velocity	VAR	Unsigned32	rw	R_PDO	Sets the terminal (max) velocity
6083 _h		Profile acceleration	VAR	Unsigned32	rw	R_PDO	Sets the acceleration for profile position and profile velocity motion
6084 _h		Profile deceleration	VAR	Unsigned32	rw	R_PDO	Sets the deceleration for profile position and profile velocity motion
6085 _h		Quick stop deceleration	VAR	Unsigned32	rw		Sets the deceleration for a quick stop state
6086 _h		Motion profile type	VAR	Integer16	rw	R_PDO	Defines method by which profile motion is evaluated
6087 _h		Torque slope	VAR	Unsigned32	rw		Defines the torque ramp for Profile Torque mode
608F _h		Position encoder resolution	ARR				Defines relation between motor revolution and position increments
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 02 _h
	01 _h	Resolution numerator	VAR	Unsigned32	rw		# of encoder increments
	02 _h	Resolution denominator	VAR	Unsigned32	rw		# of motor revolutions

Index	Sub	Name	Obj. code	Data type	Access	PDO	Description
6092 _h		Factor group feed and driveshaft	ARR				Defines relation between feed user units and pdrive shaft revolutions
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 02 _h
	01 _h	Feed numerator	VAR	Unsigned32	rw		# of feed increments
	02 _h	Driveshaft denominator	VAR	Unsigned32	rw		# of driveshaft revolutions
6098 _h		Homing method	VAR	Integer8	rw		Defines the method for homing operation
6099 _h		Homing speed	ARR				Defines the high and low speeds for homing
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 02 _h
	01 _h	Homing speed fast	VAR	Unsigned32	rw		Defines the high speed for homing
	02 _h	Homing speed slow	VAR	Unsigned32	rw		Defines the low speed for homing
60C2 _h		Interpolated position time period	REC				Defines time for interpolation position trajectory.
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 02 _h
	01 _h	Interpoltion period	VAR	Unsigned8	rw		Interpoltion time period
	02 _h	Interpolation factor	VAR	Integer8	rw		Interpolation factor
60F8 _h		Maximum slippage	VAR	Integer32	rw		Maximum slippage
60FD _h		Digital inputs	VAR	Unsigned32	ro	T_PDO	Reads the state of digital inputs
60FE _h		Digital outputs	ARR				Sets the state of digital outputs
	00 _h	Number of entries	VAR	Unsigned8	ro		Number of entries = 01 _h
	01 _h	Digital outputs	VAR	Unsigned32	rw	R_PDO	Reads the state of digital inputs
60FF _h		Target velocity	VAR	Integer32	rw	R_PDO	Defines the target velocity
6402 _h		Motor types	VAR	Unsigned16	ro		Motor type = 9: Stepper motor
6502 _h		Supported drive modes	VAR	Unsigned32	ro		Profile position, profile velocity, homing

8.5 Details of object group 1000_h

8.5.1 1000_h Device type

The object specifies the device profile used as well as the device type.

Object description

Index	1000 _h
Name	Device type
Object code	VAR
Data type	Unsigned32

Value description

Sub-index	00 _h , device type
Meaning	Device type and profile
Access	Read only
PDO mapping	—
Value range	—
Default value	0044 0192 _h
Category	—

Bit coding sub-index 00_h

Bit	Access	Value	Meaning
31-16	ro	0044 _h	Stepper motor
15-0	ro	0192 _h	Device profile DSP402

8.5.2 1001_h Error register

The object specifies the error of the device. The detailed cause of error can be determined with the object `predefined error field` (1003_h) and - for reasons of compatibility with devices with other fieldbus profiles - with the object `error code` (603F_h).

Errors are signaled by an EMCY message as soon as they occur.

Object description

Index	1001 _h
Name	Error register
Object code	VAR
Data type	Unsigned8

Value description

Sub-index	00 _h , error register
Meaning	Error register
Access	Read only
PDO mapping	—
Value range	—
Default value	—
Category	—

Bit coding sub-index 00_h

Bit	Access	Value	Meaning
0	ro	—	Error (generic error)
1	ro	—	Reserved
2	ro	—	Reserved
3	ro	—	Temperature
4	ro	—	Communication profile (communication error)
5	ro	—	Reserved
6	ro	—	Reserved
7	ro	—	Manufacturer specific

8.5.3 1003_h Pre-defined error field

- The object contains the latest error messages that were shown as EMCY messages.
- The sub-index 00h entry contains the number of saved error messages.
 - The current error message is stored at sub-index 01h, older messages are moved to higher sub-index entries.
 - Writing 0 to sub-index 00h resets the error list.

Object description

Index	1003 _h
Name	Pre-defined error field
Object code	ARRAY
Data type	Unsigned32

Value description

Sub-index	00 _h , number of errors
Meaning	Number of error entries
Access	Read-write
PDO mapping	—
Value range	0 ... 4
Default value	0
Category	—
Sub-index	01 _h – 04 _h , error field
Meaning	Error number
Access	Read only
PDO mapping	—
Value range	—
Default value	0
Category	—

Bit coding sub-index 00_h ... 04_h

Bytes 0 ... 15: error code. Bytes 16 ... 31 additional error information, not assigned in the device.

8.5.4 1005_h COB ID SYNC message

The object specifies the COB ID of the SYNC object and determines whether a device sends or receives SYNC messages.

The device can only receive SYNC messages.

For synchronization, a device in the network must send SYNC objects.

The COB ID can be changed in the NMT state “Pre-Operational”

Object description	Index	1005 _h
	Name	COB ID SYNC
	Object code	VAR
	Data type	Unsigned32
Value description	Sub-index	00 _h , COB ID SYNC
	Meaning	Identifier of the synchronization object
	Access	Read-write
	PDO mapping	—
	Value range	0...4294967295
	Default value	0000 0080 _h
	Category	Yes

Bit coding sub-index 00 _h	Bit	Access	Value	Meaning
	31	ro	0 _b	
	30	ro	0 _b	
	29	ro	0 _b	
	28-11	ro	0000 _h	
	10-7	rw	0001 _b	
	6-0	ro	7F _h	

8.5.5 1007_h Sync window length

Contains the length of the time window for synchronous PDOs in microseconds.

Object description

Index	1007 _h
Name	Sync window length
Object code	VAR
Data type	Unsigned32

Value description

Sub-index	00 _h , Sync window length
Meaning	Timing for sync PDOs
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	0000 0000 _h
Category	Yes

8.5.6 1008_h Mfg. device name

Provides the name of the device as given by the manufacturer.

Object description

Index	1008 _h
Name	Manufacturer device name
Object code	VAR
Data type	Visible String

Value description

Sub-index	00 _h , Manufacturer device name
Meaning	Manufacturer device name
Access	Read only
PDO mapping	—
Value range	Visible String
Default value	CANopen Lexium MDrive Motion Control Node
Category	—

8.5.7 1009_h Mfg. hardware version

Provides the hardware version of the device as given by the manufacturer.

Object description

Index	1009 _h
Name	Manufacturer hardware version
Object code	VAR
Data type	Visible String

Value description

Sub-index	00 _h , Manufacturer hardware version
Meaning	Manufacturer hardware version
Access	Read only
PDO mapping	—
Value range	Visible String
Default value	V1.00
Category	—

8.5.8 100A_h Mfg. software version

Provides the software version of the device as given by the manufacturer.

Object description

Index	100A _h
Name	Manufacturer software version
Object code	VAR
Data type	Visible String

Value description

Sub-index	00 _h , Manufacturer software version
Meaning	Manufacturer software version
Access	Read only
PDO mapping	—
Value range	Visible String
Default value	V5.48
Category	—

8.5.9 100C_h Guard time

The object specifies the time span for connection monitoring (Node Guarding) of an NMT slave.

The time span for connection monitoring of an NMT master results from the time span “guard time” multiplied by the factor “life time”, object `Life time factor(100Dh)`.

The time span can be changed in the NMT state “Pre-Operational”.

Object description

Index	100C _h
Name	Guard time
Object code	VAR
Data type	Unsigned16

Value description

Sub-index	00 _h , Guard time
Meaning	Guard time
Access	Read-write
PDO mapping	—
Value range	0...65535
Default value	0000 _h
Category	Yes

8.5.10 100D_h Life time factor

The object specifies the factor that, together with the time span “guard time”, results in the time interval for connection monitoring of an NMT master. Within this period, the NMT slave device expects a monitoring request via Node Guarding from the NMT master.

life time = guard time * life time factor

The value “0” deactivates monitoring of the NMT master.

If there is no connection monitoring through the NMT master during the time interval “life time”, the device signals an error and switches to the operating state Fault.

The time factor can be changed in the NMT state “Pre-Operational”. The time span “guard time” is set with the object `Guard time (100Ch)`.

Object description

Index	100D _h
Name	Life time factor
Object code	VAR
Data type	Unsigned8

Value description

Sub-index	00 _h , Life time factor
Meaning	Life time factor
Access	Read-write
PDO mapping	—
Value range	0...255
Default value	00 _h
Category	Yes

8.5.10 1010_h Store parameters

This object supports the saving of parameters in non volatile memory. By read access the device provides information about its saving capabilities. Several parameter groups are distinguished:

- Sub-Index 0 contains the largest Sub-Index that is supported.
- Sub-Index 1 refers to all parameters that can be stored on the device.
- Sub-Index 2 refers to communication related parameters (Index 1000_h - 1FFF_h manufacturer specific communication parameters).
- Sub-Index 3 refers to application related parameters (Index 6000_h - 9FFF_h manufacturer specific application parameters).
- Sub-index 4 refers to manufacturer specific parameters.

In order to avoid storage of parameters by mistake, storage is only executed when a specific signature is written to the appropriate Sub-Index. The signature is "save".

Signature				
ISO 8859	MSB			LSB
ASCII	e	v	a	s
hex	65h	76h	61h	73h

Figure 8.1: Storage write access signature

On reception of the correct signature in the appropriate sub-index the device stores the parameter and then confirms the SDO transmission (initiate download response). If the storing failed, the device responds with an Abort SDO Transfer (abort code: 0606 0000_h).

If a wrong signature is written, the device refuses to store and responds with Abort SDO Transfer (abort code: 0800 002x_h).

On read access to the appropriate Sub-Index the device provides information about its storage functionality with the following format:

Unsigned32			
	MSB		
bits	31 ... 2	1	0
	Reserved (=0)	0/1	0/1

Figure 8.2: Storage read access structure

Bit	Value	Meaning
31 ... 2	0	Reserved (=0)
1	0	Device does not save the parameters autonomously
	1	Device does save the parameters autonomously
2	0	Device does not save the parameters on command
	1	Device does save the parameters on command

Table 8.3: Structure of read access

Autonomous saving means that a device stores the storable parameters in a non-volatile manner without user request.

Object description

Index	1010 _h
Name	Store parameters
Object code	Array
Data type	Unsigned32

Value description

Sub-index	00 _h , Largest supported sub-index
Meaning	Largest supported sub-index
Access	Read only
PDO mapping	—
Value range	1 _h - 4 _h
Default value	4 _h
Category	—

Sub-index	01 _h , Save all parameters
Meaning	Save all parameters
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	—
Category	—

Sub-index	02 _h , Save communication parameters
Meaning	Save communication parameters
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	—
Category	—

Sub-index	03 _h , Save application parameters
Meaning	Save application parameters
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	—
Category	—

Sub-index	04 _h , Save manufacturer parameters
Meaning	Save manufacturer parameters
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	—
Category	—

8.5.11 1011_h Restore default parameters

With this object the default values of parameters according to the communication or device profile are restored. By read access the device provides information about its capabilities to restore these values. Several parameter groups are distinguished:

- 1) Sub-Index 0 contains the largest Sub-Index that is supported.
- 2) Sub-Index 1 refers to all parameters that can be restored. Sub-Index 2 refers to communication related parameters (Index 1000_h - 1FFF_h manufacturer specific communication parameters).
- 3) Sub-Index 3 refers to application related parameters (Index 6000_h - 9FFF_h manufacturer specific application parameters).
- 4) At Sub-Index 4 - 127 manufacturers may restore their individual choice of parameters.
- 5) Sub-Index 128 - 254 are reserved for future use.

In order to avoid the restoring of default parameters by mistake, restoring is only executed when a specific signature is written to the appropriate sub-index. The signature is "load".

Signature				
ISO 8859	MSB			LSB
ASCII	d	a	o	l
hex	64h	61h	6Fh	6Ch

Figure 8.3: Restore default parameters write access signature.

On reception of the correct signature in the appropriate sub-index the device restores the default parameters and then confirms the SDO transmission (initiate download response). If the restoring failed, the device responds with an Abort SDO Transfer (abort code: 0606 0000_h). If a wrong signature is written, the device refuses to restore the defaults and responds with an Abort SDO Transfer (abort code: 0800 002x_h).

The default values are set valid after the device is reset (reset node for sub-index 1_h - 4_h, reset communication for sub-index 2_h) or power cycled.

On read access to the appropriate sub-index the device provides parameter restoring capability with the following format:

Unsigned32	
	MSB
bits	31 ... 1
	Reserved (=0)
	LSB
	0
	0/1

Figure 8.4: Restore default parameters write access structure.

Bit	Value	Meaning
31 ... 1	0	Reserved (=0)
1	0	Device does not restore the default parameters
	1	Device does restore the default parameters

Table 8.4: Structure of write access

Object description

Index	1011 _h
Name	Restore default parameters
Object code	Array
Data type	Unsigned32

Value description

Sub-index	00 _h , Largest supported sub-index
Meaning	Largest supported sub-index
Access	Read only
PDO mapping	—
Value range	1 _h - 4 _h
Default value	4 _h
Category	—

Sub-index	01 _h , Restore all parameters
Meaning	Restore all parameters
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	—
Category	—

Sub-index	02 _h , Restore communication parameters
Meaning	Restore communication parameters
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	—
Category	—

Sub-index	03 _h , Restore application parameters
Meaning	Restore application parameters
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	—
Category	—

Sub-index	04 _h , Restore manufacturer parameters
Meaning	Restore manufacturer parameters
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	—
Category	—

8.5.12 1012_h COB-ID time stamp object

Index 1012_h defines the COB-ID of the time-stamp object (TIME). Further, it defines whether the device consumes the TIME or whether the device generates the TIME.




Figure 8.5: Structure of the COB-ID TIME entry

Bit	Value	Meaning
31 (MSB)	0	Device does not consume the TIME message
	1	Device consumes the TIME message
30	0	Device does not produce the TIME message
	1	Device produces the TIME message
29	0	11-bit ID (CAN 2.0A)
	1	29-bit ID (CAN 2.0B)
28 ... 11	0	If bit 29=0
	X	if bit 29=1: bits 28 ... 11 of 29 bit TIME-COB-ID
10 ... 0 (LSB)	X	Bits 10 ... 0 of TIME-COB-ID

Table 8.5: Description of the TIME COB-ID entry

Bits 29, 30 may be static (not changeable). If a device is not able to generate TIME messages, an attempt to set bit 30 is responded with an abort message (abort code: 0609 0030_h). Devices supporting the standard CAN frame type only, an attempt to set bit 29 is responded with an abort message (abort code: 0609 0030_h). It is not allowed to change Bits 0-29, while the object exists (Bit 30=1).

Object description

Index	1012 _h
Name	COB-ID time stamp message
Object code	VAR
Data type	Unsigned32

Value description

Sub-index	00h, COB-ID time stamp message
Meaning	COB-ID time stamp message
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	0000 0100 _h
Category	—

8.5.13 1014_h COB-ID emergency error object

Index 1014h defines the COB-ID of the Emergency Object (EMCY).




Figure 8.6: Structure of the EMCY identifier entry

Bit	Value	Meaning
31 (MSB)	0	EMCY exists / is valid
	1	EMCY does not exist / is not valid
30	0	Reserved (always 0)
29	0	11-bit ID (CAN 2.0A)
	1	29-bit ID (CAN 2.0B)
28 ... 11	0	If bit 29=0
	X	if bit 29=1: bits 28 ... 11 of 29 bit COB-ID
10 ... 0 (LSB)	X	Bits 10 ... 0 of COB-ID

Table 8.6: Description of the COB-ID entry

Devices supporting the standard CAN frame type only, an attempt to set bit 29 is responded with an abort message (abort code: 0609 0030_h). It is not allowed to change Bits 0-29, while the object exists (Bit 31=0).

Object description

Index	10142 _h
Name	COB-ID emergency message
Object code	VAR
Data type	Unsigned32

Value description

Sub-index	00h, COB-ID emergency message
Meaning	COB-ID emergency message
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	0080 _h + node ID
Category	—

8.5.14 1015_h Inhibit time EMCY object

The inhibit time for the EMCY message can be adjusted via this entry. If this entry exists it must be writable in the object dictionary. The time has to be a multiple of 100µs

Object description

Index	1015 _h
Name	Inhibit tme EMCY
Object code	VAR
Data type	Unsigned16

Value description

Sub-index	00h, Inhibit tme EMCY
Meaning	Inhibit tme EMCY
Access	Read-write
PDO mapping	—
Value range	Unsigned16
Default value	0000 _h
Category	—

8.5.15 1017_h Producer heartbeat time

The producer heartbeat time defines the cycle time of the heartbeat. The producer heartbeat time is 0 if it not used. The time has to be a multiple of 1ms.

Object description

Index	1017 _h
Name	Producer heartbeat time
Object code	VAR
Data type	Unsigned16

Value description

Sub-index	00h, Producer heartbeat time
Meaning	Producer heartbeat time
Access	Read-write
PDO mapping	—
Value range	Unsigned16
Default value	0000 _h
Category	—

8.5.16 1018_h Identity object

The object at index 1018_n contains general information about the device. The Vendor ID (sub-index 1_n) contains a unique value allocated to each manufacturer.

The manufacturer-specific Product code (sub-index 2_h) identifies a specific device version. The manufacturer-specific Revision number (sub-index 3_h) consists of a major revision number and a minor revision number. The major revision number identifies a specific CANopen behaviour. If the CANopen functionality is expanded, the major revision has to be incremented. The minor revision number identifies different versions with the same CANopen behaviour.




Figure 8.7: Structure of the revision number

The manufacturer-specific serial number (sub-index 4h) identifies a specific device.

Object description

Index	1018 _h
Name	Identity object
Object code	Array
Data type	Unsigned32

Value description

Sub-index	00 _h , Largest supported sub-index
Meaning	Largest supported sub-index
Access	Read only
PDO mapping	—
Value range	1 _h - 4 _h
Default value	4 _h
Category	—

Sub-index	01 _h , Vendor ID
Meaning	Vendor ID
Access	Read-only
PDO mapping	—
Value range	Unsigned32
Default value	0000 021B _h
Category	—

Sub-index	02 _h , Product code
Meaning	Product code
Access	Read only
PDO mapping	—
Value range	Unsigned32
Default value	0000 0000 _h
Category	—

Sub-index	03 _h , Revision number
Meaning	Revision number
Access	Read only
PDO mapping	—
Value range	Unsigned32
Default value	0000 0507 _h
Category	—

Sub-index	04 _h , Serial number
Meaning	Serial number
Access	Read only
PDO mapping	—
Value range	Unsigned32
Default value	—
Category	—

8.5.18 1400 – 1403_h Receive PDO communications parameter

Contains the communication parameters for the PDOs the device is able to receive. The type of the PDO communication parameter (20h) is described in Section 9.5.4 of CiA DS-301: CANopen Application Layer and Communications Profile. The sub-index 0h contains the number of valid entries within the communication record. Its value is at least 2. If inhibit time supported the value is 3. At sub-index 1h resides the COB-ID of the PDO. This entry has been defined as UNSIGNED32 in order to cater for 11-bit CAN Identifiers (CAN 2.0A) as well as for 29-bit CAN identifiers (CAN 2.0B).




Figure 8.8: Structure of the PDO COB-ID entry

Bit	Value	Meaning
31 (MSB)	0	PDO Exists/Is Valid
	1	PDO Does Not Exist/Is Not Valid
30	0	RTR is Allowed on this PDO
	1	RTR is Not Allowed on this PDO
29	0	11-bit ID (CAN 2.0A)
	1	29-bit ID (CAN 2.0B)
28 ... 11	0	If bit 29=0
	X	if bit 29=1: bits 28 ... 11 of 29 bit COB-ID
10 ... 0 (LSB)	X	Bits 10 ... 0 of COB-ID

Table 8.7: Description of the PDO COB-ID entry

The PDO valid/not valid allows to select which PDOs are used in the operational state. There may be PDOs fully configured (e.g. by default) but not used, and therefore set to “not valid” (deleted). The feature is necessary for devices supporting more than 4 RPDOs or 4 TPDOs, because each device has only default identifiers for the first four RPDOs/TPDOs. Devices supporting the standard CAN frame type only or do not support Remote Frames, an attempt to set bit 29 to 1 or bit 30 to 0 is responded with an abort message (abort code: 0609 0030_h). It is not allowed to change bit 0-29 while the PDO exists (Bit 31=0).

The transmission type (sub-index 2) defines the transmission/reception character of the PDO. On an attempt to change the value of the transmission type to a value that is not supported by the device an abort message (abort code: 0609 0030_h) is generated.

Transmission type	PDO transmission				
	cyclic	acyclic	sync	async	RTR only
0		X	X		
1 – 240	X		X		
241 – 251	Reserved				
252			X		X
253				X	X
254				X	
255				X	

Table 8.8: Description of the PDO COB-ID entry

Synchronous (transmission types 0-240 and 252) means that the transmission of the PDO shall be related to the SYNC object. Preferably the devices use the SYNC as a trigger to output or actuate based on the previous synchronous Receive PDO respectively to update the data transmitted at the following synchronous Transmit PDO. Details of this mechanism depend on the device type and are defined in the device profile if applicable.

Asynchronous means that the transmission of the PDO is not related to the SYNC object. A transmission type of zero means that the message shall be transmitted synchronously with the SYNC object but not periodically. A value between 1 and 240 means that the PDO is transferred synchronously and cyclically. The transmission type indicating the number of SYNC which are necessary to trigger PDO transmissions.

Receive PDOs are always triggered by the following SYNC upon reception of data independent of the transmission types 0 - 240. The transmission types 252 and 253 mean that the PDO is only transmitted on remote transmission request. At transmission type 252, the data is updated (but not sent) immediately after reception of the SYNC object.

At transmission type 253 the data is updated at the reception of the remote transmission request (hardware and software restrictions may apply). These value are only possible for T_PDOs.

For T_PDOs transmission type 254 means, the application event is manufacturer specific (manufacturer specific part of the Object Dictionary), transmission type 255 means, the application event is defined in the device profile. R_PDOs with that type trigger the update of the mapped data with the reception.

Sub-index 3_h contains the inhibit time. This time is a minimum interval for PDO transmission. The value is defined as multiple of 100µs. It is not allowed to change the value while the PDO exists (Bit 31 of sub-index 1 is 0).

Sub-index 4_h is reserved. It does not have to be implemented, in this case read or write access leads to Abort SDO Transfer (abort code: 0609 0011_h).

In mode 254/255 additionally an event time can be used for T_PDO. If an event timer exists for a T_PDO (value not equal to 0) the elapsed timer is considered to be an event. The event timer elapses as multiple of 1 ms of the entry in sub-index 5_h of the T_PDO. This event will cause the transmission of this T_PDO in addition to otherwise defined events. The occurrence of the events set the timer. Independent of the transmission type the R_PDO event timer is used recognize the expiration of the R_PDO.

Object description

Index	1400 – 1403 _h
Name	1st, 2nd, 3rd and 4th receive PDO parameters
Object code	Record
Data type	—

Value description

Sub-index	00 _h , Largest supported sub-index
Meaning	Largest supported sub-index
Access	Read only
PDO mapping	—
Value range	Unsigned8
Default value	05 _h
Category	—

Sub-index	01 _h , COB-ID used by PDO
Meaning	COB-ID used by PDO
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	1400 _h = 0200 _h + node ID 1401 _h = 0300 _h + node ID 1402 _h = 0400 _h + node ID 1403 _h = 0500 _h + node ID
Category	Yes

Sub-index	02 _h , Transmission type
Meaning	Transmission type
Access	Read-write
PDO mapping	—
Value range	Unsigned8
Default value	255 (asynchronous)
Category	Yes

Sub-index	03 _h , Inhibit time
Meaning	Inhibit time
Access	Read-write
PDO mapping	—
Value range	Unsigned16
Default value	0000 _h
Category	Yes

Sub-index	05 _h , Event timer
Meaning	Event timer
Access	Read-write
PDO mapping	—
Value range	Unsigned16
Default value	0000 _h
Category	Yes

8.5.19 1600 – 1603_h Receive PDO mapping parameter

Contains the mapping for the PDOs the device is able to receive. The type of the PDO mapping parameter (21_h) is described in Section 9.5.4 of CiA DS-301: CANopen Application Layer and Communications Profile.. The sub-index 0_h contains the number of valid entries within the mapping record. This number of entries is also the number of the application variables which shall be transmitted/received with the corresponding PDO. The sub-indices from 1_h to number of entries contain the information about the mapped application variables. These entries describe the PDO contents by their index, sub-index and length. All three values are hexadecimal coded. The length entry contains the length of the object in bit (1..40_h).

This parameter can be used to verify the overall mapping length. It is mandatory.

The structure of the entries from sub-index 1_h – 40_h is as follows:

Byte:	MSB		LSB
	Index (16-bit)	Sub-Index (8-Bit)	Object Length (8-Bit)

Figure 8.9: Structure of the PDO mapping entry

If the change of the PDO mapping cannot be executed (e.g. the PDO length is exceeded or the SDO client attempts to map an object that cannot be mapped) the device responds with an Abort SDO Transfer Service.

Sub-index 0 determines the valid number of objects that have been mapped. For changing the PDO mapping first the PDO has to be deleted, the sub-index 0 must be set to 0 (mapping is deactivated). Then the objects can be remapped. When a new object is mapped by writing a sub-index between 1 and 64, the device may check whether the object specified by index / sub-index exists. If the object does not exist or the object cannot be mapped, the SDO transfer must be aborted with the Abort SDO Transfer Service with one of the abort codes 0602 0000_h or 0604 0041_h.

After all objects are mapped sub-index 0 is set to the valid number of mapped objects. Finally the PDO will be created by writing to its communication parameter COB-ID. When sub-index 0 is set to a value >0 the device may validate the new PDO mapping before transmitting the response of the SDO service. If an error is detected the device has to transmit the Abort SDO Transfer Service with one of the abort codes 0602 0000_h, 0604 0041_h or 0604 0042_h.

When sub-index 0 is read the actual number of valid mapped objects is returned. If data types (Index 1_h-7_h) are mapped they serve as „dummy entries“. The corresponding data in the PDO is not evaluated by the device. This optional feature is useful e.g. to transmit data to several devices using one PDO, each device only utilising a part of the PDO. It is not possible to create a dummy mapping for a T_PDO.

A device that supports dynamic mapping of PDOs must support this during the state PREOPERATIONAL state. If dynamic mapping during the state OPERATIONAL is supported, the SDO client is responsible for data consistency.




Figure 8.10: Principle of PDO mapping

Object description

Index	1600 – 1603 _h
Name	1st, 2nd, 3rd and 4th receive PDO mapping
Object code	Record
Data type	—

Value description

Sub-index	00 _h , Number of mapped application objects
Meaning	Number of mapped application objects
Access	Read-write
PDO mapping	—
Value range	1 – 64
Default value	1600 _h = 1 1601 _h = 2 1602 _h = 2 1603 _h = 2
Category	Yes

Sub-index	01 _h , PDO mapping 1st application object
Meaning	PDO mapping 1st application object
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	1600 _h = 6040 0010 _h 1601 _h = 6040 0010 _h 1602 _h = 6040 0010 _h 1603 _h = 6040 0010 _h
Category	Yes

Sub-index	02 _h , PDO mapping 2nd application object
Meaning	PDO mapping 2nd application object
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	1600 _h = 0000 0000 _h 1601 _h = 607A 0020 _h (Profile position – target position) 1602 _h = 60FF 0020 _h (Profile velocity – target velocity) 1603 _h = 6071 0020 _h (Profile torque – target torque)
Category	Yes

Sub-index	03 – 08 _h , PDO mapping <i>n</i> th application object
Meaning	PDO mapping <i>n</i> th application object
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	1600 _h = 0000 0000 _h 1601 _h = 0000 0000 _h 1602 _h = 0000 0000 _h 1603 _h = 0000 0000 _h
Category	Yes

8.5.20 1800 – 1803_h Receive PDO mapping parameter

Contains the communication parameters for the PDOs the device is able to transmit. The type of the PDO communication parameter (20_h) is described in 9.5.4 of CiA DS-301: CANopen Application Layer and Communications Profile. A detailed description of the entries is done in the section for the Receive PDO Communication Parameter (1400_h – 1403_h).

Object description

Index	1800 – 1803 _h
Name	1st, 2nd, 3rd and 4th transmit PDO parameters
Object code	Record
Data type	—

Value description

Sub-index	00 _h , Largest supported sub-index
Meaning	Largest supported sub-index
Access	Read only
PDO mapping	—
Value range	Unsigned8
Default value	05 _h
Category	—

Sub-index	01 _h , COB-ID used by PDO
Meaning	COB-ID used by PDO
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	1800 _h = 0180 _h + node ID 1801 _h = 0280 _h + node ID 1802 _h = 0380 _h + node ID 1803 _h = 0480 _h + node ID
Category	Yes

Sub-index	02 _h , Transmission type
Meaning	Transmission type
Access	Read-write
PDO mapping	—
Value range	Unsigned8
Default value	255 (asynchronous)
Category	Yes

Sub-index	03 _h , Inhibit time
Meaning	Inhibit time
Access	Read-write
PDO mapping	—
Value range	Unsigned16
Default value	0000 _h
Category	Yes

Sub-index	05 _h , Event timer
Meaning	Event timer
Access	Read-write
PDO mapping	—
Value range	Unsigned16
Default value	1800 _h = 0 1801 _h = 100 1802 _h = 100
Category	Yes

8.5.21 1A00 – 1A02_h Transmit PDO mapping parameter

Contains the mapping for the PDOs the device is able to transmit. The type of the PDO mapping parameter (21_h) is described in 9.5.4 of CiA DS-301: CANopen Application Layer and Communications Profile. A detailed description of the entries is done in the Section 8.5.19 for the Receive PDO Mapping Parameter (1600_h – 1602_h).

Object description

Index	1A00 – 1A02 _h
Name	1st, 2nd and 3rd transmit PDO mapping
Object code	Record
Data type	—

Value description

Sub-index	00 _h , Number of mapped application objects
Meaning	Number of mapped application objects
Access	Read-write
PDO mapping	—
Value range	1 – 64
Default value	1A00 _h = 1 1A01 _h = 2 1A02 _h = 2 1A03 _h = 1
Category	Yes

Sub-index	01 _h , PDO mapping 1st application object
Meaning	PDO mapping 1st application object
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	1A00 _h = 6041 0010 _h (Status Word) 1A01 _h = 6041 0010 _h (Status Word) 1A02 _h = 6041 0010 _h (Status Word) 1A03 _h = 6041 0010 _h (Status Word)

Category	Yes
Sub-index	02 _h , PDO mapping 2nd application object
Meaning	PDO mapping 2nd application object
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	1800 _h = 0000 0000 _h 1801 _h = 6064 0020 _h (Profile position – position actual value) 1802 _h = 606C 0020 _h (Profile velocity – velocity actual value) 1803 _h = 0000 0000 _h
Category	Yes
Sub-index	03 – 08 _h , PDO mapping <i>n</i> th application object
Meaning	PDO mapping <i>n</i> th application object
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	1600 _h = 0000 0000 _h 1601 _h = 0000 0000 _h 1602 _h = 0000 0000 _h 1603 _h = 0000 0000 _h
Category	Yes

8.6 Details of object group 2000_h (Mfg specific)

The objects detailed in this section are Schneider Electric Motion USA manufacturer specific configuration objects to configure the manufacturer object specific to the Lexium MDrive CANopen node.

8.6.1 2000_h I/O configuration

This object facilitates the configuration of the input and output points available on Lexium MDrive CANopen devices. The sub-indexes 4 and 5, which may be configured as sinking or sourcing inputs or outputs. Each bit of the sub-indices are mapped to a particular I/O point with I/O 12 being the Most Significant bit (MSb) and I/O 1 being the Least Significant bit (LSb). The configuration options are:

- 1) Sub-Index 01_h: Reserved
- 2) Sub-Index 02_h: Reserved
- 3) Sub-Index 03_h: Reserved
- 4) Sub-Index 04_h: This allows the configuration of inputs to read inverted polarity. By default this is deactivated and setting the bit to a 1 will change the invert polarity read by the input. See Optional Application FE, Object 60DF.
- 5) Sub-Index 05_h: This allows the configuration of outputs to invert the output polarity. See Optional Application FE, Object 60FE.

The I/O configuration is saved using the Store Parameters Object (1010h).

Object description

Index	2000 _h
Name	I/O configuration
Object code	ARRAY
Data type	Unsigned8

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	05 _h
Category	—

Sub-index	01 _h - 03 _h
Meaning	Reserved
Access	—
PDO mapping	—
Value range	—
Default value	—
Category	Yes

Sub-index	04 _h , Configure as polarity in
Meaning	Configure as polarity in (See object 60FD _h sub-index 01 _h)
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	00 _h
Category	Yes

Sub-index	05 _h , Configure as polarity out
Meaning	Configure as polarity out
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	00 _h (See object 60FE _h sub-index 01 _h)
Category	Yes

8.6.2 2003_h Configure input switches

Object 2002 facilitates the configuration of input switches. Input switches may be configured as the following types:

- 1) Home
- 2) Positive Limit
- 3) Negative Limit
- 4) Inhibit (Inhibit Switch function is configured by Object 2007h)

Object description

Index	2002 _h
Name	Configure input switches
Object code	ARRAY
Data type	Unsigned8

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	04 _h
Category	—

Sub-index	01 _h , Configure input as home
Meaning	Configure input as home switch (I/O point bit(s) = 1 _b to select as home)
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	00 _h
Category	Yes

Sub-index	02 _h , Configure input as positive limit
Meaning	Configure input as + Limit (I/O point bit(s) = 1 _b to select as + limit)
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	00 _h
Category	Yes

Sub-index	03 _h , Configure input as negative limit
Meaning	Configure input as – Limit (I/O point bit(s) = 1 _b to select as – limit)
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	00 _h
Category	Yes

Sub-index	04 _h , Configure inhibit switch
Meaning	Configure inhibit switch (I/O point bit(s) = 1 _b to select as inhibit). Use object 2007 _h to define inhibit function.
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	00 _h
Category	Yes

8.6.3 2004_h Configure input filter mask

The Input filter mask object configure s the device to filter the selected inputs. Sub-indices 01_h through 04_h define the inputs to which filtering will be applied. Object 2006_h defines the filter time applied to each input.




Figure 8.12: Input filter mask

Object description

Index	2004 _h
Name	Configure input mask
Object code	ARRAY
Data type	—

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	08 _h
Category	—

Sub-index	01 _h , Configure mask for Input 1
Meaning	Configure mask for Input 1
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	01 _h
Category	Yes

Sub-index	02 _h , Configure mask for Input 2
Meaning	Configure mask for Input 2
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	02 _h
Category	Yes

Sub-index	03 _h , Configure mask for Input 3
Meaning	Configure mask for Input 3
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	04 _h
Category	Yes

Sub-index	04 _h , Configure mask for Input 4
Meaning	Configure mask for Input 4
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	08 _h
Category	Yes

Sub-index	05 _h - 08 _h , reserved
Meaning	reserved
Access	reserved
PDO mapping	—
Value range	—
Default value	—
Category	Yes

8.6.4 2006_h Configure input filter time

This object sets the input filter time in milliseconds. Each sub-index applies to a specific input where sub-index 01_h applies to input 1, sub-index 02_h applies to input 2 and etc.

Object description

Index	2006 _h
Name	Configure input filter
Object code	ARRAY
Data type	—

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	08 _h
Category	—

Sub-index	01 _h , Configure filter for Input 1
Meaning	Configure filter for Input 1
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	00 _h
Category	Yes

Sub-index	02 _h , Configure filter for Input 2
Meaning	Configure filter for Input 2
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	00 _h
Category	Yes

Sub-index	03 _h , Configure filter for Input 3
Meaning	Configure filter for Input 3
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	00 _h
Category	Yes

Sub-index	05 _h , Configure filter for Input 4
Meaning	Configure filter for Input 4
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	00 _h
Category	Yes

Sub-index	05 _h , Configure filter for Input 9
Meaning	Configure filter for Input 9
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	00 _h
Category	Yes

Sub-index	06 _h , Configure filter for Input 10
Meaning	Configure filter for Input 10
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	00 _h
Category	Yes

Sub-index	07 _h , Configure filter for Input 11
Meaning	Configure filter for Input 11
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	00 _h
Category	Yes

Sub-index	08 _h , Configure filter for Input 12
Meaning	Configure filter for Input 12
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	00 _h
Category	Yes

8.6.7 2007_h Inhibit switch reaction

This object allows the user to configure different actions for an inhibit switch (See Object 2002_h, Sub-index 4_h).

This object will function through Control word overwrites and overrides. The inhibit switch reaction is set using sub-index 01_h.

Object description

Index	2007 _h
Name	Inhibit switch reaction
Object code	ARRAY
Data type	—

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	01 _h
Category	—

Sub-index	01 _h , Inhibit switch reaction
Meaning	Inhibit switch reaction
Access	Read-write
PDO mapping	—
Value range	1 – 12
Default value	12
Category	Yes

Value	Meaning
0	No action
1	Fault signal - Control word overwrite
2	Fault signal - Control word override
3	Disable voltage command - Control word overwrite
4	Disable voltage command - Control word override
5	Quick stop command - Control word overwrite
6	Quick stop command - Control word override
7	Shutdown command - Control word overwrite
8	Shutdown command - Control word override
9	Disable operation command - Control word overwrite
10	Disable operation command - Control word override
11	Halt command - Control word overwrite
12	Halt command - Control word override

Table 8.9: Inhibit switch reactions

8.6.8 2008_h Output definition

This object allows the user to configure one or more outputs as brake outputs. For an explanation of brake functions, see Object 2035_h: Brake Timers

Object description

Index	2008 _h
Name	Output definition
Object code	ARRAY
Data type	—

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	02 _h
Category	—

Sub-index	01 _h , Brake output defined
Meaning	Brake output defined
Access	Read-write
PDO mapping	—
Value range	Unsigned8
Default value	00 _h
Category	Yes

Sub-index	02 _h , Target reached output defined
Meaning	Target reached output defined
Access	Read-write
PDO mapping	—
Value range	Unsigned8
Default value	00 _h
Category	Yes

Output selected	Setting
1	Sub-index = 01 _h
2	Sub-index = 02 _h
3	Sub-index = 04 _h

Table 8.10: Brake and target reached output definition

8.6.9 2010_h Analog input configuration

This object allows the user to configure the 12-bit Analog Input. There are 3 sub-indices that set the configuration properties for the input:

- 1) Sub-Index 01_h: Analog Full Scale. This has a range of 0 to 4095 and sets the full scale of the analog input.
- 2) Sub-Index 02_h: This sets the type of device the Analog Input will read. It can be set for two modes, Voltage with ranges of 0 to 5V or 0 to 10V, or Current with an input range of 0 to 20 mA.
- 3) Sub-Index 03_h: This sets the filtering for the Analog Input. In the 0 (default) setting the filtering is off.

Object description

Index	2010 _h
Name	Analog input configuration
Object code	ARRAY
Data type	—

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	03 _h
Category	—

Sub-index	01 _h , Analog input reading
Meaning	Analog input reading
Access	Read-only
PDO mapping	Yes – T_PDO
Value range	0 – 4095 _d (0000 – FFFF _h – Unsigned16)
Default value	—
Category	—

Sub-index	02 _h , Analog input configuration
Meaning	Analog input configuration
Access	Read-write
PDO mapping	—
Value range	00 _h , 02 _h , or 08 _h (Unsigned8)
Default value	00 _h
Category	Yes

Sub-index 02 _h	Analog input mode
00 _h	0 to 5 V scale
02 _h	4 to 20 mA scale
08 _h	0 to 10 V scale

Sub-index	03 _h , Analog filter level
Meaning	Analog filter level
Access	Read-write
PDO mapping	—
Value range	00 – 31 _h (Unsigned8)
Default value	00 _h
Category	Yes

8.6.10 2014_h Auxiliary power input monitoring

This object allows for the user to monitor the voltage level of the aux-power input, as well as establish low and high level warning limits. This input provides power to logic and feedback circuitry in the event of a main power loss.

The reading is given as voltage X 10 i.e. 244 = 24.4 VDC.

Object description

Index	2014 _h
Name	Auxiliary power input monitoring
Object code	ARRAY
Data type	—

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	03 _h
Category	—

Sub-index	01 _h , Aux-power input reading
Meaning	Aux-power input reading
Access	Read-only
PDO mapping	Yes – T_PDO
Value range	0 – 280 _d (0000 – 0118 _h – Unsigned16)
Default value	—
Category	—

Sub-index	02 _h , Aux-power input low-level warning
Meaning	Aux-power input low-level warning
Access	Read-write
PDO mapping	—
Value range	0 – 280 _d (0000 – 0118 _h – Unsigned16)
Default value	00 _h
Category	Yes

Sub-index	03 _h , Aux-power input high-level warning
Meaning	Aux-power input high-level warning
Access	Read-write
PDO mapping	—
Value range	0 – 280 _d (0000 – 0118 _h – Unsigned16)
Default value	280 _d (0118 _h)
Category	Yes

8.6.11 2015_h +VDC input monitoring

This object allows for the user to monitor the voltage level of the motor power input (+VDC), as well as establish low and high level warning limits.

The reading is given as voltage X 10 i.e. 448 = 44.8 VDC.

Object description

Index	2015 _h
Name	+VDC input monitoring
Object code	ARRAY
Data type	—

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	03 _h
Category	—

Sub-index	01 _h , +VDC input monitoring
Meaning	+VDC input monitoring
Access	Read-only
PDO mapping	Yes – T_PDO
Value range	0 – 800 _d (0000 – 0320 _h – Unsigned16)
Default value	—
Category	—

Sub-index	02 _h , +VDC input low-level warning
Meaning	+VDC input low-level warning
Access	Read-write
PDO mapping	—
Value range	0 – 800 _d (0000 – 0320 _h – Unsigned16)
Default value	100 _d (64 _h)
Category	Yes

Sub-index	03 _h , +VDC input high-level warning
Meaning	+VDC input high-level warning
Access	Read-write
PDO mapping	—
Value range	0 – 800 _d (0000 – 0320 _h – Unsigned16)
Default value	580 _d (244 _h)
Category	Yes

8.6.12 2018_h PCB temperature options

This object reflects the temperature of the PCB as measured at the micro-processor. There are 3 sub-indices:

- 1) Sub-Index 01_h: Read-only sub-index that reads the internal temperature of the device. May be mapped to a PDO
- 1) Sub-Index 02_h: Temperature Warning parameter allows for the setting of a parameter that will generate an error (Index 1003 – 0016 4210_h) if the warning threshold is reached. the default is 80°C.
- 1) Sub-Index 03_h: This sub-index sets the threshold for a temperature fault. Note that the outputs of the device will disable at 85°C regardless of the setting for this parameter. if reached, the error message will be located at Index 1003_h. The error code is byte will read 0008 4210_h.

The units for this object are degrees Celsius (°C).

Object description

Index	2018 _h
Name	PCB temperature options
Object code	ARRAY
Data type	Signed8

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	03 _h
Category	—

Sub-index	01 _h , PCB temperature reading
Meaning	PCB temperature reading
Access	Read-only
PDO mapping	Yes – T_PDO
Value range	—
Default value	—
Category	—

Sub-index	02 _h , PCB temperature warning threshold
Meaning	PCB temperature warning threshold
Access	Read-write
PDO mapping	—
Value range	-50 to +120 _d (Signed8)
Default value	80 _d
Category	Yes

Sub-index	03 _h , PCB temperature fault
Meaning	PCB temperature fault
Access	Read-write
PDO mapping	—
Value range	-50 to +120 _d (Signed8)
Default value	85 _d
Category	Yes

8.6.13 2019_h Bridge temperature options

This object reflects the temperature of the output bridge as measured at the bridge. There are 3 sub-indices:

- 1) Sub-Index 01_h: Read-only sub-index that reads the bridge temperature of the device. May be mapped to a PDO
- 1) Sub-Index 02_h: Temperature Warning parameter allows for the setting of a parameter that will generate an error (Index 1003 - 0016 4210_h) if the warning threshold is reached. the default is 80°C.
- 1) Sub-Index 03_h: This sub-index sets the threshold for a temperature fault. Note that the outputs of the device will disable at 85°C regardless of the setting for this parameter. if reached, the error message will be located at Index 1003_h. The error code is byte will read 0008 4210_h.

The units for this object are degrees Celsius (°C).

Object description

Index	2018 _h
Name	Bridge temperature options
Object code	ARRAY
Data type	Signed8

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	03 _h
Category	—

Sub-index	01 _h , Bridge temperature reading
Meaning	Bridge temperature reading
Access	Read-only
PDO mapping	Yes – T_PDO
Value range	—
Default value	—
Category	—

Sub-index	02 _h , Bridge temperature warning threshold
Meaning	Bridge temperature warning threshold
Access	Read-write
PDO mapping	—
Value range	-50 to +120 _d (Signed8)
Default value	80 _d
Category	Yes

Sub-index	03 _h , Bridge temperature fault
Meaning	Bridge temperature fault
Access	Read-write
PDO mapping	—
Value range	-50 to +120 _d (Signed8)
Default value	85 _d
Category	Yes

8.6.14 2020_h Software limits as hardware

This object defines the actions taken when the Position Software Limit for Object 2022_h is reached. It consists of 2 sub-indices.

- 2) Sub-index 01_h: Limit reached flag. This flag will be set based upon the status of a limit, it will register whether the limit reached is a hardware limit or a software limit. The statusword (6041_h), bit 11, internal limit active will set whenever the flag is not 0. The action taken for a limit reached condition will be determined by the limit mask sub-index.

Status	Bit 3	Bit 4	Bit 1	Bit 0
Negative hardware limit reached	0	0	0	1
Positive hardware limit reached	0	0	1	0
Negative software limit reached	0	1	0	0
Positive software limit reached	1	0	0	0

Table 8.11: Description of limit reached flag 2020.01_h

- 3) Sub-index 02_h: Limit reached mask




Figure 8.13: Software limits as hardware functions

Object description

Index	2020 _h
Name	Software limits as hardware
Object code	ARRAY
Data type	Unsigned8

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	02 _h
Category	—

Sub-index	01 _h , Limit reached flag
Meaning	Limit reached flag
Access	Read-write
PDO mapping	—
Value range	00 – 0F _h
Default value	00 _h
Category	—

Sub-index	02 _h , Limit reached mask
Meaning	Limit reached mask
Access	Read-write
PDO mapping	—
Value range	00 – 0F _h
Default value	03 _h
Category	Yes

8.6.15 2022_h Actual position software limit

This object defines the software limit based on set negative and positive limits set in actual position counts. See object 2020_h for a description of software limit functionality and configuration.

- 1) Sub-index 01_h: Actual negative limit
- 2) Sub-index 02_h: Actual positive limit

Object description

Index	2022 _h
Name	Actual position software limit
Object code	ARRAY
Data type	Signed32

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	02 _h
Category	—

Sub-index	01 _h , Actual negative limit
Meaning	Actual negative limit
Access	Read-write
PDO mapping	—
Value range	Signed32
Default value	8000 0000 _h
Category	—

Sub-index	02 _h , Actual positive limit
Meaning	Actual positive limit
Access	Read-write
PDO mapping	—
Value range	Signed32
Default value	7FFF FFFF _h
Category	Yes

8.6.16 2030_h Output bridge polarity

This object defines the polarity of the output bridge where positive=clockwise and negative=counter clockwise (default). By changing this to a negative integer between -128 to -1 the polarity of the bridge, thus the default CW/CCW motor direction can be swapped.

There is no value assigned to the number, any negative integer from -128 to -1 will reverse the bridge polarity, any positive integer from 0 to 127 will reset the polarity to the default CW/CCW motor direction configuration.

Object description

Index	2030 _h
Name	Output bridge polarity
Object code	VAR
Data type	Signed8

Value description

Sub-index	00 _h , Output bridge polarity
Meaning	Output bridge polarity
Access	Read-write
PDO mapping	—
Value range	-128 to 127 _d
Default value	0 _d
Category	Yes

8.6.17 2031_h Unit options (encoder enable, trip/capture enable)

This object defines the configuration of the following unit options:

- 1) Encoder sync actions (bits 5, 4). Encoder sync will determine whether the encoder counter, position counter or -home offset will be the master counter for synchronizing the counters. If -home offset is used it will function as homing 35.
- 2) Encoder enable (bit 3)
- 3) Trip output/capture input (bit 2)

Note: Encoder functions only apply to the Lexium MDrive products. The MForce products do not have closed loop capability.

Object description

Index	2031 _h
Name	Unit options (encoder enable, trip/capture enable)
Object code	VAR
Data type	Unsigned8

Value description

Sub-index	00 _h , Unit options (encoder enable, trip/capture enable)
Meaning	Unit options (encoder enable, trip/capture enable)
Access	Read-write
PDO mapping	—
Value range	Unsigned8
Default value	00 _h
Category	Yes

Bits	7	6	5	4	3	2	1	0
Function	X	X	sync_action		e/e	c/t	X	X
Encoder auto-sync action (sync_action)								
Bit 5	Bit 4	Bits 5 and 4 control encoder sync action						
0	0	No action						
0	1	Position synced to encoder master						
1	0	Encoder synced to position master						
1	1	Position and encoder synced to –home offset						
Encoder enable (e/e)								
Bit 3	0	Encoder not enabled						
	1	Encoder operation enabled						
Capture/trip select (c/t)								
Bit 2	0	Will operate as a capture input (configure using 2033 _h)						
	1	Will operate as a trip output (configure using 2038 _h)						

Table 8.12: Description of unit options object 2031.00_h

8.6.18 2033_h Capture input parameters

This object configures the functionality of the capture input.

- 1) Sub-index 01_h: Capture input control: sets a bit that will enable the capture input. Note that the capture input must also be selected using object 2031_h.
- 2) Sub-index 02_h: Position captured flag. Displays the status of a position capture by setting the least significant bit (lsb) of an 8-bit unsigned integer. Write all ones to clear the flag.
- 3) Sub-index 03_h: Capture input filter time. This sub-index configures the filtering for the capture input.
- 4) Sub-index 04_h: Captured position. This sub-index holds the captured position.

Object description

Index	2033 _h
Name	Capture input parameters
Object code	REC
Data type	—

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	04 _h
Category	—

Sub-index	01 _h , Capture input enable
Meaning	Capture input enable
Access	Read-write
PDO mapping	—
Value range	0/1 (Unsigned8)
Default value	0 (disabled)
Category	Yes

Sub-index	02 _h , Position captured flag
Meaning	Position captured flag
Access	Read-write
PDO mapping	—
Value range	0/1 (Unsigned8)
Default value	0 (no position captured)
Category	Yes

Sub-index	03 _h , Capture input filter time
Meaning	Capture input filter time
Access	Read-write
PDO mapping	—
Value range	0 – 9 (Unsigned8)
Default value	0 (50ns)
Category	Yes

Value	Filter
0	50ns
1	150ns
2	200ns
3	300ns

Value	Filter
4	500ns
5	900ns
6	1.7µs
7	3.3µs

Value	Filter
8	6.5µs
9	12.9µs

Sub-index	04 _h , Captured position
Meaning	Captured position
Access	Read-only
PDO mapping	—
Value range	Integer32
Default value	0 (no position)
Category	—

8.6.19 2034_h Bridge on settle time

Establishes the time in milliseconds that current in the bridge is allowed to stabilize after power on. This index will delay the device entering operation enabled mode by the time set (0 to 1000ms). It is also a factor in the brake logic block. See object 2035_h for functional block diagram.

Object description

Index	2034 _h
Name	Bridge on settle time
Object code	Array
Data type	Unsigned16

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	01 _h
Category	—

Sub-index	01 _h , Bridge on settle time
Meaning	Bridge on settle time
Access	Read-write
PDO mapping	—
Value range	0 – 1000 _d
Default value	0
Category	Yes

8.6.20 2035_h Brake settle allow time

Establishes the time in milliseconds that the brake is allowed to settle. This object works in cooperation with object 2034.01_h, Bridge on settle allow time. The sequence of events follows for a braking operation:

- 1) Bridge power turns on, object 2034.01_h begins timing the amount of milliseconds specified in sub-index 01_h. This will be the time between bridge power enabled and brake off. This time will also allow time for settling before initial synchronizing with encoder counts.
- 2) Break discrete turns off, object 2035.02_h specifies the time delay from set brake off to allow for motor movement.
- 3) Device enters the operation enabled state of the state machine. Motion occurs.
- 4) Motion ceases, the brake engages, object 2035.01_h specifies the time delay from set brake on to removal of bridge power.




Figure 8.14: Bridge to brake timing




Figure 8.15: Brake functions block diagram

Object description

Index	2035 _h
Name	Brake settle allow time
Object code	ARRAY
Data type	—

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	02 _h
Category	—

Sub-index	01 _h , Brake on settle time
Meaning	Brake on settle time
Access	Read-write
PDO mapping	—
Value range	0 – 2000 _d (ms)
Default value	0
Category	Yes

Sub-index	02 _h , Brake off settle time
Meaning	Brake off settle time
Access	Read-write
PDO mapping	—
Value range	0 – 1000 _d (ms)
Default value	0
Category	Yes

8.6.21 2036_h Hold current delay time

Defines the delay time in milliseconds between the device switching from the run current (object 2204_h) to the holding current (object 2205_h)

Object description

Index	2036 _h
Name	Hold current delay time
Object code	VAR
Data type	Unsigned16

Value description

Sub-index	00 _h , Hold current delay time
Meaning	Hold current delay time
Access	Read-write
PDO mapping	—
Value range	0 _d (off) or 2 to 65535 _d (ms)
Default value	500 _d (ms)
Category	Yes

8.6.22 2037_h Bridge on to encoder settle time

Defines the delay time in milliseconds between the device switching into operation enable to resynching the encoder position. Only applicable on Lexium MDrive models equipped with an encoder.

Object description

Index	2037 _h
Name	Bridge on to encoder settle time
Object code	VAR
Data type	Unsigned16

Value description

Sub-index	00 _h , Bridge on to encoder settle time
Meaning	Bridge on to encoder settle time
Access	Read-write
PDO mapping	—
Value range	0 _d to 3000 _d (ms)
Default value	300 _d (ms)
Category	Yes

8.6.23 2038_h Trip output configuration

This object configures the functionality of the trip output which will pulse the output upon reaching particular position_demand_effort_position(s).

Values are in Internal Units, based on 51200/rev and not necessarily scaled to user units. Also note trip is activated on position demand effort, and not actual position or encoder position.

This definition of point(s) begins with sub-index 2038.02_h (1st position of a series) then add sub-index 2038.03_h to form the specified number of trip points.

- 1) Sub-index 01_h: Trip output control: controls the logic and trip points and is used to set up one or multiple trip positions. Note that the trip output must also be selected using object 2031_h.
- 2) Sub-index 02_h: 1st trip point of a series. Defines the first trip point of a series of points.
- 3) Sub-index 03_h: Capture input filter time. This sub-index configures the filtering for the capture input.
- 4) Sub-index 04_h: Multiple trip point spacing. This sub-index defines the modulus, or spacing between the trip points. Scaled at 51200 steps/rev.

Object description

Index	2038 _h
Name	Trip output configuration
Object code	REC
Data type	—

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	03 _h
Category	—

Sub-index	01 _h , Trip output control
Meaning	Trip output control
Access	Read-write
PDO mapping	—
Value range	Unsigned16
Default value	0000 _h
Category	Yes

Sub-index 01 _h value range		
Bit: 15 (trip enable)	14 ... 12	Bits: 11 ... 0 (number of trip points)
0= disabled, 1=enabled	0 0 0	0=infinite, 1 – 4095=# trip points from start

V1.00, 09.2014

Sub-index	02 _h , First trip point
Meaning	First trip point
Access	Read-write
PDO mapping	—
Value range	Integer32
Default value	0000 0000 _h
Category	Yes

Sub-index	03 _h , Multiple trip point spacing
Meaning	Multiple trip point spacing
Access	Read-write
PDO mapping	—
Value range	Integer32
Default value	5120 _d
Category	Yes

8.6.24 2098_h Homing configuration

Determines the position or encoder counter status following a home. If 0 the position or encoder counter will clear following a home. If 0, the position and encoder counter will NOT be assigned, following a homing attained. The exception to this rule is when performing homing method 35.

If 1 (default) the device will subtract the homing offset (object 607C_h) from the counter and set the counter to the difference.

Object description

Index	2098 _h
Name	Homing configuration
Object code	VAR
Data type	Unsigned8

Value description

Sub-index	00 _h , Homing configuration
Meaning	Homing configuration
Access	Read-write
PDO mapping	—
Value range	0/1
Default value	1
Category	Yes

8.6.25 2204_h Run current

This object sets the percentage of full current at which the device will operate.

Object description

Index	2204 _h
Name	Run current
Object code	VAR
Data type	Unsigned8

Value description

Sub-index	00 _h , Run current
Meaning	Run current
Access	Read-write
PDO mapping	—
Value range	1 – 100 _d (%)
Default value	50 (%)

8.6.26 2205_h Hold current

This object sets the percentage of full current at which the device will transition to when motion ceases.

Object description

Index	2205 _h
Name	Hold current
Object code	VAR
Data type	Unsigned8

Value description

Sub-index	00 _h , Hold current
Meaning	Hold current
Access	Read-write
PDO mapping	—
Value range	0 – 100 _d (%)
Default value	5 (%)
Category	Yes

8.6.27 2211_h Position present point target

This object contains the position present point target

<i>Object description</i>	Index	2211 _h
	Name	Position present point target
	Object code	VAR
	Data type	Integer32
<i>Value description</i>	Sub-index	00 _h , Position present point target
	Meaning	Position present point target
	Access	Read-only
	PDO mapping	—
	Value range	±2 ³¹
	Default value	0
	Category	—

8.6.28 2212_h Position final point target

This object contains the position final point target

<i>Object description</i>	Index	2212 _h
	Name	Position final point target
	Object code	VAR
	Data type	Integer32
<i>Value description</i>	Sub-index	00 _h , Position final point target
	Meaning	Position final point target
	Access	Read-only
	PDO mapping	—
	Value range	±2 ³¹
	Default value	0
	Category	—

8.6.29 2221_h Following error

This object defines an action to take in the event of a following error (Idx 6041 bit 13).

Object description

Index	2221 _h
Name	Following error
Object code	VAR
Data type	Integer32

Value description

Sub-index	00 _h , Number of entries
Meaning	Number of entries
Access	Read only
PDO mapping	—
Value range	—
Default value	01 _h
Category	—

Sub-index	01 _h , Following error reaction code
Meaning	Following error reaction code
Access	Read-only
PDO mapping	—
Value range	—
Default value	0 - 2
Category	—

Sub-index 01 _h value range	
Value	Action
0	No action taken
1	Post-move to correct for error after initial move
2	Post-move to correct for error after initial move, the adjust for encoder position

8.6.30 2401_h General purpose user variable

This object is a general purpose user variable which can be used to store 8-bits of data.

Object description

Index	2401 _h
Name	General purpose user variable
Object code	VAR
Data type	Integer32

Value description

Sub-index	00 _h , General purpose user variable
Meaning	General purpose user variable
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	0
Category	—

8.6.31 2504_h SEM options

This object allows interoperability with Schneider Electric Twido PLC's and will not ordinarily be used.

Object description

Index	2504 _h
Name	SEM options
Object code	VAR
Data type	Integer32

Value description

Sub-index	00 _h , SEM options
Meaning	SEM options
Access	Read-write
PDO mapping	—
Value range	00 – FF _h
Default value	0
Category	—

8.6.32 2701_h hMTechnology enable

This object controls the enable/disable state of the hMTechnology control circuitry.

- Disabled = 00_h
- Enabled = 80_h

Object 2701_h is only available on Lexium MDrive closed loop models.

Object description

Index	2701 _h
Name	Hybrid enable
Object code	VAR
Data type	Unsigned8

Value description

Sub-index	00 _h , Hybrid enable
Meaning	Hybrid enable
Access	Read-write
PDO mapping	—
Value range	00 _h or 80 _h
Default value	00 _h
Category	Yes

8.6.33 2702_h hMTechnology configuration

This object sets the parameters of the hMTechnology (hMT)operation. The following parameters are set:

- 1) **Fixed/variable current (bit 7):** hMT can operate using two current modes: fixed and variable. In fixed current mode the device will operate using the settings of the run (object 2204_h) and hold (object 2205_h) current set parameters. In variable current mode the device will adjust the current between the run and hold current settings to what is required to move the load at the desired velocity.
- 2) **Control boundaries (bits 6 ... 5):** HMT functions by closely monitoring the relationship between the rotor and stator of the motor to within set boundaries from 1.1 to 1.7 motor full steps where a lower setting gives enhanced torque performance and a higher setting deliver batter speed performance.
- 3) **Make-up mode (bits 1 ... 0):** If enabled, hMT control will make-up for lost steps in the move profile. This can occur at a fixed velocity of 2.5 MHz or at a speed preset using object 2703_h.

Object 2701_h is only avialable on Lexium MDrive closed loop models.

Object description

Index	2702 _h
Name	hMTechnology configuration
Object code	VAR
Data type	Unsigned8

Value description

Sub-index	00 _h , hMTechnology configuration
Meaning	hMTechnology configuration
Access	Read-write
PDO mapping	—
Value range	See Table 8.13 (Unsigned8)
Default value	A2 _h
Category	Yes

Bits	7	6	5	4	3	2	1	0
------	---	---	---	---	---	---	---	---

Function		cur_fv	c_bnds	X	X	X	mu
Current mode (cur_fv)							
Bit 7	0	Fixed current (default)					
	1	Variable current					
Control bounds (c_bnds)							
Bit 6	Bit 5						
0	0	1.1 full steps (best torque performance)					
0	1	1.3 full steps (default)				(Best overall performance)	
1	0	1.5 ful steps					
1	1	1.7 full steps (best speed performance)					
Make-up mode (mu)							
Bit 1	Bit 0						
0	0	Make up disabled					
0	1	reserved					
1	0	Make-up velocity = 2.5 MHz (default)					
1	1	Make-up velocity = 2703 _h setting					

Table 8.11: Description of clock options object 2032.01_h

8.6.34 2703_h Make-up velocity

Defines the velocity for hybrid make-up (Object 2702_h, bits 1 ... 0) if selected. The make-up period is determined using the equation:

Frequency = (x+2) * 50ns where x is the setting of 2703_h

e.g. (1998+2) * 50 = 100000 steps/sec

Object 2703_h is only available on Lexium MDrive closed loop models.

Object description

Index	2703 _h
Name	Make-up velocity
Object code	VAR
Data type	Unsigned32

Value description

Sub-index	00 _h , Make-up velocity
Meaning	Make-up velocity
Access	Read-write
PDO mapping	—
Value range	Unsigned32
Default value	1998 _d (100000 steps/sec)
Category	Yes

8.6.35 2704_h Torque velocity

Defines the maximum velocity for Profile Torque mode.

Velocity = 12 Mhz (x+2) where x is the setting of 2703_h

e.g. $12 \times 10^6 / (98+2) = 120000$ steps/sec @ torque (Idx 6071)

Idx 2704_h is only available on Lexium MDrive closed loop models.

Object description

Index	2704 _h
Name	Torque velocity
Object code	VAR
Data type	Unsigned8

Value description

Sub-index	00 _h , Torque velocity
Meaning	Torque velocity
Access	Read-write
PDO mapping	—
Value range	Unsigned8
Default value	98 _d (120000 steps/sec)
Category	Yes

8.6.36 2740_h Clear locked rotor

Used to clear the locked rotor status flag. Sending 04_h will clear a locked rotor indication.

Object description

Index	2740 _h
Name	Clear locked rotor
Object code	VAR
Data type	Unsigned8

Value description

Sub-index	00 _h , Clear locked rotor
Meaning	Clear locked rotor
Access	Read-write
PDO mapping	Yes, R_PDO
Value range	Unsigned8
Default value	—
Category	Yes

8.6.37 2741_h hMTechnology status (filtered)

Indicates the status of the hMTechnology logic. This object may be filtered using Idx 2743. The purpose behind the filter is that the object is PDO mappable. Bit 4, hMT intervening may cycle rapidly between states, if mapped to a PDO this can flood the bus with messages.

7	6	5	4	3	2	1	0
Factory	Reserved	Reserved	hMT intervening	Locked rotor	Reserved	Reserved	Fault
	Bit	Value	Meaning				
	1	0	No error				
		1	hMTechnology error state exists				
	3	0	Rotor normal				
		1	Rotor is locked				
	4	0	hMT not intervening				
		1	hMT intervening				
	7	0	N/A				
		1	Factory alignment - This bit will always be 1				

Object 2741_h is only available on Lexium MDrive closed loop models.

Object description

Index	2741 _h
Name	hMT status
Object code	VAR
Data type	Unsigned8

Value description

Sub-index	00 _h , hMT status
Meaning	hMT status
Access	Read-only
PDO mapping	Yes, T_PDO
Value range	Unsigned8
Default value	80 _h
Category	—

8.6.38 2742_h hMTechnology status (unfiltered)

Indicates the status of the hMTechnology logic.

7	6	5	4	3	2	1	0
Factory	Reserved	Reserved	hMT intervening	Locked rotor	Reserved	Reserved	Fault

Bit	Value	Meaning
1	0	No error
	1	hMTechnology error state exists
3	0	Rotor normal
	1	Rotor is locked
4	0	hMT not intervening
	1	hMT intervening
7	0	N/A
	1	Factory alignment - This bit will always be 1

Object 2742_h is only available on Lexium MDrive closed loop models.

Object description

Index	2742 _h
Name	hMT status
Object code	VAR
Data type	Unsigned8

Value description

Sub-index	00 _h , hMT status
Meaning	hMT status
Access	Read-only
PDO mapping	—
Value range	Unsigned8
Default value	80 _h
Category	—

8.6.39 2743_h hMTechnology status byte filter

Filters the status byte of the hMTechnology logic.

7	6	5	4	3	2	1	0
Factory	Reserved	Reserved	hMT intervening	Locked rotor	Reserved	Reserved	Fault
1	1	1	0	1	1	1	1

Object 2743_h is only available on Lexium MDrive closed loop models.

Object description

Index	2743 _h
Name	hMT status filter
Object code	VAR
Data type	Unsigned8

Value description

Sub-index	00 _h , hMT status filter
Meaning	hMT status filter
Access	Read-write
PDO mapping	—
Value range	Unsigned8
Default value	EF _h
Category	—

8.7 Details of object group 5000_h (Mfg factory specific)

Object group 5000_h contains objects factory configuration and are not for end use.

8.8 Details of assignment objects group 6000_h

The objects in group 6000_h are operation specific. See Section 6 for detailed information on these objects.

9 CANopen configurator

9

The software associated with Lexium MDrive CANopen products is contained within the Lexium MDrive Software Suite. This software package is available for download at the Schneider Electric Motion USA web site at <http://motion.schneider-electric.com>.

The modules applicable are:

1. CANopen configuration interface: Graphic User Interface (GUI) for commissioning the Lexium MDrive

See the Lexium MDrive Software Suite manual for installation and usage instructions.

WARRANTY

Reference the web site at www.motion.schneider-electric.com for the latest warranty and product information.

USA SALES OFFICES

East Region

Tel. 610-573-9655

e-mail: e.region@imshome.com

Northeast Region

Tel. 860-368-9703

e-mail: n.region@imshome.com

Central Region

Tel. 630-267-3302

e-mail: c.region@imshome.com

Western Region

Tel. 602-578-7201

e-mail: w.region@imshome.com

EUROPEAN SALES MANAGEMENT

Tel. +33/4 7256 5113 – Fax +33/4 7838 1537

e-mail: europe.sales@imshome.com

TECHNICAL SUPPORT

Tel. +00 (1) 860-295-6102 – Fax +00 (1) 860-295-6107

e-mail: etech@imshome.com

Schneider Electric Motion USA

370 N. Main Street
Marlborough, CT 06447 USA

www.motion.schneider-electric.com

Owing to changes in standards and equipment, the characteristics given in the text and images in this document are not binding until they have been confirmed with us.

Print: Schneider Electric Motion USA
Photos: Schneider Electric Motion USA

Date : 09 / 2014